


**Panasonic**<sup>®</sup>



<KX-UT248>

Model No.

## Administrator Guide SIP Phone

**KX-UT113/KX-UT123  
KX-UT133/KX-UT136  
KX-UT248**

Thank you for purchasing this Panasonic product.  
Please read this manual carefully before using this product and save this manual for future use.

**KX-UT113/KX-UT123/KX-UT133/KX-UT136/KX-UT248: Software File Version 01.160 or later**

In this manual, the suffix of each model number is omitted unless necessary.

Document Version: 2012-06

# Introduction

## Outline

This Administrator Guide provides detailed information on the configuration and management of this unit.

## Audience

This Administrator Guide contains explanations about the installation, maintenance, and management of the unit and is aimed at network administrators and phone system dealers.

Technical descriptions are included in this guide. Prior knowledge of networking and VoIP (Voice over Internet Protocol) is required.

## Related Documentation

### Getting Started

Briefly describes basic information about the installation of the unit.

### Operating Instructions

Describes information about the installation and operation of the unit.

Manuals and supporting information are provided on the Panasonic Web site at:

<http://www.panasonic.com/sip> (for users in the United States)

<http://panasonic.net/pcc/support/sipphone> (for users in all other countries/areas)

## Technical Support

When technical support is required, contact your phone system dealer.

## Open Source Software Notice

Parts of this product use open source software. For details about the open source software, see the Operating Instructions.

## Trademarks

- Microsoft, Excel, Internet Explorer, Outlook, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.
- All other trademarks identified herein are the property of their respective owners.
- Microsoft product screen shot(s) reprinted with permission from Microsoft Corporation.

## NOTES

- The screen shots shown in this guide are provided for reference only, and may differ from the screens displayed on your PC.

# Table of Contents

<b>1 Initial Setup .....</b>	<b>17</b>
<b>1.1 Setup .....</b>	<b>18</b>
1.1.1 Factory Defaults .....	18
1.1.2 Language Selection for the Unit .....	18
1.1.3 Basic Network Setup .....	18
1.1.4 Overview of Programming .....	20
1.1.5 Phone User Interface Programming .....	20
1.1.5.1 Changing the Language for Phone User Interface Programming .....	20
1.1.6 Web User Interface Programming .....	21
1.1.6.1 Password for Web User Interface Programming .....	21
1.1.6.2 Changing the Language for Web User Interface Programming .....	21
1.1.6.3 Before Accessing the Web User Interface .....	22
1.1.6.4 Accessing the Web User Interface .....	23
1.1.7 Other Network Settings .....	27
1.1.7.1 Firewall and Router Setup .....	27
1.1.7.2 NAT (Network Address Translation) Setup .....	28
1.1.7.3 Global Address Detection .....	29
<b>1.2 Reset and Firmware Update .....</b>	<b>29</b>
1.2.1 Reset .....	29
1.2.1.1 Resetting to Factory Default (Factory Setting) .....	29
1.2.1.2 Resetting the Network Settings (IP Reset) .....	30
1.2.1.3 Resetting the Settings Made through the Web User Interface (Reset Web Settings) .....	30
1.2.2 Firmware Update .....	31
<b>2 General Information on Provisioning .....</b>	<b>33</b>
<b>2.1 Pre-provisioning .....</b>	<b>34</b>
2.1.1 What is Pre-provisioning? .....	34
2.1.2 Pre-provisioning when Setting Static IP Addresses .....	35
2.1.3 Server for Pre-provisioning .....	35
2.1.4 Pre-provisioning Setting Example .....	35
<b>2.2 Provisioning .....</b>	<b>38</b>
2.2.1 What is Provisioning? .....	38
2.2.2 Protocols for Provisioning .....	38
2.2.3 Configuration File .....	38
2.2.4 Downloading Configuration Files .....	40
2.2.5 Provisioning Server Setting Example .....	43
2.2.6 Encryption .....	44
<b>2.3 Priority of Setting Methods .....</b>	<b>45</b>
<b>2.4 Configuration File Specifications .....</b>	<b>46</b>
<b>2.5 Configuration File Examples .....</b>	<b>47</b>
2.5.1 Examples of Codec Settings .....	48
2.5.2 Example with Incorrect Descriptions .....	49
<b>2.6 Setting Configuration File Parameters Using TR-069 .....</b>	<b>50</b>
<b>3 Phone User Interface Programming .....</b>	<b>55</b>
<b>3.1 Phone User Interface Programming .....</b>	<b>56</b>
3.1.1 Phone User Interface Feature List and Direct Commands .....	56
3.1.2 Phonebook deletion .....	56
3.1.3 Terminal Number Settings .....	56
3.1.4 Reset Web ID/Password .....	57
3.1.5 Sound Quality (KX-UT113/KX-UT123/KX-UT133/KX-UT136 only) .....	57

---

<b>4 Web User Interface Programming .....</b>	<b>59</b>
<b>4.1 Web User Interface Setting List .....</b>	<b>60</b>
<b>4.2 Status .....</b>	<b>71</b>
<b>4.2.1 Version Information .....</b>	<b>72</b>
<b>4.2.1.1 Version Information .....</b>	<b>72</b>
<b>Model .....</b>	<b>72</b>
<b>Operating Bank .....</b>	<b>72</b>
<b>IPL Version .....</b>	<b>72</b>
<b>Firmware Version .....</b>	<b>72</b>
<b>4.2.2 Network Status .....</b>	<b>73</b>
<b>4.2.2.1 Network Status .....</b>	<b>73</b>
<b>MAC Address .....</b>	<b>73</b>
<b>Ethernet Link Status (LAN Port) .....</b>	<b>73</b>
<b>Ethernet Link Status (PC Port) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only) .....</b>	<b>73</b>
<b>Connection Mode .....</b>	<b>74</b>
<b>IP Address .....</b>	<b>74</b>
<b>Subnet Mask .....</b>	<b>74</b>
<b>Default Gateway .....</b>	<b>74</b>
<b>DNS1 .....</b>	<b>75</b>
<b>DNS2 .....</b>	<b>75</b>
<b>IEEE802.1X Status (KX-UT248 only) .....</b>	<b>75</b>
<b>4.2.3 VoIP Status .....</b>	<b>75</b>
<b>4.2.3.1 VoIP Status .....</b>	<b>76</b>
<b>Line No. .....</b>	<b>76</b>
<b>Phone Number .....</b>	<b>76</b>
<b>VoIP Status .....</b>	<b>76</b>
<b>4.3 Network .....</b>	<b>77</b>
<b>4.3.1 Basic Network Settings .....</b>	<b>77</b>
<b>4.3.1.1 Connection Mode .....</b>	<b>78</b>
<b>Connection Mode .....</b>	<b>78</b>
<b>4.3.1.2 DHCP Settings .....</b>	<b>78</b>
<b>Host Name .....</b>	<b>78</b>
<b>Domain Name Server .....</b>	<b>79</b>
<b>4.3.1.3 Static Settings .....</b>	<b>79</b>
<b>Static IP Address .....</b>	<b>79</b>
<b>Subnet Mask .....</b>	<b>80</b>
<b>Default Gateway .....</b>	<b>80</b>
<b>DNS1 .....</b>	<b>80</b>
<b>DNS2 .....</b>	<b>81</b>
<b>4.3.2 Ethernet Port Settings .....</b>	<b>81</b>
<b>4.3.2.1 Link Speed/Duplex Mode .....</b>	<b>82</b>
<b>LAN Port .....</b>	<b>82</b>
<b>PC Port (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only) .....</b>	<b>82</b>
<b>4.3.2.2 LLDP Settings .....</b>	<b>83</b>
<b>Enable LLDP .....</b>	<b>83</b>
<b>LLDP-MED Interval timer .....</b>	<b>83</b>
<b>IP Phone (VLAN ID) .....</b>	<b>83</b>
<b>IP Phone (Priority) .....</b>	<b>83</b>
<b>PC (VLAN ID) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only) .....</b>	<b>84</b>
<b>PC (Priority) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only) .....</b>	<b>84</b>
<b>4.3.2.3 VLAN Settings .....</b>	<b>84</b>
<b>Enable VLAN .....</b>	<b>84</b>
<b>IP Phone (VLAN ID) .....</b>	<b>84</b>

	IP Phone (Priority) .....	85
	PC (VLAN ID) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only) .....	85
	PC (Priority) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only) .....	85
4.3.3	IEEE802.1X Settings (KX-UT248 only) .....	86
4.3.3.1	IEEE802.1X Settings .....	86
	Enable IEEE802.1X .....	86
4.3.3.2	IEEE802.1X Authentication .....	86
	Authentication Protocol .....	86
	Authentication ID .....	87
	Authentication Password .....	87
4.3.4	HTTP Client Settings .....	87
4.3.4.1	HTTP Client Settings .....	88
	HTTP Version .....	88
	HTTP User Agent .....	88
4.3.4.2	HTTP Authentication .....	88
	Authentication ID .....	88
	Authentication Password .....	89
4.3.4.3	Proxy Server Settings .....	89
	Enable Proxy .....	89
	Proxy Server Address .....	89
	Proxy Server Port .....	89
4.3.5	Global Address Detection .....	89
4.3.5.1	Global Address Detection .....	90
	Detection Method .....	90
	Detection Interval .....	90
4.3.5.2	STUN Server .....	90
	STUN Server Address .....	90
	STUN Server Port .....	91
4.3.6	Static NAPT Settings .....	91
4.3.6.1	Global IP Address .....	91
	Global IP Address .....	91
4.3.6.2	Enable Global IP Address Usage per Line .....	92
	Line 1–Line x .....	92
4.3.6.3	External RTP Port .....	92
	Channel 1–25 .....	92
4.3.7	Application Settings .....	93
4.3.7.1	Application Settings .....	93
	Application Port .....	93
	Enable Application .....	93
4.3.7.2	Application Authentication .....	93
	Authentication ID .....	93
	Authentication Password .....	94
4.4	System .....	94
4.4.1	Web Language .....	94
4.4.1.1	Web Language .....	94
	Language .....	94
4.4.2	Administrator Password .....	95
4.4.2.1	Change Administrator Password .....	95
	Current Password .....	95
	New Password .....	95
	Confirm New Password .....	96
4.4.3	Change User Password .....	96
4.4.3.1	Change User Password .....	96
	Current Password .....	96
	New Password .....	97

## Table of Contents

---

	Confirm New Password .....	97
4.4.4	Web Server Settings .....	97
4.4.4.1	Web Server Settings .....	98
	Web Server Port .....	98
	Port Close Timer .....	98
4.4.5	Time Adjust Settings .....	99
4.4.5.1	Synchronization .....	99
	Enable Synchronization by NTP .....	99
	Synchronization Interval .....	99
4.4.5.2	Time Server .....	100
	NTP Server Address .....	100
4.4.5.3	Time Zone .....	100
	Time Zone .....	100
4.4.5.4	Daylight Saving Time (Summer Time) .....	100
	Enable DST (Enable Summer Time) .....	100
	DST Offset (Summer Time Offset) .....	100
4.4.5.5	Start Day and Time of DST (Start Day and Time of Summer Time) .....	101
	Month .....	101
	Day of Week .....	101
	Time .....	102
4.4.5.6	End Day and Time of DST (End Day and Time of Summer Time) .....	102
	Month .....	102
	Day of Week .....	102
	Time .....	103
4.5	VoIP .....	103
4.5.1	SIP Settings .....	103
4.5.1.1	SIP Setting .....	104
	SIP User Agent .....	104
4.5.2	SIP Settings [Line 1]–[Line x] .....	104
4.5.2.1	Phone Number .....	105
	Phone Number .....	105
	SIP URI .....	106
4.5.2.2	SIP Server .....	106
	Registrar Server Address .....	106
	Registrar Server Port .....	106
	Proxy Server Address .....	106
	Proxy Server Port .....	107
	Presence Server Address .....	107
	Presence Server Port .....	107
4.5.2.3	Outbound Proxy Server .....	107
	Outbound Proxy Server Address .....	107
	Outbound Proxy Server Port .....	107
4.5.2.4	SIP Service Domain .....	108
	Service Domain .....	108
4.5.2.5	SIP Source Port .....	108
	Source Port .....	108
4.5.2.6	SIP Authentication .....	108
	Authentication ID .....	108
	Authentication Password .....	109
4.5.2.7	DNS .....	109
	Enable DNS SRV lookup .....	109
	SRV lookup Prefix for UDP .....	109
	SRV lookup Prefix for TCP .....	110
4.5.2.8	Transport Protocol of SIP .....	110
	Transport Protocol .....	110

4.5.2.9	Timer Settings .....	110
	T1 Timer .....	110
	T2 Timer .....	110
	Timer B .....	111
	Timer D .....	111
	Timer F .....	111
	Timer H .....	111
	Timer J .....	112
4.5.2.10	Quality of Service (QoS) .....	112
	SIP Packet QoS (DSCP) .....	112
4.5.2.11	SIP extensions .....	112
	Supports 100rel (RFC 3262) .....	112
	Supports Session Timer (RFC 4028) .....	112
4.5.2.12	NAT Identity .....	113
	Keep Alive Interval .....	113
	Supports Rport (RFC 3581) .....	113
4.5.2.13	Security .....	113
	Enable SSAF (SIP Source Address Filter) .....	113
4.5.3	VoIP Settings .....	114
4.5.3.1	RTP Settings .....	114
	RTP Packet Time .....	114
	Minimum RTP Port Number .....	114
	Maximum RTP Port Number .....	115
	Telephone-event Payload Type .....	115
4.5.4	VoIP Settings [Line 1]–[Line x] .....	116
4.5.4.1	Quality of Service (QoS) .....	116
	RTP Packet QoS (DSCP) .....	116
	RTCP Packet QoS (DSCP) .....	116
4.5.4.2	Statistical Information .....	117
	RTCP Enable .....	117
	RTCP Interval .....	117
4.5.4.3	Jitter Buffer .....	117
	Maximum Delay .....	117
	Minimum Delay .....	117
	Initial Delay .....	118
4.5.4.4	DTMF .....	118
	DTMF Type .....	118
	DTMF Relay .....	118
4.5.4.5	Call Hold .....	119
	Supports RFC 2543 (c=0.0.0.0) .....	119
4.5.4.6	CODEC Preferences .....	119
	G722 (Enable) .....	119
	G722 (Priority) .....	119
	PCMA (Enable) .....	120
	PCMA (Priority) .....	120
	G726–32 (Enable) .....	120
	G726–32 (Priority) .....	120
	G729A (Enable) .....	120
	G729A (Priority) .....	121
	PCMU (Enable) .....	121
	PCMU (Priority) .....	121
4.6	Telephone .....	121
4.6.1	Call Control .....	122
4.6.1.1	Call Control .....	122
	Send SUBSCRIBE to Voice Mail Server .....	122

## Table of Contents

---

Conference Server URI .....	123
Inter-digit Timeout .....	123
Timer for Dial Plan .....	123
International Call Prefix .....	123
Country Calling Code .....	124
National Access Code .....	124
Default Line for Outgoing .....	124
Flash/Recall Button .....	124
Flash Hook Event .....	125
Direct Call Pickup .....	125
4.6.1.2    Call Rejection Phone Numbers .....	125
1–30 .....	125
4.6.2    Call Control [Line 1]–[Line x] .....	125
4.6.2.1    Call Control .....	126
Display Name .....	126
Voice Mail Access Number .....	126
Enable Shared Call .....	127
Synchronize Do Not Disturb and Call Forward .....	127
Resource List URI .....	128
4.6.2.2    Dial Plan .....	128
Dial Plan (max 1000 columns) .....	128
Call Even If Dial Plan Does Not Match .....	128
4.6.2.3    Call Features .....	129
Block Caller ID .....	129
Block Anonymous Call .....	129
Do Not Disturb .....	130
4.6.2.4    Call Forward .....	130
Unconditional (Enable Call Forward) .....	130
Unconditional (Phone Number) .....	131
Busy (Enable Call Forward) .....	131
Busy (Phone Number) .....	132
No Answer (Enable Call Forward) .....	132
No Answer (Phone Number) .....	133
No Answer (Ring Count) .....	133
4.6.3    Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only) .....	134
4.6.3.1    Flexible Button Settings .....	134
Type (No. 1–24) .....	134
Parameter (No. 1–24) .....	134
Label Name (No. 1–24) .....	135
4.6.4    Tone Settings .....	135
4.6.4.1    Dial Tone .....	135
Tone Frequencies .....	135
Tone Timings .....	136
4.6.4.2    Busy Tone .....	136
Tone Frequencies .....	136
Tone Timings .....	137
4.6.4.3    Ringing Tone .....	137
Tone Frequencies .....	137
Tone Timings .....	137
4.6.4.4    Stutter Tone .....	138
Tone Frequencies .....	138
Tone Timings .....	138
4.6.4.5    Reorder Tone .....	138
Tone Frequencies .....	138
Tone Timings .....	139

4.6.5	Telephone Settings .....	139
4.6.5.1	Telephone Settings .....	139
	Key Click Tone .....	139
	Extension PIN .....	140
	Number Matching Lower Digit .....	140
	Number Matching Upper Digit .....	140
4.6.6	Import Phonebook .....	140
4.6.6.1	Import Phonebook .....	141
	File Name .....	141
4.6.7	Export Phonebook .....	141
4.6.8	Application Settings .....	142
4.6.8.1	Application Bootup URL .....	142
	URL .....	142
4.6.8.2	Application initial URL .....	143
	URL .....	143
4.6.8.3	Incoming call URL .....	143
	URL .....	143
4.6.8.4	Talking URL .....	143
	URL .....	143
4.6.8.5	Making call URL .....	143
	URL .....	143
4.6.8.6	Call log URL .....	144
	URL .....	144
4.6.8.7	Idling URL .....	144
	URL .....	144
4.6.8.8	Network Phone Book URL .....	144
	URL .....	144
4.6.8.9	Network Phone Book URL Authentication .....	144
	Authentication ID .....	144
	Authentication Password .....	145
<b>4.7</b>	<b>Maintenance .....</b>	<b>145</b>
4.7.1	Firmware Maintenance .....	145
4.7.1.1	Firmware Maintenance .....	145
	Enable Firmware Update .....	145
	Update Type .....	146
	Firmware File URL .....	146
4.7.2	Local Firmware Update .....	146
4.7.2.1	Local Firmware Update .....	147
	Encryption .....	147
	File Name .....	147
4.7.3	Provisioning Maintenance .....	147
4.7.3.1	Provisioning Maintenance .....	148
	Enable Provisioning .....	148
	Standard File URL .....	148
	Product File URL .....	149
	Master File URL .....	149
	Cyclic Auto Resync .....	149
	Resync Interval .....	150
	Header Value for Resync Event .....	150
4.7.4	Management Server .....	150
4.7.4.1	Management Server .....	151
	Management Server URL .....	151
4.7.4.2	Management Server Authentication .....	151
	Authentication ID .....	151
	Authentication Password .....	151

## Table of Contents

---

4.7.5	Reset to Defaults .....	151
4.7.6	Restart .....	152
<b>5</b>	<b>Configuration File Programming .....</b>	<b>153</b>
<b>5.1</b>	<b>Configuration File Parameter List .....</b>	<b>154</b>
<b>5.2</b>	<b>General Information on the Configuration Files .....</b>	<b>165</b>
5.2.1	Configuration File Parameters .....	165
5.2.2	Characters Available for String Values .....	166
<b>5.3</b>	<b>System Settings .....</b>	<b>167</b>
5.3.1	Login Account Settings .....	167
	ADMIN_ID .....	167
	ADMIN_PASS .....	167
	USER_ID .....	168
	USER_PASS .....	168
5.3.2	System Time Settings .....	168
	TIME_ZONE .....	168
	DST_ENABLE .....	169
	DST_OFFSET .....	169
	DST_START_MONTH .....	170
	DST_START_ORDINAL_DAY .....	170
	DST_START_DAY_OF_WEEK .....	170
	DST_START_TIME .....	171
	DST_STOP_MONTH .....	171
	DST_STOP_ORDINAL_DAY .....	172
	DST_STOP_DAY_OF_WEEK .....	172
	DST_STOP_TIME .....	172
	LOCAL_TIME_ZONE_POSIX .....	173
5.3.3	Syslog Settings .....	173
	SYSLOG_EVENT_SIP .....	173
	SYSLOG_EVENT_CFG .....	174
	SYSLOG_EVENT_VOIP .....	174
	SYSLOG_EVENT_TEL .....	174
	SYSLOG_ADDR .....	174
	SYSLOG_PORT .....	175
	SYSLOG_RTPSMLY_INTVL_n .....	175
5.3.4	Firmware Update Settings .....	175
	FIRM_UPGRADE_ENABLE .....	175
	FIRM_VERSION .....	176
	FIRM_UPGRADE_AUTO .....	176
	FIRM_FILE_PATH .....	176
5.3.5	Provisioning Settings .....	177
	OPTION66_ENABLE .....	177
	OPTION66_REBOOT .....	177
	PROVISION_ENABLE .....	178
	CFG_STANDARD_FILE_PATH .....	178
	CFG_PRODUCT_FILE_PATH .....	179
	CFG_MASTER_FILE_PATH .....	180
	CFG_FILE_KEY1 .....	181
	CFG_FILE_KEY2 .....	182
	CFG_FILE_KEY3 .....	182
	CFG_FILE_KEY_LENGTH .....	182
	CFG_CYCLIC .....	182
	CFG_CYCLIC_INTVL .....	183
	CFG_RTRY_INTVL .....	183
	CFG_RESYNC_TIME .....	183

	CFG_RESET_DURATIONS .....	184
	CFG_RESET_FROM_SIP .....	184
5.3.6	Management Server Settings .....	184
	ACS_URL .....	184
	ACS_USER_ID .....	184
	ACS_PASS .....	185
	PERIODIC_INFORM_ENABLE .....	185
	PERIODIC_INFORM_INTERVAL .....	185
	PERIODIC_INFORM_TIME .....	185
	CON_REQ_USER_ID .....	186
	CON_REQ_PASS .....	186
	ANNEX_G_STUN_ENABLE .....	187
	ANNEX_G_STUN_SERV_ADDR .....	187
	ANNEX_G_STUN_SERV_PORT .....	187
	ANNEX_G_STUN_USER_ID .....	187
	ANNEX_G_STUN_PASS .....	188
	ANNEX_G_STUN_MAX_KEEP_ALIVE .....	188
	ANNEX_G_STUN_MIN_KEEP_ALIVE .....	188
	UDP_CON_REQ_ADDR_NOTIFY_LIMIT .....	189
5.4	<b>Network Settings .....</b>	<b>189</b>
5.4.1	IP Settings .....	189
	CONNECTION_TYPE .....	189
	HOST_NAME .....	190
	DHCP_DNS_ENABLE .....	190
	STATIC_IP_ADDRESS .....	190
	STATIC_SUBNET .....	191
	STATIC_GATEWAY .....	191
	USER_DNS1_ADDR .....	192
	USER_DNS2_ADDR .....	192
5.4.2	DNS Settings .....	192
	DNS_QRY_PRLL .....	192
	DNS_PRIORITY .....	193
	DNS1_ADDR .....	193
	DNS2_ADDR .....	193
5.4.3	Ethernet Port Settings .....	194
	VLAN_ENABLE .....	194
	VLAN_ID_IP_PHONE .....	194
	VLAN_PRI_IP_PHONE .....	194
	VLAN_ID_PC .....	195
	VLAN_PRI_PC .....	195
5.4.4	IEEE 802.1X Settings (KX-UT248 only) .....	195
	IEEE8021X_ENABLE .....	195
	IEEE8021X_AUTH_PRTCL .....	196
	IEEE8021X_USER_ID .....	196
	IEEE8021X_USER_PASS .....	196
5.4.5	HTTP Settings .....	197
	HTTPD_PORTOPEN_AUTO .....	197
	HTTP_VER .....	197
	HTTP_USER_AGENT .....	197
	HTTP_SSL_VERIFY .....	198
	CFG_ROOT_CERTIFICATE_PATH .....	198
5.4.6	Time Adjust Settings .....	199
	NTP_ADDR .....	199
	TIME_SYNC_INTVL .....	199
	TIME_QUERY_INTVL .....	199

## Table of Contents

---

5.4.7	STUN Settings .....	200
	STUN_SERV_ADDR .....	200
	STUN_SERV_PORT .....	200
	STUN_2NDSERV_ADDR .....	200
	STUN_2NDSERV_PORT .....	200
5.4.8	Miscellaneous Network Settings .....	201
	NW_SETTING_ENABLE .....	201
	CUSTOM_WEB_PAGE .....	201
5.4.9	LLDP-MED Settings .....	201
	LLDP_ENABLE .....	201
	LLDP_INTERVAL .....	202
	LLDP_VLAN_ID_PC .....	202
	LLDP_VLAN_PRI_PC .....	202
<b>5.5</b>	<b>Telephone Settings .....</b>	<b>202</b>
5.5.1	Call Control Settings .....	202
	VM_SUBSCRIBE_ENABLE .....	202
	CONFERENCE_SERVER_URI .....	203
	FIRSTDIGIT_TIM .....	203
	INTDIGIT_TIM .....	203
	MACRODIGIT_TIM .....	203
	INTERNATIONAL_ACCESS_CODE .....	204
	COUNTRY_CALLING_CODE .....	204
	NATIONAL_ACCESS_CODE .....	204
	DEFAULT_LINE_SELECT .....	204
	DATA_LINE_MODE .....	205
	NUM_PLAN_PICKUP_DIRECT .....	205
	TALK_PACKAGE .....	205
	HOLD_PACKAGE .....	206
	HOLD_RECALL_TIM .....	206
	AUTO_ANS_RING_TIM .....	206
	RINGING_OFF_SETTING_ENABLE .....	206
	AUTO_CALL_HOLD .....	207
	REDIALKEY_CALLOG_ENABLE .....	207
	ONHOOK_TRANSFER_ENABLE .....	207
	DISCONNECTION_MODE .....	207
	TONE_LEN_DISCONNECT_HANDSET .....	207
	TONE_LEN_DISCONNECT_HANDSFREE .....	208
	KEY_PAD_TONE .....	208
	HOLD_AND_CALL_ENABLE .....	208
	HOLD_TRANSFER_OPERATION .....	208
5.5.2	Tone Settings .....	209
	DIAL_TONE1_FRQ .....	209
	DIAL_TONE1_GAIN .....	209
	DIAL_TONE1_RPT .....	209
	DIAL_TONE1_TIMING .....	209
	DIAL_TONE2_FRQ .....	210
	DIAL_TONE2_GAIN .....	210
	DIAL_TONE2_RPT .....	210
	DIAL_TONE2_TIMING .....	210
	DIAL_TONE4_FRQ .....	211
	DIAL_TONE4_GAIN .....	211
	DIAL_TONE4_RPT .....	211
	DIAL_TONE4_TIMING .....	211
	BUSY_TONE_FRQ .....	212
	BUSY_TONE_GAIN .....	212

BUSY_TONE_RPT .....	212
BUSY_TONE_TIMING .....	212
REORDER_TONE_FRQ .....	213
REORDER_TONE_GAIN .....	213
REORDER_TONE_RPT .....	213
REORDER_TONE_TIMING .....	213
RINGBACK_TONE_FRQ .....	214
RINGBACK_TONE_GAIN .....	214
RINGBACK_TONE_RPT .....	214
RINGBACK_TONE_TIMING .....	214
HOLD_ALARM_FRQ .....	215
HOLD_ALARM_GAIN .....	215
HOLD_ALARM_RPT .....	215
HOLD_ALARM_TIMING .....	215
CW_TONE1_FRQ .....	216
CW_TONE1_GAIN .....	216
CW_TONE1_RPT .....	216
CW_TONE1_TIMING .....	216
HOLD_TONE_FRQ .....	217
HOLD_TONE_GAIN .....	217
HOLD_TONE_RPT .....	217
HOLD_TONE_TIMING .....	217
BELL_CORE_PATTERN1_TIMING .....	218
BELL_CORE_PATTERN2_TIMING .....	218
BELL_CORE_PATTERN3_TIMING .....	218
BELL_CORE_PATTERN4_TIMING .....	219
BELL_CORE_PATTERN5_TIMING .....	219
5.5.3 Telephone Settings .....	219
DISPLAY_NAME_REPLACE .....	219
NUMBER_MATCHING_LOWER_DIGIT .....	219
NUMBER_MATCHING_UPPER_DIGIT .....	220
DISPLAY_DATE_PATTERN .....	220
DISPLAY_TIME_PATTERN .....	220
DEFAULT_LANGUAGE .....	220
EXTENSION_PIN .....	221
POUND_KEY_DELIMITER_ENABLE .....	221
5.5.4 Miscellaneous Telephone Settings .....	222
ADJDATA_GAIN .....	222
ADJDATA_ATT (KX-UT113/KX-UT123/KX-UT133/KX-UT136 only) .....	223
5.5.5 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only) .....	224
FLEX_BUTTON_FACILITY_ACTx .....	224
FLEX_BUTTON_FACILITY_ARGx .....	224
FLEX_BUTTON_QUICK_DIALx .....	224
FLEX_BUTTON_LABELx .....	225
5.5.6 XML Application Settings .....	225
XMLAPP_ENABLE .....	225
XMLAPP_USERID .....	225
XMLAPP_USERPASS .....	226
XMLAPP_START_URL .....	226
XMLAPP_INITIAL_URL .....	226
XMLAPP_INCOMING_URL .....	226
XMLAPP_TALKING_URL .....	227
XMLAPP_MAKECALL_URL .....	227
XMLAPP_CALLLOG_URL .....	227
XMLAPP_IDLING_URL .....	227

## Table of Contents

---

XMLAPP_LDAP_URL .....	228
XMLAPP_LDAP_USERID .....	228
XMLAPP_LDAP_USERPASS .....	228
XML_INITIATE_KEY_SOFT1 .....	228
XML_INITIATE_KEY_SOFT2 .....	229
XML_INITIATE_KEY_SOFT3 .....	229
XML_INITIATE_KEY_SOFT4 .....	229
XML_INITIATE_KEY_FWDDND .....	229
XML_INITIATE_KEY_FLASH .....	229
XML_ERROR_INFORMATION .....	230
XML_HTTPD_PORT .....	230
<b>5.6 VoIP Settings .....</b>	<b>230</b>
5.6.1 Codec Settings .....	230
CODEC_G711_REQ .....	230
CODEC_G729_PARAM .....	231
CODEC_ENABLEEx_n .....	231
CODEC_PRIORITYYx_n .....	231
5.6.2 RTP Settings .....	232
DSCP_RTP_n .....	232
DSCP_RTCP_n .....	232
RTCP_INTVL_n .....	233
MAX_DELAY_n .....	233
MIN_DELAY_n .....	233
NOM_DELAY_n .....	234
RTP_PORT_MIN .....	234
RTP_PORT_MAX .....	234
RTP_PTIME .....	235
RTCP_ENABLE_n .....	235
RTCP_SEND_BY_SDP_n .....	236
RTP_CLOSE_ENABLE_n .....	236
5.6.3 Miscellaneous VoIP Settings .....	236
OUTBANDDTMF_n .....	236
DTMF_RELAY_n .....	237
OUTBANDDTMF_VOL .....	237
INBANDDTMF_VOL .....	237
TELEVNT_PAYLOAD .....	237
RFC2543_HOLD_ENABLE_n .....	238
DTMF_SIGNAL_LEN .....	238
DTMF_INTDIGIT_TIM .....	238
<b>5.7 Line Settings .....</b>	<b>239</b>
5.7.1 Call Control Settings .....	239
DISPLAY_NAME_n .....	239
VM_NUMBER_n .....	239
DIAL_PLAN_n .....	239
DIAL_PLAN_NOT_MATCH_ENABLE_n .....	240
SHARED_CALL_ENABLE_n .....	240
FWD_DND_SYNCHRO_ENABLE_n .....	241
RESOURCELIST_URI_n .....	241
CW_ENABLE_n .....	242
RETURN_VOL_SET_DEFAULT_ENABLE .....	242
FLASH_RECALL_TERMINATE .....	242
FLASHHOOK_CONTENT_TYPE .....	242
VOICE_MESSAGE_AVAILABLE .....	243
HOLD_SOUND_PATH_n .....	243
5.7.2 SIP Settings .....	243

SIP_USER_AGENT .....	243
PHONE_NUMBER_n .....	244
SIP_URI_n .....	244
LINE_ENABLE_n .....	245
PROFILE_ENABLEn .....	245
SIP_AUTHID_n .....	245
SIP_PASS_n .....	246
SIP_SRC_PORT_n .....	246
SIP_PRXY_ADDR_n .....	246
SIP_PRXY_PORT_n .....	246
SIP_RGSTR_ADDR_n .....	247
SIP_RGSTR_PORT_n .....	247
SIP_SVCDOMAIN_n .....	247
REG_EXPIRE_TIME_n .....	248
REG_INTERVAL_RATE_n .....	248
SIP_SESSION_TIME_n .....	248
SIP_SESSION_METHOD_n .....	248
DSCP_SIP_n .....	249
SIP_2NDPROXY_ADDR_n .....	249
SIP_2NDPROXY_PORT_n .....	249
SIP_2NDRGSTR_ADDR_n .....	250
SIP_2NDRGSTR_PORT_n .....	250
SIP_TIMER_T1_n .....	250
SIP_TIMER_T2_n .....	250
SIP_TIMER_T4_n .....	251
SIP_FOVR_NORSP_n .....	251
SIP_FOVR_MAX_n .....	252
SIP_REFRESHER_n .....	252
SIP_DNSSRV_ENA_n .....	252
SIP_UDP_SRV_PREFIX_n .....	253
SIP_TCP_SRV_PREFIX_n .....	253
SIP_100REL_ENABLE_n .....	253
SIP_INVITE_EXPIRE_n .....	254
SIP_18X_RTX_INTVL_n .....	254
SIP_PRSNC_ADDR_n .....	254
SIP_PRSNC_PORT_n .....	255
SIP_2NDPRSNC_ADDR_n .....	255
SIP_2NDPRSNC_PORT_n .....	255
USE_DEL_REG_OPEN_n .....	255
USE_DEL_REG_CLOSE_n .....	256
PORT_PUNCH_INTVL_n .....	256
SIP_ADD_RPORT_n .....	256
SIP_REQURI_PORT_n .....	257
SIP_SUBS_EXPIRE_n .....	257
SUB_RTX_INTVL_n .....	257
REG_RTX_INTVL_n .....	258
SIP_P_PREFERRED_ID_n .....	258
SIP_PRIVACY_n .....	258
ADD_USER_PHONE_n .....	259
SDP_USER_ID_n .....	259
SUB_INTERVAL_RATE_n .....	259
SIP_OUTPROXY_ADDR_n .....	259
SIP_OUTPROXY_PORT_n .....	260
SIP_TRANSPORT_n .....	260
SIP_ANM_DISPNAME_n .....	260

## Table of Contents

---

SIP_ANM_USERNAME_n .....	261
SIP_ANM_HOSTNAME_n .....	261
SIP_DETECT_SSAF_n .....	261
SIP_RCV_DET_HEADER_n .....	262
SIP_CONTACT_ON_ACK_n .....	262
SIP_TIMER_B_n .....	262
SIP_TIMER_D_n .....	262
SIP_TIMER_F_n .....	263
SIP_TIMER_H_n .....	263
SIP_TIMER_J_n .....	263
ADD_TRANSPORT_UDP_n .....	264
ADD_EXPIRES_HEADER_n .....	264
SIP_HOLD_HOLDRECEIVE_n .....	264
SIP_ADD_DIVERSION_n .....	264
SIP_RESPONSE_CODE_DND .....	265
SIP_RESPONSE_CODE_CALL_REJECT .....	265
SIP_FOVR_MODE_n .....	265
SIP_FOVR_DURATION_n .....	265
SIP_ADD_ROUTE_n .....	266
SIP_403_REG_SUB_RTX_n .....	266
<b>6 Useful Telephone Functions .....</b>	<b>267</b>
<b>6.1 Phonebook Import and Export .....</b>	<b>268</b>
6.1.1 Import/Export Operation .....	270
6.1.2 Editing with Microsoft Excel .....	271
6.1.3 Exporting Data from Microsoft Outlook .....	273
<b>6.2 Dial Plan .....</b>	<b>274</b>
6.2.1 Dial Plan Settings .....	275
<b>6.3 Flexible Buttons (KX-UT133/KX-UT136/KX-UT248 only) .....</b>	<b>278</b>
6.3.1 Flexible Button Settings .....	279
<b>7 Firmware Update .....</b>	<b>283</b>
<b>7.1 Firmware Server Setup .....</b>	<b>284</b>
<b>7.2 Firmware Update Settings .....</b>	<b>284</b>
<b>7.3 Executing Firmware Update .....</b>	<b>284</b>
<b>7.4 Local Firmware Update .....</b>	<b>285</b>
<b>8 Troubleshooting .....</b>	<b>287</b>
<b>8.1 Troubleshooting .....</b>	<b>288</b>
<b>9 Appendix .....</b>	<b>293</b>
<b>9.1 Revision History .....</b>	<b>294</b>
9.1.1 KX-UT113/KX-UT123/KX-UT133/KX-UT136 Software File Version 01.025 .....	294
9.1.2 KX-UT113/KX-UT123/KX-UT133/KX-UT136 Software File Version 01.080 .....	295
9.1.3 KX-UT113/KX-UT123/KX-UT133/KX-UT136/KX-UT248 Software File Version 01.160 .....	296
<b>Index.....</b>	<b>297</b>

---

# **Section 1**

## ***Initial Setup***

*This section provides an overview of the setup procedures for the unit.*

## 1.1 Setup

---

### 1.1.1 Factory Defaults

Many of the settings for this unit have been configured before the unit ships.

Where possible, these settings are configured with the optimum or most common values for the setting. For example, the port number of the SIP (Session Initiation Protocol) server is set to "5060".

However, many of the settings, such as the address of the SIP server or the phone number, have not been pre-configured, and they must be modified depending on the usage environment. If the port number of the SIP server is not "5060", the value of this setting must be changed.

This unit thus will not function properly using only the factory default settings. The settings for each feature must be configured according to the environment in which the unit is used.

### 1.1.2 Language Selection for the Unit

You can change the language used on the LCD.

In addition, various settings can be configured by accessing the Web user interface from a PC on the same network (→ see **Section 4 Web User Interface Programming**). You can select the language for the Web user interface.

**Note**

- To select the display language for the unit, refer to the Operating Instructions on the Panasonic Web site (→ see **Introduction**).
- To select the display language for the Web user interface, see **4.4.1 Web Language**.

### 1.1.3 Basic Network Setup

This section describes the basic network settings that you must configure before you can use the unit on your network.

You must configure the following network settings:

- TCP/IP settings (DHCP [Dynamic Host Configuration Protocol] or static IP address assignment)
- DNS server settings

### TCP/IP Settings (DHCP or Static IP Address Assignment)

---

A unique IP address must be assigned to the unit so that it can communicate on the network. How you assign an IP address depends on your network environment. This unit supports the following 2 methods for assigning an IP address:

#### Obtaining an IP Address Automatically from a DHCP Server

You can configure the unit to automatically obtain its IP address when it starts up from a DHCP server running on your network. With this method, the system can efficiently manage a limited number of IP addresses. Note that the IP address assigned to the unit may vary every time the unit is started up.

For details about the DHCP server, consult your network administrator.

#### Using a Static IP Address Specified by Your Network Administrator

If IP addresses for network devices are specified individually by your network administrator, you will need to manually configure settings such as the IP address, subnet mask, default gateway, and DNS servers.

For details about the required network settings, consult your network administrator.

## DNS Server Settings

You can configure the unit to use 2 DNS servers: a primary DNS server and a secondary DNS server. If you set both DNS servers, the primary DNS server receives priority over the secondary DNS server. If the primary DNS server returns no reply, the secondary DNS server will be used.

For details about configuring the DNS server settings using the unit, or using the Web user interface, see **Configuring the Network Settings of the Unit** in this section.

### DNS Priority Using Configuration File

The setting for DNS server(s) may be configured using the configuration files by your phone system dealer (→ see "DNS1\_ADDR" and "DNS2\_ADDR" in **5.4.2 DNS Settings**).

- If the DNS server addresses specified in the configuration file (→ see "DNS\_PRIORITY" in **5.4.2 DNS Settings**) are given priority, the unit first sends its requests to those DNS servers. If a match is not found, the unit then sends its request to the DNS servers that were specified by the DHCP server, or the primary/secondary DNS servers that were specified on the unit or via the Web user interface.
- If the DNS servers that were specified by the DHCP server, or the primary/secondary DNS servers that were specified on the unit or via the Web user interface are given priority, the unit first sends its requests to those DNS servers. If a match is not found, the unit then sends its request to the DNS servers that were specified using the configuration file.

## Configuring the Network Settings of the Unit

The following procedures explain how to change the network settings via the unit.

For details about the individual network settings that can be configured via the unit, refer to the Operating Instructions on the Panasonic Web site (→ see **Introduction**).

For details about configuring network settings via the Web user interface, see **4.3.1 Basic Network Settings**.

### To configure network settings automatically

1. Press **Setting** or **Setup**.
2. Press **[A]** or **[V]** to select "Network Settings", and then press **[ENTER]**.
3. Press **[A]** or **[V]** to select "Network", and then press **[ENTER]**.
4. Press **[A]** or **[V]** to select "DHCP", and then press **[ENTER]**.
5. Press **[A]** or **[V]** to select "Automatic" for DNS, and then press **[ENTER]**.
  - Select "Manual" to enter the addresses for DNS1 (primary DNS server) and, if necessary, DNS2 (secondary DNS server) manually, and then press **[ENTER]**.
6. Press **[CANCEL]**.

### To configure network settings manually

1. Press **Setting** or **Setup**.
2. Press **[A]** or **[V]** to select "Network Settings", and then press **[ENTER]**.
3. Press **[A]** or **[V]** to select "Network", and then press **[ENTER]**.
4. Press **[A]** or **[V]** to select "STATIC", and then press **[ENTER]**.
5. Enter the IP address, subnet mask, default gateway, DNS1 (primary DNS server), and, if necessary, DNS2 (secondary DNS server), and then press **[ENTER]**.
6. Press **[CANCEL]**.

### Note

- If your phone system dealer does not allow you these settings, you cannot change them even though the unit shows the setting menu. Contact your phone system dealer for further information.

## 1.1.5 Phone User Interface Programming

---

- If you select "DHCP" for the connection mode, all the settings concerning static connection will be ignored, even if they have been specified.
- If you select "DHCP" for the connection mode and "Automatic" for DNS, the DNS server settings (DNS1 and DNS2) will be ignored, even if they have been specified.

## 1.1.4 Overview of Programming

There are 3 types of programming, as shown in the table below:

Programming Type	Description	References
Phone user interface programming	Configuring the unit's settings directly from the unit.	→ 1.1.5 Phone User Interface Programming → Section 3 Phone User Interface Programming
Web user interface programming	Configuring the unit's settings by accessing the Web user interface from a PC connected to the same network.	→ 1.1.6 Web User Interface Programming → Section 4 Web User Interface Programming
Configuration file programming	Configuring the unit's settings beforehand by creating configuration files (pre-provisioning), and having the unit download the files from a server on the Internet and configure its own settings (provisioning).	→ Section 2 General Information on Provisioning → Section 5 Configuration File Programming

## 1.1.5 Phone User Interface Programming

You can change the settings directly from the unit.

For details about the operations, refer to the Operating Instructions on the Panasonic Web site (→ see **Introduction**).

For details about additional features available with direct commands, see **Section 3 Phone User Interface Programming**.


### 1.1.5.1 Changing the Language for Phone User Interface Programming

You can change the language used on the LCD. Because the language settings for the LCD of the unit are not synchronized, you must set the languages individually for the unit.

For details about changing the setting, refer to the Operating Instructions on the Panasonic Web site (→ see **Introduction**).

## 1.1.6 Web User Interface Programming

After connecting the unit to your network, you can configure the unit's settings by accessing the Web user interface from a PC connected to the same network. For details, see **Section 4 Web User Interface Programming**.



### 1.1.6.1 Password for Web User Interface Programming

To program the unit via the Web user interface, a login account is required. There are 2 types of accounts, and each has different access privileges.

- **User:** User accounts are for use by end users. Users can change the settings that are specific to the unit.
- **Administrator:** Administrator accounts are for use by administrators to manage the system configuration. Administrators can change all the settings, including the network settings, in addition to the settings that can be changed from a User account.

A separate password is assigned to each account.

For details, see **Access Levels (IDs and Passwords)** in **1.1.6.3 Before Accessing the Web User Interface**.

#### Notice

- You should manage the passwords carefully, and change them regularly.

### 1.1.6.2 Changing the Language for Web User Interface Programming

When accessing the unit via the Web user interface on a PC connected to the same network, various menus and settings are displayed. You can change the language used for displaying these setting items. Because the language setting for the Web user interface is not synchronized with those of the unit, you must set the languages for each independently.

For details, see **4.4.1 Web Language**.

### 1.1.6.3 Before Accessing the Web User Interface

#### Recommended Environment

This unit supports the following specifications:

<b>HTTP Version</b>	HTTP/1.0 (RFC 1945), HTTP/1.1 (RFC 2616)
<b>Authentication Method</b>	Digest (or Basic)

The Web user interface will operate correctly in the following environments:

<b>Operating System</b>	Microsoft® Windows® XP or Windows 7 operating system
<b>Web Browser</b>	Windows Internet Explorer® 7 or Windows Internet Explorer 8 web browser
<b>Language (recommended)</b>	English

#### Opening/Closing the Web Port

To access the Web user interface, you must open the unit's Web port beforehand. For details, refer to the Operating Instructions on the Panasonic Web site (→ see **Introduction**).

For details about additional features available with direct commands, see **Section 3 Phone User Interface Programming**.

##### Configuring Settings from the Unit

###### To open the unit's Web port

1. Press **Setting** or **Setup**.
2. Press **[#][5][3][4]**.
3. Press **[▲]** or **[▼]** to select "On" for "Embedded web", and then press **[ENTER]**.

###### To close the unit's Web port

1. Press **Setting** or **Setup**.
2. Press **[#][5][3][4]**.
3. Press **[▲]** or **[▼]** to select "Off" for "Embedded web", and then press **[ENTER]**.

##### Configuring Settings from the Web User Interface

###### To close the unit's Web port

1. In the Web user interface, click **[Web Port Close]**.
2. Click **OK**.

###### Note

- The Web port of the unit will be closed automatically in the following conditions:
  - The port close timer configured through the Web user interface expires (→ see **[Port Close Timer]** in **4.4.4.1 Web Server Settings**).
  - 3 consecutive unsuccessful login attempts occur.
- The Web port can be set to stay open continuously, through Configuration file programming (→ see "**HTTPD\_PORTOPEN\_AUTO**" in **5.4.5 HTTP Settings**). However, please recognize the possibility of unauthorized access to the unit by doing so.

## Access Levels (IDs and Passwords)

2 accounts with different access privileges are provided for accessing the Web user interface: User and Administrator. Each account has its own ID and password, which are required to log in to the Web user interface.

Account	Target User	ID (default)	Password (default)	Password Restrictions
User	End users	user	-blank-(NULL)	<ul style="list-style-type: none"> <li>When logged in as User, you can change the password for the User account (→ see <b>4.4.3 Change User Password</b>).</li> <li>The password can consist of 6 to 16 ASCII characters (case-sensitive) (→ see <b>Entering Characters</b> in <b>1.1.6.4 Accessing the Web User Interface</b>).</li> </ul>
Administrator	Network administrators, etc.	admin	adminpass	<ul style="list-style-type: none"> <li>When logged in as Administrator, you can change the password for both the User and Administrator accounts (→ see <b>4.4.2 Administrator Password</b>).</li> <li>The password can consist of 6 to 16 ASCII characters (case-sensitive) (→ see <b>Entering Characters</b> in <b>1.1.6.4 Accessing the Web User Interface</b>).</li> </ul>

### Notice

- Only one account can be logged in to the Web user interface at a time. If you try to access the Web user interface while someone is logged in, you will be denied access.
- You cannot log in to the Web user interface even under the same account as someone who is already logged in.
- The user password is required to change the settings.
- The IDs can be changed through configuration file programming (→ see "**ADMIN\_ID**" and "**USER\_ID**" in **5.3.1 Login Account Settings**).
- You can reset the account IDs and passwords to their factory default settings by performing Reset Web ID/Password from the unit. For details, see **3.1.4 Reset Web ID/Password**.

## 1.1.6.4 Accessing the Web User Interface

The unit can be configured from the Web user interface.

### To access the Web user interface

- Open your Web browser, and then enter "http://" followed by the unit's IP address into the address field of your browser.

### Note


- To determine the unit's IP address, perform the following operations on the unit:

## 1.1.6 Web User Interface Programming

1. Press **Setting** or **Setup**.
  2. Press **[▲]** or **[▼]** to select "Information Display", and then press **[ENTER]**.
  3. Press **[▲]** or **[▼]** to select "IP Address".
  4. Press **[CANCEL]**.
2. For authentication, enter your ID (username) and password, and then click **OK**.
- Notice**
- The default ID for the User account is "user", and the default password is blank. The ID cannot be changed from the Web user interface, but it can be changed through configuration file programming.
  - When you log in as User to the Web user interface for the first time, the **[Change User Password]** screen (→ see **4.4.3 Change User Password**) will be displayed. Enter a new password, and then perform authentication again with the new password to log in to the Web user interface.
  - The default ID for the Administrator account is "admin", and the default password is "adminpass". The ID cannot be changed from the Web user interface, but it can be changed through configuration file programming.
3. The Web user interface window is displayed. Configure the settings for the unit as desired.
  4. You can log out from the Web user interface at any time by clicking **[Web Port Close]**.

## Controls on the Window

The Web user interface window contains various controls for navigating and configuring settings. The following figure shows the controls that are displayed on the **[Basic Network Settings]** screen as an example:



### Note

- The screen shots shown are taken from the Web user interface of the KX-UT136 (or, in some cases, KX-UT248), so the model name may differ from that shown on your PC.
- Actual default values may vary depending on your phone system dealer.
- When you log in to the Web user interface with the User account, the languages of messages displayed on the configuration screen may differ depending on the country/area of use.

## ① Tabs

Tabs are the top categories for classifying settings. When you click a tab, the corresponding menu items and the configuration screen of the first menu item appear. There are 6 tabs for the Administrator account and 4 tabs for the User account. For details about the account types, see **Access Levels (IDs and Passwords)** in this section.

## ② Menu

The menu displays the sub-categories of the selected tab.

## ③ Configuration Screen

Clicking a menu displays the corresponding configuration screen, which contains the actual settings, grouped into sections. For details, see **4.2 Status to 4.7.6 Restart**.

## ④ Buttons

The following standard buttons are displayed in the Web user interface:

Button	Function
Web Port Close	Closes the Web port of the unit and logs you out of the Web user interface after a confirmation message is displayed.
Save	Applies changes and displays a result message (→ see <b>Result Messages</b> in this section).
Cancel	Discards changes. The settings on the current screen will return to the values they had before being changed.
Refresh	Updates the status information displayed on the screen. This button is displayed in the upper-right area of the [ <b>Network Status</b> ] and [ <b>VoIP Status</b> ] screens.

## Entering Characters

In the Web user interface, when specifying a name, message, password, or other text item, you can enter any of the ASCII characters displayed in the following table with a white background.

	00	01	02	03	04	05	06	07	08	09	0A	0B	0C	0D	0E	0F
20	SP	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/
30	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
40	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
50	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	_
60	'	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
70	p	q	r	s	t	u	v	w	x	y	z	{		}	~	

However, there are additional limitations for certain types of fields as follows:

- Number field
  - You may only enter a sequence of numeric characters.
  - You cannot leave the field empty.
- IP Address field
  - You can enter the IP address using dotted-decimal notation (i.e., "n.n.n.n" where n=0–255).

- You cannot enter invalid IP addresses, for example, "0.0.0.0", "255.255.255.255", or "127.0.0.1".
- FQDN field
  - The field cannot contain ", &, ', <, >, or trailing spaces.
  - You can enter the IP address using dotted-decimal notation (i.e., "n.n.n.n" where n=0–255).
  - You cannot enter invalid IP addresses, for example, "0.0.0.0", "255.255.255.255", or "127.0.0.1".
- Authentication ID/Password field
  - The field cannot contain ", &, ', :, <, >, or space.
  - The length of user password and administrator password must be from 6 to 16 characters.
- Display Name field (→ see [Display Name] in 4.6.2.1 Call Control)
  - This is the only field in which you can enter Unicode characters.

## Result Messages

When you click [Save] after changing the settings on the current configuration screen, one of the following messages will appear in the upper-left area of the current configuration screen:

Result Message	Description	Applicable Screens
Complete	The operation has successfully completed.	All screens except <b>4.6.7 Export Phonebook</b>
Failed (Parameter Error)	The operation failed because: <ul style="list-style-type: none"> <li>• Some specified values are out of range or invalid.</li> </ul>	All screens
Failed (Memory Access Failure)	The operation failed because: <ul style="list-style-type: none"> <li>• Access error to the flash memory occurred while reading or writing the data.</li> </ul>	All screens
Failed (Transfer Failure) <sup>1</sup>	The operation failed because: <ul style="list-style-type: none"> <li>• A network error occurred during the data transmission.</li> </ul>	All screens
Failed (Busy)	The operation failed because: <ul style="list-style-type: none"> <li>• The unit is in an operation that accesses the flash memory of the unit.</li> </ul>	All screens
	<ul style="list-style-type: none"> <li>• When attempting to import/export the phonebook data, the unit is on a call.</li> <li>• While transferring the phonebook data, a call arrived at the unit.</li> </ul>	<b>4.6.6 Import Phonebook</b> <b>4.6.7 Export Phonebook</b>
	<ul style="list-style-type: none"> <li>• When updating the firmware, the unit is on a call.</li> </ul>	<b>4.7.2 Local Firmware Update</b>
Failed (Canceled)	The operation failed because: <ul style="list-style-type: none"> <li>• While transferring the phonebook data, IP Reset was performed on the unit.</li> </ul>	<b>4.6.6 Import Phonebook</b> <b>4.6.7 Export Phonebook</b>
	<ul style="list-style-type: none"> <li>• While transferring the firmware file, IP Reset was performed on the unit.</li> </ul>	<b>4.7.2 Local Firmware Update</b>
	<ul style="list-style-type: none"> <li>• While transferring the phonebook data, the connection with the unit was interrupted.</li> </ul>	<b>4.6.6 Import Phonebook</b> <b>4.6.7 Export Phonebook</b>

Result Message	Description	Applicable Screens
Failed (Invalid File)	The operation failed because: <ul style="list-style-type: none"> <li>The imported UTF-16 text file has an invalid BOM (Byte-order Mark).</li> <li>The firmware file is corrupted or invalid.</li> </ul>	<b>4.6.6 Import Phonebook</b>
		<b>4.7.2 Local Firmware Update</b>
Failed (File Size Error)	The operation failed because: <ul style="list-style-type: none"> <li>The size of the imported phonebook is too large.</li> <li>The size of the firmware file is insufficient.</li> </ul>	<b>4.6.6 Import Phonebook</b>
		<b>4.7.2 Local Firmware Update</b>
Failed (Busy)	The operation failed because: <ul style="list-style-type: none"> <li>When attempting to import/export the phonebook data, the connection with the unit has been disconnected.</li> </ul>	<b>4.6.6 Import Phonebook</b> <b>4.6.7 Export Phonebook</b>
Memory Full	The operation failed because: <ul style="list-style-type: none"> <li>When attempting to import the phonebook data, the total number of phonebook entries, including the existing entries, exceeds the limit (of up to 100 [for the KX-UT113]/500 [for the KX-UT123/KX-UT133/KX-UT136/KX-UT248] entries).</li> </ul>	<b>4.6.6 Import Phonebook</b>
No Data	The operation failed because: <ul style="list-style-type: none"> <li>The imported phonebook file contains no valid phonebook entries.</li> </ul>	<b>4.6.6 Import Phonebook</b>
	<ul style="list-style-type: none"> <li>No phonebook entry is registered in the export source the unit.</li> </ul>	<b>4.6.7 Export Phonebook</b>

\*1 "Failed (Transfer Failure)" may not be displayed depending on your Web browser.

#### Notice

- Do not click the navigation buttons of your Web browser or open a new window to display the screen. Otherwise, an error ("403 Forbidden") will occur when you click **[Save]**.


## 1.1.7 Other Network Settings

### 1.1.7.1 Firewall and Router Setup

When the unit is connected to a network that is protected by a firewall and/or router, you need to configure the firewall and/or router so that they do not block communication from the IP address and port number used by the unit.

### 1.1.7.2 NAT (Network Address Translation) Setup

This section provides information about configuring a router that uses NAT.



If the unit is connected to a network that uses a NAT router and a private IP address is assigned to each terminal on the network, depending on your phone system's setup, you might need to configure the unit and router so as to use NAT Traversal techniques.

If your phone system dealer provides an outbound proxy service that supports NAT Traversal, you need only to set the IP address of the SIP outbound proxy server to the unit—no other settings are necessary.

However, depending on the phone system of the outbound proxy service, no setting may be necessary because private IP addresses are automatically translated into global IP addresses by the outbound proxy server.

For details about the outbound proxy service, consult your phone system dealer.

When TCP is used to transport the SIP messages, you must always configure the devices for NAT Traversal.

To configure NAT Traversal, you must have the following information:

- The global IP address of the router.
- The port numbers you will specify for **[Source Port]** and **[External RTP Port]** through the Web user interface, so that you can configure the appropriate port forwarding settings.

#### Note

- Because the IP address of the router needs to be set in the unit, the IP address must be static.

## SIP Setup

---

It might be necessary to manually set the router's global IP address and reception port number in the unit. In addition, it might also be necessary to configure the port forwarding settings of the router so that packets sent from an outside network are sent to the unit. These settings are required for each individual line. For details about Web user interface programming, see **4.3.6 Static NAPT Settings** and **4.5.2.5 SIP Source Port**.

## RTP (Real-time Transport Protocol) Setup

If the unit is connected to a network that uses a NAT router and a private IP address is assigned to each terminal on the network, you must configure the RTP function for the unit and router so that the units can perform voice transmission between each other using a peer-to-peer connection.

However, if your phone system supports the SBC (Session Border Controller) function, it is not necessary to configure these settings.

For details about the SBC function, consult your phone system dealer.

For details about Web user interface programming, see **4.3.6 Static NAPT Settings**.

## Router Setup

When configuring the port forwarding function, specify the router's reception port number as the unit's port number.

Port forwarding should be configured for the ports specified in **[Source Port]** (→ see **SIP Setup** in this section) and **[External RTP Port]** (→ see **RTP (Real-time Transport Protocol) Setup** in this section).

Set the same port number for the source port and destination port, and set the unit's private IP address as the destination address.

Because the unit's private IP address will have to be set in the router's port forwarding configuration again if it is changed, set a static IP address to the unit, or configure the router so that the same IP address is always assigned to the unit if IP addresses are assigned by a DHCP server.

For details about how to configure the router, refer to the documentation for the router.

Because the port forwarding settings depend on the user's network environment, they cannot be programmed using configuration files.

### 1.1.7.3 Global Address Detection

The global IP address is a unique IP address that is assigned to a particular terminal. If the global IP address assigned to the firewall or the router is changed, the unit will not be able to communicate.

If the global IP addresses of these terminals are assigned by a DHCP server in the higher level network where they are connected, the IP address may differ each time the unit transmits data.

The Global Address Detection feature detects the current global IP address and, if the IP address has changed, sets it automatically to the SIP server. There are 2 methods, using STUN (Simple Traversal of UDP through NATs) or SIP messages, to perform this feature. For details about specifying this setting through the Web user interface, see **4.3.5 Global Address Detection**.

#### Note

- For details about server information, consult your network administrator.

## 1.2 Reset and Firmware Update

### 1.2.1 Reset

#### 1.2.1.1 Resetting to Factory Default (Factory Setting)

Performing Factory Setting from the phone user interface resets all settings in the unit to their factory defaults. This type of initialization also deletes all other data on the unit, such as the call logs and the phonebook.

To perform this initialization, follow the procedure below:

### 1.2.1 Reset

---

1. Press **Setting** or **Setup**.
2. Press **[#][1][3][6]**.
3. Press **[▲]** or **[▼]** to select "Factory Setting", and then press **[ENTER]**.
4. Press **[▲]** or **[▼]** to select "Yes", and then press **[ENTER]**.
5. Press **[▲]** or **[▼]** to select "Yes", and then press **[ENTER]**.

#### **Notice**

- After performing Factory Setting, the unit will restart automatically. To avoid problems, it is recommended that you save your settings before performing Factory Setting.

### 1.2.1.2 Resetting the Network Settings (IP Reset)

Performing IP Reset from the phone user interface restores the basic network settings made through phone user interface programming, Web user interface programming, or configuration file programming to their factory defaults. If the unit is unable to connect to the network after changing network settings, you can restore the network settings to their factory defaults by performing IP Reset, and then try configuring the settings again. Apart from Call Rejection Phone Numbers, all Web user interface and configuration file programming settings will be reset to their factory defaults. However, settings such as the phonebook data, are not cleared by this feature.

To perform this initialization, follow the procedure below:

1. Press **Setting** or **Setup**.
2. Press **[#][1][3][6]**.
3. Press **[▲]** or **[▼]** to select "IP Reset", and then press **[ENTER]**.
4. Press **[▲]** or **[▼]** to select "Yes", and then press **[ENTER]**.
5. Press **[▲]** or **[▼]** to select "Yes", and then press **[ENTER]**.

#### **Notice**

- After performing IP Reset, the unit will restart automatically. To avoid problems, it is recommended that you save your settings before performing IP Reset.

### 1.2.1.3 Resetting the Settings Made through the Web User Interface (Reset Web Settings)

Performing Reset Web Settings from the Web user interface (→ see **4.7.5 Reset to Defaults**) resets the settings made through the Web user interface to their default values.

When you use this feature, the unit will return to the status just after performing the most recent provisioning or pre-provisioning.

#### **Notice**

- After performing Reset Web Settings, the unit will restart automatically. To avoid problems, it is recommended that you save your settings before performing Reset Web Settings.


#### **Note**

- The settings configured through the phone user interface only will not be reset. However, settings that can be configured through both the phone user interface and Web user interface will be reset.

## 1.2.2 Firmware Update

You can update the unit's firmware to improve the unit's operation. You can configure the unit so that it automatically downloads the new firmware file from a specified location. The firmware update will be executed when the unit is restarted.

For details, see **Section 7 Firmware Update**.



## **1.2.2 Firmware Update**

---

---

## **Section 2**

### ***General Information on Provisioning***

*This section provides an overview of the configuration file programming procedures for the unit, including pre-provisioning and provisioning.*

## 2.1 Pre-provisioning


---

### 2.1.1 What is Pre-provisioning?

To perform pre-provisioning, you must set the IP address of a TFTP server to the DHCP server option 66 so that the unit can acquire the TFTP server address. When the unit starts up and no configuration has been applied, it will automatically acquire the address of the TFTP server and download the configuration file.

For details about the configuration file, see [2.2.3 Configuration File](#).

For details about the settings that can be configured with the configuration files and how to specify the settings, see [Section 5 Configuration File Programming](#).



Pre-provisioning can aid the installation process by allowing phone system dealers to configure beforehand the minimum settings required to operate the unit.

For example, phone system dealers can store on the TFTP server a configuration file that contains only the URL of a server where another configuration file is stored. This second configuration file contains settings configured specifically for the usage environment of the user. The user will be able to start using the unit by just connecting it to the network.

Pre-provisioning is performed only once after the unit has been shipped. Once any configuration (such as pre-provisioning, provisioning, or Web user interface programming) has been applied, pre-provisioning will not be performed again.

Note that the settings configured by pre-provisioning cannot be restored once it has been performed. If you want to restore them, consult your phone system dealer.

Although pre-provisioning is often used to specify the location of the configuration files for provisioning, you can configure any of the settings through pre-provisioning. The unit can be made fully operational by configuring settings through pre-provisioning.

## 2.1.2 Pre-provisioning when Setting Static IP Addresses

To perform pre-provisioning, the unit needs to acquire the TFTP server address from option 66 on a DHCP server. Therefore, pre-provisioning cannot be performed if you use static IP addressing on your network. If you use static IP addressing and want to perform pre-provisioning, construct a small, separate network and connect a DHCP and TFTP server to that network.

In addition, if option 66 of the DHCP server cannot be set, or if you are unauthorized to change this setting, perform pre-provisioning on the separate network, and then connect the unit to the actual network.

## 2.1.3 Server for Pre-provisioning

The DHCP server and TFTP server play important roles in performing pre-provisioning. This section explains their purposes, uses, and brief descriptions.

Server	Purpose	Description
DHCP server	Used to provide the address of a TFTP server, set in option 66 of the DHCP server, to units that have not been configured yet.	<p>In option 66 of the DHCP server, specify the IP address or FQDN (Fully Qualified Domain Name) of the TFTP server. For details, refer to the documentation for your DHCP server.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>The maximum length of FQDN text is 255 bytes.</li> </ul>
TFTP server	Used to store configuration files, and is set as the access point for downloading them automatically.	<p>The unit will download the configuration file "(model name).cfg" stored in the root directory of the TFTP server. For example, if the model name is KX-UTxxx, the unit will download the configuration file "/KX-UTxxx.cfg".</p>

DHCP and TFTP servers may be supplied with your operating system, provided through commercial services, and are also distributed freely on the Internet. Use a server setup that best matches your environment.

When installing and setting up the DHCP server and TFTP server, refer to the documentation supplied with the product. For details about connecting servers to the network and managing them, consult your network administrator.

## 2.1.4 Pre-provisioning Setting Example

This section gives an example of how to perform pre-provisioning.

### Assumptions

Item	Description/Setting
TFTP server address	192.168.0.130
Distribution directory of TFTP server	/tftpboot
Model name of the unit	KX-UTxxx
MAC address of the unit	0080F0123456

## 2.1.4 Pre-provisioning Setting Example

---

Item	Description/Setting
Provisioning server name (where the configuration file used for provisioning is to be stored)	provisioning.example.com
Distribution directory of the provisioning server	/Panasonic
File name of the configuration file used for provisioning	Config0080F0123456.cfg
URL of the configuration file used for provisioning	http://provisioning.example.com/Panasonic/Config0080F0123456.cfg


### Prior Settings

Item	Description/Setting
DHCP server option 66	192.168.0.130
IP address range assigned by DHCP server	192.168.0.16 to 192.168.0.63
File name of the configuration file used for pre-provisioning	KX-UTxxx.cfg
URL of the configuration file used for provisioning that is entered in the configuration file	<b>CFG_STANDARD_FILE_PATH="http://provisioning.example.com/Panasonic/Config{MAC}.cfg"</b> <u>Note</u> <ul style="list-style-type: none"> <li>• "{MAC}" is replaced by the MAC address of the unit. (e.g., "0080F0123456")</li> </ul>
Stored location of the configuration file on the TFTP server	Configuration file "KX-UTxxx.cfg" is stored in the directory "/tftpboot".

## The pre-provisioning process


### Step 1

Connect the unit to the network, and turn the power on. The unit is assigned an IP address by the DHCP server, and also receives the TFTP server address from the DHCP server using DHCP server option 66.




### Step 2

The unit downloads the configuration file for pre-provisioning from the TFTP server:  
`tftp://192.168.0.130/KX-UT248.cfg`




#### Note

- The file name may be different depending on the phone being used. For example, the file name for KX-UT113 users will be:  
`tftp://192.168.0.130/KX-UT113.cfg`




### Step 3

The URL of the server where the configuration file for provisioning is stored (provisioning server) is set to the unit:  
`http://provisioning.example.com/Panasonic/Config{MAC}.cfg`



### Step 4

The unit will display a message indicating pre-provisioning is complete.



### Step 5

When the message is displayed, turn off the unit's power, then turn it back on.

The unit may restart automatically depending on the configuration file programming (→ see "OPTION66\_REBOOT" in **5.3.5 Provisioning Settings**).  
When the unit is distributed to end users and started up in real circumstances, provisioning will be performed correctly.


#### Note

- This example describes the case when only one unit is connected. However, multiple units can be configured through the same procedure without changing any settings, because the MAC address is specified by the {MAC} macro.

## 2.2 Provisioning

### 2.2.1 What is Provisioning?

After pre-provisioning has been performed (→ see **2.1 Pre-provisioning**), you can set up the unit automatically by downloading the configuration file stored on the provisioning server into the unit. This is called "provisioning".



### 2.2.2 Protocols for Provisioning

Provisioning can be performed over HTTP, HTTPS, FTP, and TFTP. The protocol you should use differs depending on how you will perform provisioning. Normally, HTTP, HTTPS, or FTP is used for provisioning. If you are transmitting encrypted configuration files, it is recommended that you use HTTPS. If you are transmitting unencrypted configuration files, it is recommended that you use HTTP. You may not be able to use FTP depending on the conditions of the network router or the network to be used.

### 2.2.3 Configuration File

This section gives concrete examples of the functions of the configuration file and how to manage it. The configuration file is a text file that contains the various settings that are necessary for operating the unit. The files are normally stored on a server maintained by your phone system dealer, and will be downloaded to the units as required. All configurable settings can be specified in the configuration file. You can ignore settings that already have the desired values. Only change parameters as necessary.

For details about setting parameters and their descriptions, see **Section 5 Configuration File Programming**.

## Using 3 Types of Configuration Files

The unit can download up to 3 configuration files. One way to take advantage of this is by classifying the configuration files into the following 3 types:

Type	Usage
Master configuration file	<p>Configure settings that are common to all units, such as the SIP server address, and the IP addresses of the DNS and NTP (Network Time Protocol) servers managed by your phone system dealer. This configuration file is used by all the units.</p> <p>Example of the configuration file's URL:  <a href="http://prov.example.com/Panasonic/ConfigCommon.cfg">http://prov.example.com/Panasonic/ConfigCommon.cfg</a></p>
Product configuration file	<p>Configure settings that are required for a particular model, such as the default setting of the privacy mode. This configuration file is used by all the units that have the same model name.</p> <p>The same number of configuration files as models being used on the network are stored on the provisioning server, and units with the same model name download the corresponding configuration file.</p> <p>Example of the configuration file's URL:  <a href="http://prov.example.com/Panasonic/Config{MODEL}.cfg">http://prov.example.com/Panasonic/Config{MODEL}.cfg</a></p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>When a unit requests the configuration file, "{MODEL}" is replaced by the model name of the unit.</li> </ul>
Standard configuration file	<p>Configure settings that are unique to each unit, such as the phone number, user ID, password, etc.</p> <p>The same number of configuration files as units are stored on the provisioning server, and each unit downloads the corresponding standard configuration file.</p> <p>Example of the configuration file's URL:  <a href="http://prov.example.com/Panasonic/Config{MAC}.cfg">http://prov.example.com/Panasonic/Config{MAC}.cfg</a></p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>When a unit requests the configuration file, "{MAC}" is replaced by the MAC address of the unit.</li> </ul>

Depending on the situation, you can use all 3 types of configuration files, and can also use only a standard configuration file.

The above example shows only one possible way to use configuration files. Depending on the requirements of your phone system dealer, there are a number of ways to use configuration files effectively.

## Using 2 Types of Configuration Files

The following table shows an example of using 2 types of configuration files: a master configuration file to configure settings common to all units, and product configuration files to configure settings common to particular groups.

### Using Product Configuration Files According to the Position Groups

You can use product configuration files for different groups or for multiple users within the same group.

## 2.2.4 Downloading Configuration Files

---

Department Name	URL of Product Configuration File
Sales	<a href="http://prov.example.com/Panasonic/ConfigSales.cfg">http://prov.example.com/Panasonic/ConfigSales.cfg</a>
Planning	<a href="http://prov.example.com/Panasonic/ConfigPlanning.cfg">http://prov.example.com/Panasonic/ConfigPlanning.cfg</a>

## 2.2.4 Downloading Configuration Files

### Downloading a Configuration File via the Web User Interface

---

The following procedure describes how to enable downloading a configuration file via the Web User Interface to be used for programming the unit.


1. Confirm that the provisioning server's IP address/FQDN and directory are correct, and store the configuration files in the directory (e.g., [http://provisioning.example.com/Panasonic/Config\\_Sample.cfg](http://provisioning.example.com/Panasonic/Config_Sample.cfg)).
2. Enter the IP address of the unit into the PC's Web browser (→ see **1.1.6.3 Before Accessing the Web User Interface**).
3. Log in as the administrator (→ see **Access Levels (IDs and Passwords)** in **1.1.6.3 Before Accessing the Web User Interface**).
4. Click the **[Maintenance]** tab, click **[Provisioning Maintenance]**, and then select **[Yes]** for **[Enable Provisioning]**.
5. Enter the URL set up in Step 1 in **[Standard File URL]**.
6. Click **[Save]**.

### Timing of Downloading


---

A unit downloads configuration files when it starts up, at regular intervals, and when directed to do so by the server. In addition, you can prohibit units from downloading the configuration files. For details about the settings, see **4.7.3 Provisioning Maintenance** and **5.3.5 Provisioning Settings**.

Download Timing	Explanation
Startup	The configuration files are downloaded when the unit starts up.

Download Timing	Explanation
At regular intervals of time	<p>The configuration files are downloaded at specified intervals of time, set in minutes. In the example below, the unit has been programmed to check for and download configuration files from the provisioning server every 3 days (4320 minutes).</p>  <p>The configuration files are downloaded periodically under the following conditions:</p> <ul style="list-style-type: none"> <li>• In the configuration file, add the line, <code>CFG_CYCLIC="Y"</code>.       <ul style="list-style-type: none"> <li>– Set an interval (minutes) by specifying "<code>CFG_CYCLIC_INTVL</code>".</li> </ul> </li> <li>• In the Web user interface:       <ul style="list-style-type: none"> <li>– Click the <b>[Maintenance]</b> tab, click <b>[Provisioning Maintenance]</b>, and then select <b>[Yes]</b> for <b>[Cyclic Auto Resync]</b>.</li> <li>– Enter an interval (minutes) in <b>[Resync Interval]</b>.</li> </ul> </li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• The interval may be determined by your phone system dealer. A maximum interval of 28 days (40320 minutes) can be set on the unit.</li> </ul>

## 2.2.4 Downloading Configuration Files

Download Timing	Explanation
At a specified time each day	<p>After the unit is powered on, it will check for and download configuration files once per day at the specified time.</p>  <p>The configuration files are downloaded at a set time each day:</p> <ul style="list-style-type: none"> <li>Set a time by specifying "<u>CFG_RESYNC_TIME</u>".</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>If the value for "<u>CFG_RESYNC_TIME</u>" is any valid value other than an empty string, the unit downloads the configuration files at the fixed time, and the settings specified in "<u>CFG_CYCLIC</u>", "<u>CFG_CYCLIC_INTVL</u>", and "<u>CFG_RTRY_INTVL</u>" are disabled.</li> <li>The time is specified using a 24-hour clock ("00:00" to "23:59").</li> </ul>
When directed	<p>When a setting needs to be changed immediately, units can be directed to download the configuration files by sending them a NOTIFY message that includes a special event from the SIP server.</p> <ul style="list-style-type: none"> <li>In the configuration file: <ul style="list-style-type: none"> <li>Specify the special event text in "<u>CFG_RESYNC_FROM_SIP</u>".</li> </ul> </li> <li>In the Web user interface: <ul style="list-style-type: none"> <li>Click the [<b>Maintenance</b>] tab, click [<b>Provisioning Maintenance</b>], and then enter the special event text in [<b>Header Value for Resync Event</b>].</li> </ul> </li> </ul> <p>Generally, "check-sync" or "resync" is set as the special event text.</p>

Download Timing	Explanation
None (prohibited)	<p>If you want to prohibit units from changing their settings by downloading configuration files, you can enable this function from the Web user interface. The following operations will be prohibited:</p> <ul style="list-style-type: none"> <li>– Pre-provisioning</li> <li>– Provisioning at startup</li> <li>– Provisioning at regular intervals</li> <li>– Provisioning by sending a NOTIFY message</li> <li>• In the configuration file: <ul style="list-style-type: none"> <li>– Add the line, <code>PROVISION_ENABLE="N"</code>.</li> </ul> </li> <li>• In the Web user interface: <ul style="list-style-type: none"> <li>– Click the <b>[Maintenance]</b> tab, click <b>[Provisioning Maintenance]</b>, and then select <b>[No]</b> for <b>[Enable Provisioning]</b>.</li> </ul> </li> <li>• To enable provisioning again, in the Web user interface: <ul style="list-style-type: none"> <li>– Click the <b>[Maintenance]</b> tab, click <b>[Provisioning Maintenance]</b>, and then select <b>[Yes]</b> for <b>[Enable Provisioning]</b>.</li> </ul> </li> </ul>

## 2.2.5 Provisioning Server Setting Example

This section gives an example of how to set up the units and provisioning server when configuring 2 units with configuration files. The standard configuration files and the master configuration file are used in this example.

### Conditions

Item	Description/Setting
Provisioning server FQDN	prov.example.com
Units' MAC addresses	<ul style="list-style-type: none"> <li>• 0080F0111111</li> <li>• 0080F0222222</li> </ul>
URL of the configuration files	<p>Configure the following 2 settings either by pre-provisioning or through the Web user interface. The values of both settings must be the same.</p> <ul style="list-style-type: none"> <li>• <code>CFG_STANDARD_FILE_PATH="http://prov.example.com/Panasonic/Config{MAC}.cfg"</code></li> <li>• <code>CFG_MASTER_FILE_PATH="http://prov.example.com/Panasonic/ConfigCommon.cfg"</code></li> </ul>
Directory on the provisioning server containing the configuration files	Create the "Panasonic" directory just under the HTTP root directory of the provisioning server.
File name of configuration files	<p>Store the following configuration files in the "Panasonic" directory.</p> <ul style="list-style-type: none"> <li>• Contains the common settings for the 2 units: <ul style="list-style-type: none"> <li>– ConfigCommon.cfg</li> </ul> </li> <li>• Contains the settings unique to each unit: <ul style="list-style-type: none"> <li>– Config0080F0111111.cfg</li> <li>– Config0080F0222222.cfg</li> </ul> </li> </ul>

## 2.2.6 Encryption

---

### To set up the provisioning server

1. Connect the units to the network, and turn them on.
  - a. The unit with the MAC address 0080F0111111 accesses the following URLs:  
<http://prov.example.com/Panasonic/ConfigCommon.cfg>  
<http://prov.example.com/Panasonic/Config0080F0111111.cfg>
  - b. The unit with the MAC address 0080F0222222 accesses the following URLs:  
<http://prov.example.com/Panasonic/ConfigCommon.cfg>  
<http://prov.example.com/Panasonic/Config0080F0222222.cfg>

### Example Provisioning Direction from the Server

The following figure shows an example NOTIFY message from the server, directing the units to perform provisioning. The text "check-sync" is specified for "CFG\_RESYNC\_FROM\_SIP".

```
NOTIFY sip:1234567890@sip.example.com SIP/2.0
Via: SIP/2.0/UDP xxx.xxx.xxx.xxx:5060;branch=abcdef-ghijkl
From: sip:prov@sip.example.com
To: sip:1234567890@sip.example.com
Date: Thu, 1 Jan 2009 01:01:01 GMT
Call-ID: 123456-1234567912345678
CSeq: 1 NOTIFY
Contact: sip:xxx.xxx.xxx.xxx:5060
Event: check-sync
Content-Length: 0
```

## 2.2.6 Encryption


### Secure Provisioning Methods

---

In order to perform provisioning securely, there are 2 methods for transferring configuration files securely between the unit and the server.

Which method is used depends on the environment and equipment available from the phone system.

#### Method 1: Transferring Encrypted Configuration Files



To use this method, an encryption key is required to encrypt and decrypt the configuration files. A preset encryption key unique to each unit, an encryption key set by your phone system dealer, etc., is used for the encryption. When the unit downloads an encrypted configuration file, it will decrypt the file using the same encryption key, and then configure the settings automatically.

#### Method 2: Transferring Configuration Files Using HTTPS

This method uses SSL, which is commonly used on the Internet, to transfer configuration files between the unit and server. For more secure communication, you can use a root certificate.

**Notice**

- To avoid redundant data transfer over the network, important data, such as the encryption key used to encrypt the configuration files and the root certificate for SSL, should be configured through pre-provisioning as much as possible.
- It is recommended that you encrypt the data in order to keep the communication secure when transferring configuration files.  
However, if you are using the units within a secure environment, such as within an intranet, it is not necessary to encrypt the data.

To decrypt configuration files, the unit uses the encryption key registered to it beforehand. The unit determines the encryption status by checking the extension of the downloaded configuration file.

For details about encrypting configuration files, contact the appropriate person in your organization.

<b>Extension of Configuration File</b>	<b>Configuration File Parameters Used for Decrypting</b>
".e1c"	<code>CFG_FILE_KEY1</code>
".e2c"	<code>CFG_FILE_KEY2</code>
".e3c"	<code>CFG_FILE_KEY3</code>
Other than ".e1c", ".e2c", and ".e3c"	Processed as unencrypted configuration files. The extension ".cfg" should be used for unencrypted configuration files.

**Comparison of the 2 Methods**

The following table compares the characteristics for the 2 transfer methods.

	<b>Transferring Encrypted Configuration Files</b>	<b>Transferring Configuration Files Using HTTPS</b>
Provisioning server load	Light	Heavy (The server encrypts data for each transmission.)
Operation load	Necessary to encrypt data beforehand.	Unnecessary to encrypt data beforehand.
Management of configuration files	Files must be decrypted and re-encrypted for maintenance.	It is easy to manage files because they are not encrypted on the server.
Security of data on the server when operating	High	Low (Configuration files are readable by anyone with access to the server.)

Moreover, there is another method: configuration files are not encrypted while stored on the server, and then, using the encryption key registered to the unit beforehand, they are encrypted when they are transferred. This method is particularly useful when several units are configured to download a common configuration file using different encryption keys. However, as when downloading an unencrypted configuration file using HTTPS, the server will be heavily burdened when transferring configuration files.

## 2.3 Priority of Setting Methods

The same settings can be configured by different configuration methods: provisioning, Web user interface programming, etc. This section explains which value is applied when the same setting is specified by multiple methods.

## 2.4 Configuration File Specifications

---

The following table shows the priority with which settings from each method are applied (lower numbers indicate higher priority):

Setting Order	Priority	Setting Method
1	4	The factory default settings for the unit
2	3	Pre-provisioning with the configuration file
3	2–3	Provisioning with the master configuration file
	2–2	Provisioning with the product configuration file
	2–1	Provisioning with the standard configuration file
4	1	Settings configured from the Web user interface or the phone user interface

According to the table, settings configured later override previous settings (i.e., settings listed lower in the table have a higher priority).

If different values are specified for the same setting by the master configuration file and Web user interface programming, the value specified from the Web user interface is applied. This is because values specified from the Web user interface have a higher priority.

For settings configured from the Web user interface and the phone user interface, the value specified most recently receives priority.

### **Notice**

- Make sure to perform Reset to Factory Default before connecting the unit to a different phone system.  
For details, see [1.2.1.1 Resetting to Factory Default \(Factory Setting\)](#).

## 2.4 Configuration File Specifications

---

The specifications of the configuration files are as follows:

### **File Format**

The configuration file is in plain text format.

### **File Size**

The maximum size of a configuration file is 120 KB. Regardless of the number of configuration files, the total size of the configuration files must be 120 KB or less.

### **Lines in Configuration Files**

A configuration file consists of a sequence of lines, with the following conditions:

- Each line must end with "<CR><LF>".
- The maximum length of a line is 537 bytes including "<CR><LF>".
- The following lines are ignored:
  - Lines that exceed the limit of 537 bytes
  - Empty lines
  - Comment lines that start with "#"
- Configuration files must start with a comment line containing the following designated character sequence (44 bytes):  
**# Panasonic SIP Phone Standard Format File #**  
The hexadecimal notation of this sequence is:

```
23 20 50 61 6E 61 73 6F 6E 69 63 20 53 49 50 20
50 68 6F 6E 65 20 53 74 61 6E 64 61 72 64 20 46
6F 72 6D 61 74 20 46 69 6C 65 20 23
```

- To prevent the designated character sequence being altered by chance, it is recommended that the configuration file starts with the comment line shown below:  
`# Panasonic SIP Phone Standard Format File # DO NOT CHANGE THIS LINE!`
- Configuration files must end with an empty line.
- Each parameter line is written in the form of XXX="yyy" (XXX: parameter name, yyy: parameter value). The value must be enclosed by double quotation marks.
- A parameter line written over multiple lines is not allowed. It will cause an error on the configuration file, resulting in invalid provisioning.

### Configuration Parameters

- The unit supports multiple telephone lines. For some parameters, the value for each line must be specified independently. A parameter name with the suffix "\_1" is the parameter for line 1; "\_2" for line 2, and so on. Examples of setting the line (phone number) for accessing a voice mail server:  
`"VM_NUMBER_1": for line 1,`  
`"VM_NUMBER_2": for line 2, ...,`  
`"VM_NUMBER_6": for line 6`

#### Note

- The number of lines available varies depending on the phone being used, as follows:
  - KX-UT113/KX-UT123: 1–2
  - KX-UT133/KX-UT136: 1–4
  - KX-UT248: 1–6
- The maximum length of a parameter name is 32 characters.
- The maximum length of a parameter value is 500 characters excluding double quotation marks.
- No space characters are allowed in the line except when the value includes a space character(s). Example:  
`DISPLAY_NAME_1="John Smith" (valid)`  
`DISPLAY_NAME_1 = "John Smith" (invalid)`
- Some parameter values can be specified as "empty" to set the parameter values to empty. Example:  
`NTP_ADDR=""`
- The parameters have no order.
- If the same parameter is specified in a configuration file more than once, the value specified first is applied.
- All configurable settings can be specified in the configuration file. You can ignore settings that already have the desired values. Only change parameters as necessary.

## 2.5 Configuration File Examples

The following examples of configuration files are provided on the Panasonic Web site (→ see **Introduction**).

- Simplified Example of the Configuration File
- Comprehensive Example of the Configuration File

## 2.5.1 Examples of Codec Settings

### Setting the Codec Priority to (1)G.729A, (2)G.726-32, (3)PCMU, (4)G.722

---

```
## Codec Settings
# Enable G722
CODEC_ENABLE0_1="Y"
CODEC_PRIORITY0_1="4"
# Disable PCMA
CODEC_ENABLE1_1="N"
# Enable G726-32K
CODEC_ENABLE2_1="Y"
CODEC_PRIORITY2_1="2"
# Enable G729A
CODEC_ENABLE3_1="Y"
CODEC_PRIORITY3_1="1"
# Enable PCMU
CODEC_ENABLE4_1="Y"
CODEC_PRIORITY4_1="3"
```

### Setting Narrow-band Codecs (PCMA, G.726-32 and G.729A)

---

```
## Codec Settings
# Disable G722
CODEC_ENABLE0_1="N"
# Enable PCMA
CODEC_ENABLE1_1="Y"
CODEC_PRIORITY1_1="1"
# Enable G726-32K
CODEC_ENABLE2_1="Y"
CODEC_PRIORITY2_1="1"
# Enable G729A
CODEC_ENABLE3_1="Y"
CODEC_PRIORITY3_1="1"
# Disable PCMU
CODEC_ENABLE4_1="N"
```

### Setting the G.729A Codec Only

---

```
## Codec Settings
# Disable G722
CODEC_ENABLE0_1="N"
# Disable PCMA
CODEC_ENABLE1_1="N"
# Disable G726-32K
CODEC_ENABLE2_1="N"
# Enable G729A
CODEC_ENABLE3_1="Y"
CODEC_PRIORITY3_1="1"
# Disable PCMU
CODEC_ENABLE4_1="N"
# Do not set PCMU
```

```
CODEC_G711_REQ="0"
```

## 2.5.2 Example with Incorrect Descriptions

The following listing shows an example of a configuration file that contains incorrect formatting:

- ① An improper description is entered in the first line. A configuration file must start with the designated character sequence "# Panasonic SIP Phone Standard Format File #".
- ② Comment lines start in the middle of the lines.
- ③ Space characters are inserted in the middle of the setting line.
- ④ A specified value is not in the range allowed for that setting.

### Incorrect Example

```
# This is a simplified sample configuration file. —①

#####
# Configuration Setting #
#####

CFG_STANDARD_FILE_PATH="http://config.example.com/0123456789AB.cfg"
    # URL of this configuration file

#####
# SIP Settings #
# Suffix "_1" indicates this parameter is for "line 1". #
#####

SIP_RGSTR_ADDR_1="registrar.example.com" # IP Address or FQDN of SIP registrar server —②
SIP_PRXY_ADDR_1="proxy.example.com"      # IP Address or FQDN of proxy server

# Enables DNS SRV lookup
SIP_DNSSRV_ENA_1="Y"

# ID, password for SIP authentication
SIP_AUTHID_1="SIP_User"                   —③
SIP_PASS_1="SIP_Password"

# Some Timer Settings #
# Expiration time of SIP registration; "1 hour"
REG_EXPIRE_TIME_1="3600"
# Disables SIP Session Timer (RFC 4028)
SIP_SESSION_TIME_1="0"
```

```
# DTMF will be sent through SDP, according to RFC 2833
OUTBANDDTMF_1="Y"

#####
# Call Control Settings #
#####

# Enables subscription to the Voice Mail server
VM_SUBSCRIBE_ENABLE="Y" ④

# Shared Call Settings
SHARED_CALL_ENABLE_1="Y"

# Disables Do Not Disturb, Call Forward synchronization.
FWD_DND_SYNCHRO_ENABLE_1="N"
```

## 2.6 Setting Configuration File Parameters Using TR-069

---

TR-069 (Technical Report 069) is a protocol for the remote management of terminals using the technical specifications of CWMP (CPE [Customer Premises Equipment] WAN Management Protocol). TR-069 allows terminals to have their settings configured automatically via connection to ACSs (Auto Configuration Servers). For details about setting up the parameters necessary for using TR-069, see **4.7.4 Management Server** and **5.3.6 Management Server Settings**.

### Notice

- Settings that are configured using TR-069 can also be configured using the standard configuration file. Therefore, take care that settings do not overlap when using both configuration methods together.

### Settings configured using TR-069

Requirement	Parameter Name		Ref.
	TR-069 Parameter	Configuration File Parameter	
TR-106	Device.Time.NTPServer1	NTP_ADDR	Page 199
TR-106	Device.Time.LocalTimeZone	LOCAL_TIME_ZONE_POSIX	Page 173
TR-106	Device.ManagementServer.URL	ACS_URL	Page 184
TR-106	Device.ManagementServer.Username	ACS_USER_ID	Page 184
TR-106	Device.ManagementServer.Password	ACS_PASS	Page 185
TR-106	Device.ManagementServer.PeriodicInfo_rmEnable	PERIODIC_INFORM_ENABLE	Page 185
TR-106	Device.ManagementServer.PeriodicInfo_rmInterval	PERIODIC_INFORM_INTERVAL	Page 185
TR-106	Device.ManagementServer.PeriodicInfo_rmTime	PERIODIC_INFORM_TIME	Page 185

<b>Requirement</b>	<b>Parameter Name</b>		<b>Ref.</b>
	<b>TR-069 Parameter</b>	<b>Configuration File Parameter</b>	
TR-106	Device.ManagementServer.ConnectionRequestUsername	<b>CON_REQ_USER_ID</b>	Page 186
TR-106	Device.ManagementServer.ConnectionRequestPassword	<b>CON_REQ_PASS</b>	Page 186
TR-106	Device.ManagementServer.STUNEnable	<b>ANNEX_G_STUN_ENABLE</b>	Page 187
TR-106	Device.ManagementServer.STUNServerAddress	<b>ANNEX_G_STUN_SERV_ADDR</b>	Page 187
TR-106	Device.ManagementServer.STUNServerPort	<b>ANNEX_G_STUN_SERV_PORT</b>	Page 187
TR-106	Device.ManagementServer.STUNUserName	<b>ANNEX_G_STUN_USER_ID</b>	Page 187
TR-106	Device.ManagementServer.STUNPassWord	<b>ANNEX_G_STUN_PASS</b>	Page 188
TR-106	Device.ManagementServer.STUNMaximumKeepAlivePeriod	<b>ANNEX_G_STUN_MAX_KEEP_ALIVE</b>	Page 188
TR-106	Device.ManagementServer.STUNMinimumKeepAlivePeriod	<b>ANNEX_G_STUN_MIN_KEEP_ALIVE</b>	Page 188
TR-106	Device.ManagementServer.UDPConnectionRequestAddressNotificationLimit	<b>UDP_CON_REQ_ADDR_NOTIFY_LIMIT</b>	Page 189
TR-104	Device.VoiceService.1.VoiceProfile.1.Line.1.Codec.List.1.PacketizationPeriod	<b>RTP_PTIME</b>	Page 235
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Line.1.Codec.List.{x}.Enable	<b>CODEC_ENABLEx_n</b>	Page 231
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Line.1.Codec.List.{x}.Priority	<b>CODEC_PRIORITYx_n</b>	Page 231
TR-104	Device.VoiceService.1.VoiceProfile.{n}.RTP.RTCP.TxRepeatInterval	<b>RTCP_INTVL_n</b>	Page 233
TR-104	Device.VoiceService.1.VoiceProfile.1.RTP.LocalPortMin	<b>RTP_PORT_MIN</b>	Page 234
TR-104	Device.VoiceService.1.VoiceProfile.1.RTP.LocalPortMax	<b>RTP_PORT_MAX</b>	Page 234
TR-104	Device.VoiceService.1.VoiceProfile.{n}.RTP.DSCPMark	<b>DSCP_RTP_n</b>	Page 232
TR-104	Device.VoiceService.1.VoiceProfile.{n}.RTP.RTCP.Enable	<b>RTCP_ENABLE_n</b>	Page 235
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Enable	<b>PROFILE_ENABLEn</b>	Page 245

## 2.6 Setting Configuration File Parameters Using TR-069

Requirement	Parameter Name		Ref.
	TR-069 Parameter	Configuration File Parameter	
TR-104	Device.VoiceService.1.VoiceProfile.{n}.DTMFMethod	<b>OUTBANDDTMF_n</b>	Page 236
		<b>DTMF_RELAY_n</b>	Page 237
TR-104	Device.VoiceService.1.VoiceProfile.{n}.DigitMap	<b>DIAL_PLAN_n</b>	Page 239
TR-104	Device.VoiceService.1.VoiceProfile.1.RTP.TelephoneEventPayloadType	<b>TELEVENT_PAYLOAD</b>	Page 237
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Line.1.SIP.AuthUserName	<b>SIP_AUTHID_n</b>	Page 245
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Line.1.SIP.AuthPassword	<b>SIP_PASS_n</b>	Page 246
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Line.1.SIP.URI	<b>SIP_URI_n</b>	Page 244
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.ProxyServer	<b>SIP_PRXY_ADDR_n</b>	Page 246
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.ProxyServerPort	<b>SIP_PRXY_PORT_n</b>	Page 246
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.RegistrarServer	<b>SIP_RGSTR_ADDR_n</b>	Page 247
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.RegistrarServerPort	<b>SIP_RGSTR_PORT_n</b>	Page 247
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.UserAgentDomain	<b>SIP_SVCDOMAIN_n</b>	Page 247
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.UserAgentPort	<b>SIP_SRC_PORT_n</b>	Page 246
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.RegisterExpires	<b>REG_EXPIRE_TIME_n</b>	Page 248
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.DSCPMark	<b>DSCP_SIP_n</b>	Page 249
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.TimerT1	<b>SIP_TIMER_T1_n</b>	Page 250
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.TimerT2	<b>SIP_TIMER_T2_n</b>	Page 250
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.TimerT4	<b>SIP_TIMER_T4_n</b>	Page 251
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.TimerB	<b>SIP_TIMER_B_n</b>	Page 262
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.TimerD	<b>SIP_TIMER_D_n</b>	Page 262

<b>Requirement</b>	<b>Parameter Name</b>		<b>Ref.</b>
	<b>TR-069 Parameter</b>	<b>Configuration File Parameter</b>	
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.TimerF	<b>SIP_TIMER_F_n</b>	Page 263
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.TimerH	<b>SIP_TIMER_H_n</b>	Page 263
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.TimerJ	<b>SIP_TIMER_J_n</b>	Page 263
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.InviteExpires	<b>SIP_INVITE_EXPIRE_n</b>	Page 254
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.EventSubscribe.{i}.Notifier	<b>SIP_PRSNC_ADDR_n</b>	Page 254
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.EventSubscribe.{i}.NotifierPort	<b>SIP_PRSNC_PORT_n</b>	Page 255
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.EventSubscribe.{i}.ExpireTime	<b>SUB_RTX_INTVL_n</b>	Page 257
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.RegisterRetryInterval	<b>REG_RTX_INTVL_n</b>	Page 258
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.OutboundProxy	<b>SIP_OUTPROXY_ADDR_n</b>	Page 259
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.OutboundProxyPort	<b>SIP_OUTPROXY_PORT_n</b>	Page 260
TR-104	Device.VoiceService.1.VoiceProfile.{n}.SIP.ProxyServerTransport	<b>SIP_TRANSPORT_n</b>	Page 260
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Line.1.DirectoryNumber	<b>PHONE_NUMBER_n</b>	Page 244
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Line.1.CallingFeatures.CallerIDName	<b>DISPLAY_NAME_n</b>	Page 239
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Line.1.CallingFeatures.CallWaitingEnable	<b>CW_ENABLE_n</b>	Page 242
TR-104	Device.VoiceService.1.VoiceProfile.{n}.Line.1.Enable	<b>LINE_ENABLE_n</b>	Page 245
TR-104	Device.VoiceService.1.VoiceProfile.1.ButtonMap.Button.{x}.FacilityAction	<b>FLEX_BUTTON_FACILITY_ACT_x</b>	Page 224
TR-104	Device.VoiceService.1.VoiceProfile.1.ButtonMap.Button.{x}.FacilityActionArgument	<b>FLEX_BUTTON_FACILITY_ARG_x</b>	Page 224
TR-104	Device.VoiceService.1.VoiceProfile.1.ButtonMap.Button.{x}.QuickDialNumber	<b>FLEX_BUTTON_QUICK_DIALx</b>	Page 224

## 2.6 Setting Configuration File Parameters Using TR-069

---

Requirement	Parameter Name		Ref.
	TR-069 Parameter	Configuration File Parameter	
TR-104	Device.VoiceService.1.VoiceProfile. 1.ButtonMap.Button.{x}.ButtonMessage	<b>FLEX_BUTTON_LABELx</b>	Page 225

---

## **Section 3**

### ***Phone User Interface Programming***

*This section explains how to configure the unit by entering direct commands through the phone user interface.*

## 3.1 Phone User Interface Programming

This section provides information about the features that can be configured directly from the unit, but that are not mentioned in the Operating Instructions.

To enter direct commands, use the dial keys and soft buttons on the unit.

For details about the other available features, settings and key operations on the phone user interface, refer to the Operating Instructions on the Panasonic Web site (→ see **Introduction**).

### 3.1.1 Phone User Interface Feature List and Direct Commands

The following table shows additional features programmable with direct commands. These commands are hidden from end users.

Direct Command	Feature	Ref.
[#][1][3][6]	Resetting the unit <sup>*1</sup>	Page 29
[#][2][8][9]	Delete all items of phonebook <sup>*1</sup>	Page 56
[#][5][3][4]	Embedded web	Page 22
[#][7][3][1]	Terminal No.	Page 56
[#][7][3][9]	Reset Web ID/Password <sup>*1</sup>	Page 57
[#][2][7][6]	Sound Quality <sup>*2</sup>	Page 57

<sup>\*1</sup> Not displayed on the LCD of the unit.

<sup>\*2</sup> KX-UT113/KX-UT123/KX-UT133/KX-UT136 only

### 3.1.2 Phonebook deletion

You can delete all items in the phonebook by performing the procedure below from the unit.

#### To delete all items in the phonebook

1. Press **Setting** or **Setup**.
2. Press **[#][2][8][9]**.
3. Press **[▲]** or **[▼]** to select "Yes" to delete all items in the phonebook, and then press **[ENTER]**.

### 3.1.3 Terminal Number Settings

You can select the terminal number of the unit that you are using from "Terminal 1"–"Terminal 9", and "Auto". The default setting is "Auto". "Auto" does not assign a fixed terminal number to the unit.

If multiple units try to access the same router simultaneously, errors can occur. Assigning a terminal number 1 to 9 to each of the units may prevent such errors.

#### To assign a terminal number to the unit

1. Press **Setting** or **Setup**.
2. Press **[#][7][3][1]**.
3. Press **[▲]** or **[▼]** to select the desired terminal number ("Auto", "Terminal 1"–"Terminal 9"), and then press **[ENTER]**.

### 3.1.4 Reset Web ID/Password

Reset Web ID/Password resets all the IDs and passwords required for users and administrators to access the Web user interface (→ see **Access Levels (IDs and Passwords)** in **1.1.6.3 Before Accessing the Web User Interface**) to their factory defaults. You can perform this operation from the unit.

#### To perform Reset Web ID/Password

1. Press **Setting** or **Setup**.
2. Press **[#][7][3][9]**.
3. Press **[▲]** or **[▼]** to select "Yes" to reset the Web ID/Password, and then press **[ENTER]**.  
All the IDs and passwords are reset, and the unit will restart.

#### Notice

- For security reasons, it is recommended that the passwords are set again immediately (→ see **4.4.2 Administrator Password** or **4.4.3 Change User Password**).

### 3.1.5 Sound Quality (KX-UT113/KX-UT123/KX-UT133/KX-UT136 only)

You can select the parameter of the unit that you are using from "0" or "1". The default setting is "0". "1" is a special technical parameter. If you select "1", handset sound becomes more stable but there is a risk of echo occurring.

#### To assign a parameter to the unit

1. Press **Setting** or **Setup**.
2. Press **[#][2][7][6]**.
3. Press **[▲]** or **[▼]** to select the parameter ("0" or "1"), and then press **[ENTER]**.

### **3.1.5 Sound Quality (KX-UT113/KX-UT123/KX-UT133/KX-UT136 only)**

---

---

## **Section 4**

### ***Web User Interface Programming***

*This section provides information about the settings available in the Web user interface.*

## 4.1 Web User Interface Setting List

The following tables show all the settings that you can configure from the Web user interface and the access levels. For details about each setting, see the reference pages listed.

For details about setting up Web user interface programming, see **1.1.6 Web User Interface Programming**.

### Status

Menu Item	Section Title	Setting	Access Level <sup>1</sup>		Ref.
			U	A	
Version Information	Version Information	Model	✓	✓	Page 72
		Operating Bank	✓	✓	Page 72
		IPL Version	✓	✓	Page 72
		Firmware Version	✓	✓	Page 72
Network Status	Network Status	MAC Address	✓	✓	Page 73
		Ethernet Link Status (LAN Port)	✓	✓	Page 73
		Ethernet Link Status (PC Port) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only)	✓	✓	Page 73
		Connection Mode	✓	✓	Page 74
		IP Address	✓	✓	Page 74
		Subnet Mask	✓	✓	Page 74
		Default Gateway	✓	✓	Page 74
		DNS1	✓	✓	Page 75
		DNS2	✓	✓	Page 75
		IEEE802.1X Status (KX-UT248 only)	✓	✓	Page 75
VoIP Status	VoIP Status	Line No.	✓	✓	Page 76
		Phone Number	✓	✓	Page 76
		VoIP Status	✓	✓	Page 76

<sup>1</sup> The access levels are abbreviated as follows:

U: User; A: Administrator

A check mark indicates that the setting is available for that access level.

## Network

Menu Item	Section Title	Setting	Access Level <sup>*1</sup>		Ref.
			U	A	
Basic Network Settings	Connection Mode	Connection Mode <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 78
	DHCP Settings	Host Name <sup>*4</sup>		✓	Page 78
		Domain Name Server <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 79
	Static Settings	Static IP Address <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 79
		Subnet Mask <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 80
		Default Gateway <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 80
		DNS1 <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 80
		DNS2 <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 81

#### 4.1 Web User Interface Setting List

Menu Item	Section Title	Setting	Access Level <sup>†1</sup>		Ref.
			U	A	
Ethernet Port Settings	Link Speed/Duplex Mode	LAN Port <sup>†5</sup>		✓	Page 82
		PC Port (KX-UT123/ KX-UT133/KX-UT136/ KX-UT248 only) <sup>†5</sup>		✓	Page 82
	LLDP Settings	Enable LLDP <sup>†2</sup>		✓	Page 83
		LLDP-MED Interval timer <sup>†2</sup>		✓	Page 83
		IP Phone	—	—	—
		VLAN ID <sup>†2</sup>		✓	Page 83
		Priority <sup>†2</sup>		✓	Page 83
		PC	—	—	—
		VLAN ID (KX-UT123/ KX-UT133/KX-UT136/ KX-UT248 only) <sup>†2</sup>		✓	Page 84
		Priority (KX-UT123/ KX-UT133/KX-UT136/ KX-UT248 only) <sup>†2</sup>		✓	Page 84
IEEE802.1X Settings (KX-UT248 only)	IEEE802.1X Settings	Enable IEEE802.1X <sup>†4</sup>		✓	Page 86
		IEEE802.1X Authentication		✓	Page 86
		Authentication Protocol <sup>†4</sup>		✓	Page 86
		Authentication ID <sup>†4</sup>		✓	Page 87
		Authentication Password <sup>†4</sup>		✓	Page 87

Menu Item	Section Title	Setting	Access Level <sup>*1</sup>		Ref.
			U	A	
HTTP Client Settings	HTTP Client Settings	HTTP Version <sup>*4</sup>		✓	Page 88
		HTTP User Agent <sup>*4</sup>		✓	Page 88
	HTTP Authentication	Authentication ID	✓	✓	Page 88
		Authentication Password	✓	✓	Page 89
	Proxy Server Settings	Enable Proxy		✓	Page 89
		Proxy Server Address		✓	Page 89
		Proxy Server Port		✓	Page 89
Global Address Detection	Global Address Detection	Detection Method		✓	Page 90
		Detection Interval		✓	Page 90
	STUN Server	STUN Server Address <sup>*4</sup>		✓	Page 90
		STUN Server Port <sup>*4</sup>		✓	Page 91
Static NAPT Settings	Global IP Address	Global IP Address		✓	Page 91
	Enable Global IP Address Usage per Line	Line 1–Line x		✓	Page 92
	External RTP Port	Channel 1–25		✓	Page 92
Application Settings	Application Settings	Application Port <sup>*4</sup>		✓	Page 93
		Enable Application <sup>*4</sup>		✓	Page 93
	Application Authentication	Authentication ID <sup>*4</sup>		✓	Page 93
		Authentication Password <sup>*4</sup>		✓	Page 94

<sup>\*1</sup> The access levels are abbreviated as follows:

U: User; A: Administrator

A check mark indicates that the setting is available for that access level.

<sup>\*2</sup> This setting can also be configured through other programming methods (phone user interface programming or configuration file programming).<sup>\*3</sup> If your phone system dealer does not allow you these settings, you cannot change them even though the unit shows the setting menu. Contact your phone system dealer for further information.<sup>\*4</sup> This setting can also be configured through configuration file programming.<sup>\*5</sup> This setting can also be configured through phone user interface programming.

## System

Menu Item	Section Title	Setting	Access Level <sup>*1</sup>		Ref.
			U	A	
Web Language	Web Language	Language	✓	✓	Page 94

## 4.1 Web User Interface Setting List

Menu Item	Section Title	Setting	Access Level <sup>*1</sup>		Ref.
			U	A	
Administrator Password	Change Administrator Password	Current Password		✓	Page 95
		New Password <sup>*2</sup>		✓	Page 95
		Confirm New Password <sup>*2</sup>		✓	Page 96
Change User Password	Change User Password	Current Password	✓	✓	Page 96
		New Password <sup>*2</sup>	✓	✓	Page 97
		Confirm New Password <sup>*2</sup>	✓	✓	Page 97
Web Server Settings	Web Server Settings	Web Server Port		✓	Page 98
		Port Close Timer		✓	Page 98
Time Adjust Settings	Synchronization	Enable Synchronization by NTP	✓ <sup>*3</sup>	✓	Page 99
		Synchronization Interval <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 99
	Time Server	NTP Server Address <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 100
	Time Zone	Time Zone <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 100
	Daylight Saving Time (Summer Time)	Enable DST (Enable Summer Time) <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 100
		DST Offset (Summer Time Offset) <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 100
	Start Day and Time of DST (Start Day and Time of Summer Time)	Month <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 101
		Day of Week <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 101
		Time <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 102
	End Day and Time of DST (End Day and Time of Summer Time)	Month <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 102
		Day of Week <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 102
		Time <sup>*2</sup>	✓ <sup>*3</sup>	✓	Page 103

<sup>\*1</sup> The access levels are abbreviated as follows:

U: User; A: Administrator

A check mark indicates that the setting is available for that access level.

<sup>\*2</sup> This setting can also be configured through configuration file programming.

<sup>\*3</sup> If your phone system dealer does not allow you these settings, you cannot change them even though the unit shows the setting menu. Contact your phone system dealer for further information.

## VoIP

Menu Item	Section Title	Setting	Access Level <sup>*1</sup>		Ref.
			U	A	
SIP Settings	SIP Setting	SIP User Agent <sup>*2</sup>		✓	Page 104
SIP Settings [Line 1]–[Line x]	Phone Number	Phone Number <sup>*2</sup>		✓	Page 105
		SIP URI <sup>*2</sup>		✓	Page 106
	SIP Server	Registrar Server Address <sup>*2</sup>		✓	Page 106
		Registrar Server Port <sup>*2</sup>		✓	Page 106
		Proxy Server Address <sup>*2</sup>		✓	Page 106
		Proxy Server Port <sup>*2</sup>		✓	Page 107
		Presence Server Address <sup>*2</sup>		✓	Page 107
		Presence Server Port <sup>*2</sup>		✓	Page 107
	Outbound Proxy Server	Outbound Proxy Server Address <sup>*2</sup>		✓	Page 107
		Outbound Proxy Server Port <sup>*2</sup>		✓	Page 107
	SIP Service Domain	Service Domain <sup>*2</sup>		✓	Page 108
	SIP Source Port	Source Port <sup>*2</sup>		✓	Page 108
	SIP Authentication	Authentication ID <sup>*2</sup>		✓	Page 108
		Authentication Password <sup>*2</sup>		✓	Page 109
	DNS	Enable DNS SRV lookup <sup>*2</sup>		✓	Page 109
		SRV lookup Prefix for UDP <sup>*2</sup>		✓	Page 109
		SRV lookup Prefix for TCP <sup>*2</sup>		✓	Page 110
	Transport Protocol of SIP	Transport Protocol <sup>*2</sup>		✓	Page 110
	Timer Settings	T1 Timer <sup>*2</sup>		✓	Page 110
		T2 Timer <sup>*2</sup>		✓	Page 110
		Timer B <sup>*2</sup>		✓	Page 111
		Timer D <sup>*2</sup>		✓	Page 111
		Timer F <sup>*2</sup>		✓	Page 111
		Timer H <sup>*2</sup>		✓	Page 111
		Timer J <sup>*2</sup>		✓	Page 112
	Quality of Service (QoS)	SIP Packet QoS (DSCP) <sup>*2</sup>		✓	Page 112

## 4.1 Web User Interface Setting List

Menu Item	Section Title	Setting	Access Level <sup>*1</sup>		Ref.
			U	A	
	SIP extensions	Supports 100rel (RFC 3262) <sup>*2</sup>		✓	Page 112
		Supports Session Timer (RFC 4028) <sup>*2</sup>		✓	Page 112
	NAT Identity	Keep Alive Interval <sup>*2</sup>		✓	Page 113
		Supports Rport (RFC 3581) <sup>*2</sup>		✓	Page 113
	Security	Enable SSAF (SIP Source Address Filter) <sup>*2</sup>		✓	Page 113
VoIP Settings	RTP Settings	RTP Packet Time <sup>*2</sup>		✓	Page 114
		Minimum RTP Port Number <sup>*2</sup>		✓	Page 114
		Maximum RTP Port Number <sup>*2</sup>		✓	Page 115
		Telephone-event Payload Type <sup>*2</sup>		✓	Page 115
VoIP Settings [Line 1]–[Line x]	Quality of Service (QoS)	RTP Packet QoS (DSCP) <sup>*2</sup>		✓	Page 116
		RTCP Packet QoS (DSCP) <sup>*2</sup>		✓	Page 116
	Statistical Information	RTCP Enable <sup>*2</sup>		✓	Page 117
		RTCP Interval <sup>*2</sup>		✓	Page 117
	Jitter Buffer	Maximum Delay <sup>*2</sup>		✓	Page 117
		Minimum Delay <sup>*2</sup>		✓	Page 117
		Initial Delay <sup>*2</sup>		✓	Page 118
	DTMF	DTMF Type <sup>*2</sup>		✓	Page 118
		DTMF Relay <sup>*2</sup>		✓	Page 118
	Call Hold	Supports RFC 2543 (c=0.0.0.0) <sup>*2</sup>		✓	Page 119

Menu Item	Section Title	Setting	Access Level <sup>*1</sup>		Ref.
			U	A	
	CODEC Preferences	G722	—	—	—
		Enable <sup>*2</sup>		✓	Page 119
		Priority <sup>*2</sup>		✓	Page 119
		PCMA	—	—	—
		Enable <sup>*2</sup>		✓	Page 120
		Priority <sup>*2</sup>		✓	Page 120
		G726-32	—	—	—
		Enable <sup>*2</sup>		✓	Page 120
		Priority <sup>*2</sup>		✓	Page 120
		G729A	—	—	—
		Enable <sup>*2</sup>		✓	Page 120
		Priority <sup>*2</sup>		✓	Page 121
		PCMU	—	—	—
		Enable <sup>*2</sup>		✓	Page 121
		Priority <sup>*2</sup>		✓	Page 121

<sup>\*1</sup> The access levels are abbreviated as follows:

U: User; A: Administrator

A check mark indicates that the setting is available for that access level.

<sup>\*2</sup> This setting can also be configured through configuration file programming.

## Telephone

Menu Item	Section Title	Setting	Access Level <sup>1</sup>		Ref.
			U	A	
Call Control	Call Control	Send SUBSCRIBE to Voice Mail Server <sup>2</sup>		✓	Page 122
		Conference Server URI <sup>2</sup>		✓	Page 123
		Inter-digit Timeout <sup>2</sup>		✓	Page 123
		Timer for Dial Plan <sup>2</sup>		✓	Page 123
		International Call Prefix <sup>2</sup>		✓	Page 123
		Country Calling Code <sup>2</sup>		✓	Page 124
		National Access Code <sup>2</sup>		✓	Page 124
		Default Line for Outgoing <sup>2</sup>	✓	✓	Page 124
		Flash/Recall Button <sup>2</sup>		✓	Page 124
		Flash Hook Event <sup>2</sup>		✓	Page 125
	Call Rejection Phone Numbers	1–30	✓	✓	Page 125

<b>Menu Item</b>	<b>Section Title</b>	<b>Setting</b>	<b>Access Level<sup>*1</sup></b>		<b>Ref.</b>
			<b>U</b>	<b>A</b>	
Call Control [Line 1]–[Line x]	Call Control	Display Name <sup>*2</sup>	✓	✓	Page 126
		Voice Mail Access Number <sup>*2</sup>		✓	Page 126
		Enable Shared Call <sup>*2</sup>		✓	Page 127
		Synchronize Do Not Disturb and Call Forward <sup>*2</sup>		✓	Page 127
		Resource List URI <sup>*2</sup>		✓	Page 128
	Dial Plan	Dial Plan (max 1000 columns) <sup>*2</sup>		✓	Page 128
		Call Even If Dial Plan Does Not Match <sup>*2</sup>		✓	Page 128
	Call Features	Block Caller ID	✓	✓	Page 129
		Block Anonymous Call	✓	✓	Page 129
		Do Not Disturb	✓	✓	Page 130
	Call Forward	Unconditional	—	—	—
		Enable Call Forward	✓	✓	Page 130
		Phone Number	✓	✓	Page 131
		Busy	—	—	—
		Enable Call Forward	✓	✓	Page 131
		Phone Number	✓	✓	Page 132
		No Answer	—	—	—
		Enable Call Forward	✓	✓	Page 132
		Phone Number	✓	✓	Page 133
		Ring Count	✓	✓	Page 133
Flexible Button Settings (KX-UT133/ KX-UT136/ KX-UT248 only)	Flexible Button Settings	Type (No. 1–24) <sup>*2</sup>	✓	✓	Page 134
		Parameter (No. 1–24) <sup>*2</sup>	✓	✓	Page 134
		Label Name (No. 1–24) <sup>*2</sup>	✓	✓	Page 135

## 4.1 Web User Interface Setting List

Menu Item	Section Title	Setting	Access Level <sup>*1</sup>		Ref.
			U	A	
Tone Settings	Dial Tone	Tone Frequencies <sup>*2</sup>		✓	Page 135
		Tone Timings <sup>*2</sup>		✓	Page 136
	Busy Tone	Tone Frequencies <sup>*2</sup>		✓	Page 136
		Tone Timings <sup>*2</sup>		✓	Page 137
	Ringing Tone	Tone Frequencies <sup>*2</sup>		✓	Page 137
		Tone Timings <sup>*2</sup>		✓	Page 137
	Stutter Tone	Tone Frequencies <sup>*2</sup>		✓	Page 138
		Tone Timings <sup>*2</sup>		✓	Page 138
	Reorder Tone	Tone Frequencies <sup>*2</sup>		✓	Page 138
		Tone Timings <sup>*2</sup>		✓	Page 139
Telephone Settings	Telephone Settings	Key Click Tone <sup>*2</sup>	✓	✓	Page 139
		Extension PIN <sup>*2</sup>	✓	✓	Page 140
		Number Matching Lower Digit <sup>*2</sup>		✓	Page 140
		Number Matching Upper Digit <sup>*2</sup>		✓	Page 140
Import Phonebook	Import Phonebook	File Name	✓	✓	Page 141
Export Phonebook	Export Phonebook	—	✓	✓	Page 141
Application Settings	Application Bootup URL	URL <sup>*2</sup>		✓	Page 142
	Application initial URL	URL <sup>*2</sup>		✓	Page 143
	Incoming call URL	URL <sup>*2</sup>		✓	Page 143
	Talking URL	URL <sup>*2</sup>		✓	Page 143
	Making call URL	URL <sup>*2</sup>		✓	Page 143
	Call log URL	URL <sup>*2</sup>		✓	Page 144
	Idling URL	URL <sup>*2</sup>		✓	Page 144
	Network Phone Book URL	URL <sup>*2</sup>		✓	Page 144
	Network Phone Book URL Authentication	Authentication ID <sup>*2</sup>		✓	Page 144
		Authentication Password <sup>*2</sup>		✓	Page 145

<sup>\*1</sup> The access levels are abbreviated as follows:

U: User; A: Administrator

A check mark indicates that the setting is available for that access level.

<sup>\*2</sup> This setting can also be configured through configuration file programming.

## Maintenance

Menu Item	Section Title	Setting	Access Level <sup>*1</sup>		Ref.
			U	A	
Firmware Maintenance	Firmware Maintenance	Enable Firmware Update <sup>*2</sup>		✓	Page 145
		Update Type <sup>*2</sup>		✓	Page 146
		Firmware File URL <sup>*2</sup>		✓	Page 146
Local Firmware Update	Local Firmware Update	Encryption		✓	Page 147
		File Name		✓	Page 147
Provisioning Maintenance	Provisioning Maintenance	Enable Provisioning <sup>*2</sup>		✓	Page 148
		Standard File URL <sup>*2</sup>		✓	Page 148
		Product File URL <sup>*2</sup>		✓	Page 149
		Master File URL <sup>*2</sup>		✓	Page 149
		Cyclic Auto Resync <sup>*2</sup>		✓	Page 149
		Resync Interval <sup>*2</sup>		✓	Page 150
		Header Value for Resync Event <sup>*2</sup>		✓	Page 150
Management Server	Management Server	Management Server URL <sup>*2</sup>		✓	Page 151
	Management Server Authentication	Authentication ID <sup>*2</sup>		✓	Page 151
		Authentication Password <sup>*2</sup>		✓	Page 151
Reset to Defaults	Reset Web Data	—		✓	Page 151
Restart	Restart	—		✓	Page 152

<sup>\*1</sup> The access levels are abbreviated as follows:

U: User; A: Administrator

A check mark indicates that the setting is available for that access level.

<sup>\*2</sup> This setting can also be configured through configuration file programming.

## 4.2 Status

This section provides detailed descriptions about all the settings classified under the **[Status]** tab.

#### 4.2.1 Version Information

---

## 4.2.1 Version Information

This screen allows you to view the current version information such as the model number and the firmware version of the unit.

The screenshot shows the Panasonic KX-UT136 web interface. The top navigation bar includes links for Status, Network, System, VoIP, Telephone, and Maintenance. The 'Status' tab is currently selected. On the left, there's a sidebar with 'Web Port Close' and three status sections: 'Status' (with 'Version Information' highlighted in red), 'Network Status', and 'VoIP Status'. The main content area is titled 'Version Information' and displays the following table:

Version Information	
Model	KX-UT13X
Operating Bank	Bank1
IPL Version	01.14
Firmware Version	Bank1: 00.045 Bank2: 00.021

### 4.2.1.1 Version Information

#### Model

Description	Indicates the model number of the unit (reference only).
Value Range	Model number
Default Value	Current model number

#### Operating Bank

Description	Indicates the storage area of the firmware that is currently operating (reference only).
Value Range	<ul style="list-style-type: none"><li>• Bank1</li><li>• Bank2</li></ul>
Default Value	Not applicable.

#### IPL Version

Description	Indicates the version of the IPL (Initial Program Load) that runs when starting the unit (reference only).
Value Range	IPL version ("nn.nn" [n=0–9])
Default Value	Current IPL version

#### Firmware Version

Description	Indicates the version of the firmware that is currently installed on the unit (reference only).
Value Range	Bank1 (Bank2): Firmware version ("nn.nnn" [n=0–9])

<b>Default Value</b>	Current firmware version
----------------------	--------------------------

## 4.2.2 Network Status

This screen allows you to view the current network information of the unit, such as the MAC address, IP address, Ethernet port status, etc.

Clicking [Refresh] updates the information displayed on the screen.

Network Status	
MAC Address	0080F0ABCDEF
Ethernet Link Status (LAN Port)	Connected
Ethernet Link Status (PC Port)	Connected
Connection Mode	DHCP
IP Address	192.168.0.111
Subnet Mask	255.255.255.0
Default Gateway	192.168.0.254
DNS1	192.168.0.254
DNS2	
IEEE802.1X Status	Disabled

### 4.2.2.1 Network Status

#### MAC Address

<b>Description</b>	Indicates the MAC address of the unit (reference only).
<b>Value Range</b>	Not applicable.
<b>Default Value</b>	Default MAC address (example: 0080F0ABCDEF)

#### Ethernet Link Status (LAN Port)

<b>Description</b>	Indicates the current connection status of the Ethernet LAN port (reference only).
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Connected</li> <li>• Not connected</li> </ul>
<b>Default Value</b>	Not applicable.

#### Ethernet Link Status (PC Port) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only)

<b>Description</b>	Indicates the current connection status of the Ethernet PC port (reference only).
--------------------	---

#### 4.2.2 Network Status

---

<b>Value Range</b>	<ul style="list-style-type: none"><li>Connected</li><li>Not connected</li></ul>
<b>Default Value</b>	Not applicable.

### Connection Mode

---

<b>Description</b>	Indicates whether the IP address of the unit is assigned automatically (DHCP) or manually (static) (reference only).
<b>Value Range</b>	<ul style="list-style-type: none"><li>DHCP</li><li>Static</li></ul>
<b>Default Value</b>	Not applicable.

### IP Address

---

<b>Description</b>	Indicates the currently assigned IP address of the unit (reference only).
<b>Value Range</b>	IP address
<b>Default Value</b>	Current IP address

### Subnet Mask

---

<b>Description</b>	Indicates the specified subnet mask for the unit (reference only).
<b>Value Range</b>	Subnet mask
<b>Default Value</b>	Current subnet mask

### Default Gateway

---

<b>Description</b>	Indicates the specified IP address of the default gateway for the network (reference only).  <b>Note</b> <ul style="list-style-type: none"><li>If the default gateway address is not specified, this field will be left blank.</li></ul>
<b>Value Range</b>	IP address of the default gateway
<b>Default Value</b>	Not applicable.

## DNS1

<b>Description</b>	Indicates the specified IP address of the primary DNS server (reference only).
<b>Note</b>	<ul style="list-style-type: none"> <li>If the primary DNS server address is not specified, this field will be left blank.</li> </ul>
<b>Value Range</b>	IP address of the primary DNS server
<b>Default Value</b>	Not applicable.

## DNS2

<b>Description</b>	Indicates the specified IP address of the secondary DNS server (reference only).
<b>Note</b>	<ul style="list-style-type: none"> <li>If the secondary DNS server address is not specified, this field will be left blank.</li> </ul>
<b>Value Range</b>	IP address of the secondary DNS server
<b>Default Value</b>	Not applicable.

## IEEE802.1X Status (KX-UT248 only)

<b>Description</b>	Indicates the current status of IEEE 802.1X settings.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Authenticating</li> <li>Authenticated</li> <li>Authenticated In Condition</li> <li>Failed (Time Out)</li> <li>Failed</li> <li>Not Connected</li> <li>Disabled</li> </ul>
<b>Default Value</b>	Not applicable.

## 4.2.3 VoIP Status

This screen allows you to view the current VoIP status of each line's unit.

#### 4.2.3 VoIP Status

Clicking [Refresh] updates the information displayed on the screen.

Line No.	Phone Number	VoIP Status
1	6039	Registered
2	6040	Registering
3		
4		

##### 4.2.3.1 VoIP Status

###### Line No.

<b>Description</b>	Indicates the line number to which a phone number is assigned (reference only).
<b>Note</b>	<ul style="list-style-type: none"><li>The available line number varies depending on the type of the unit being used.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>Line 1–Line 2 (for KX-UT113/KX-UT123)</li><li>Line 1–Line 4 (for KX-UT133/KX-UT136)</li><li>Line 1–Line 6 (for KX-UT248)</li></ul>
<b>Default Value</b>	Not applicable.

###### Phone Number

<b>Description</b>	Indicates the currently assigned phone numbers (reference only).
<b>Note</b>	<ul style="list-style-type: none"><li>The corresponding field is blank if a line has not yet been leased or if the unit has not been configured.</li></ul>
<b>Value Range</b>	Max. 32 digits
<b>Default Value</b>	Not applicable.

###### VoIP Status

<b>Description</b>	Indicates the current VoIP status of each line (reference only).
--------------------	--

<b>Value Range</b>	<ul style="list-style-type: none"> <li>Registered: The unit has been registered to the SIP server, and the line can be used.</li> <li>Registering: The unit is being registered to the SIP server, and the line cannot be used.</li> <li>Blank: The line has not been leased, the unit has not been configured yet, or a SIP authentication failure has occurred.</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>Immediately after starting up the unit, the phone numbers of the lines will be displayed, but the status of the line may not be displayed because the unit is still being registered to the SIP server. To display the status, wait about 30 to 60 seconds, and then click <b>[Refresh]</b> to obtain updated status information.</li> </ul>
<b>Default Value</b>	Not applicable.

## 4.3 Network

This section provides detailed descriptions about all the settings classified under the **[Network]** tab.

### 4.3.1 Basic Network Settings

This screen allows you to change basic network settings such as whether to use a DHCP server, and the IP address of the unit.

**Note**

- Changes to the settings on this screen are applied when the message "Complete" appears after clicking **[Save]**. Because the IP address of the unit will probably be changed if you change these settings, you will not be able to continue using the Web user interface. To continue configuring the unit from the Web user interface, log in to the Web user interface again after confirming the newly assigned IP address of the unit using the phone user interface. In addition, if the IP address of the PC from which you try to access the Web user interface has been changed, close the Web port once by selecting "off" for

#### 4.3.1 Basic Network Settings

"Embedded web" on the unit (→ see **Opening/Closing the Web Port** in **1.1.6.3 Before Accessing the Web User Interface**).

The screenshot shows the 'Basic Network Settings' page of the Panasonic KX-UT136 web interface. The 'Network' tab is active. In the 'Connection Mode' section, 'DHCP' is selected. In the 'DHCP Settings' section, the 'Host Name' field contains '(MODEL)'. Under 'Static Settings', the 'Static IP Address' is 192.168.0.123, 'Subnet Mask' is 255.255.255.0, 'Default Gateway' is 192.168.0.10, and 'DNS1' and 'DNS2' fields are empty. At the bottom are 'Save' and 'Cancel' buttons.

##### 4.3.1.1 Connection Mode

###### Connection Mode

<b>Description</b>	Selects whether to assign the IP address automatically (DHCP) or manually (static).
<b>Value Range</b>	<ul style="list-style-type: none"><li>DHCP</li><li>Static</li></ul>
<b>Default Value</b>	DHCP
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Configuration File Reference</b>	CONNECTION_TYPE (Page 189)

##### 4.3.1.2 DHCP Settings

###### Host Name

<b>Description</b>	Specifies the host name for the unit to send to the DHCP server.
<b>Note</b>	<ul style="list-style-type: none"><li>This setting is available only when <b>[Connection Mode]</b> is set to <b>[DHCP]</b>.</li></ul>

<b>Value Range</b>	Max. 63 characters  <b>Note</b> <ul style="list-style-type: none"><li>• You cannot leave this field empty.</li><li>• If "{MODEL}" is included in this parameter, it will be replaced with the unit's model name.</li></ul>
<b>Default Value</b>	{MODEL}
<b>Configuration File Reference</b>	HOST_NAME (Page 190)

## Domain Name Server

<b>Description</b>	Selects whether to receive DNS server addresses automatically or to assign a DNS server addresses (up to 2) manually.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when [Connection Mode] is set to [DHCP].</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Receive DNS server address automatically</li> <li>• Use the following settings <ul style="list-style-type: none"> <li>– DNS1</li> <li>– DNS2</li> </ul> </li> </ul> <b>Note</b> <ul style="list-style-type: none"> <li>• If you select [Use the following settings], specify the IP address(es) of the primary and, if necessary, secondary DNS server(s) manually. The permissible values are: Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)</li> </ul>
<b>Default Value</b>	Receive DNS server address automatically
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Configuration File Reference</b>	DHCP_DNS_ENABLE (Page 190)

### 4.3.1.3 Static Settings

#### Static IP Address

<b>Description</b>	Specifies the IP address for the unit.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when [Connection Mode] is set to [Static].</li></ul>
<b>Value Range</b>	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
<b>Default Value</b>	Not stored.

#### 4.3.1 Basic Network Settings

---

<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Configuration File Reference</b>	STATIC_IP_ADDRESS (Page 190)

## Subnet Mask

---

<b>Description</b>	Specifies the subnet mask for the unit.
<b>Note</b>	<ul style="list-style-type: none"><li>This setting is available only when <b>[Connection Mode]</b> is set to <b>[Static]</b>.</li></ul>
<b>Value Range</b>	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
<b>Default Value</b>	Not stored.
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Configuration File Reference</b>	STATIC_SUBNET (Page 191)

## Default Gateway

---

<b>Description</b>	Specifies the IP address of the default gateway for the network where the unit is connected.
<b>Note</b>	<ul style="list-style-type: none"><li>This setting is available only when <b>[Connection Mode]</b> is set to <b>[Static]</b>.</li></ul>
<b>Value Range</b>	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
<b>Default Value</b>	Not stored.
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Configuration File Reference</b>	STATIC_GATEWAY (Page 191)

## DNS1

---

<b>Description</b>	Specifies the IP address of the primary DNS server.
<b>Note</b>	<ul style="list-style-type: none"><li>This setting is available only when <b>[Connection Mode]</b> is set to <b>[Static]</b>.</li></ul>
<b>Value Range</b>	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
<b>Default Value</b>	Not stored.

<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Configuration File Reference</b>	USER_DNS1_ADDR (Page 192)

## DNS2

<b>Description</b>	Specifies the IP address of the secondary DNS server.
<b>Note</b>	<ul style="list-style-type: none"> <li>This setting is available only when <b>[Connection Mode]</b> is set to <b>[Static]</b>.</li> </ul>
<b>Value Range</b>	Max. 15 characters ("n.n.n.n" [n=0–255], except "0.0.0.0", "255.255.255.255", "127.0.0.1", etc.)
<b>Default Value</b>	Not stored.
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Configuration File Reference</b>	USER_DNS2_ADDR (Page 192)

## 4.3.2 Ethernet Port Settings

This screen allows you to change the connection mode of the Ethernet ports and the VLAN settings.

### Note

- When you change the settings on this screen and click **[Save]**, after the message "Complete" has been displayed, the unit will restart automatically with the new settings applied. If a unit is on a call when "Complete" has been displayed, the unit will restart after the unit returns to idle.
- Incorrect settings may cause a network failure. In such a case, you cannot access the Web user interface anymore. To access it again, you need to correct the speed/duplex settings or perform IP

#### 4.3.2 Ethernet Port Settings

Reset through phone user interface programming. For details, refer to the Operating Instructions on the Panasonic Web site (→ see **Introduction**).

Panasonic

KX-UT248

Status Network System VoIP Telephone Maintenance

Web Port Close

Network

Basic Network Settings

Ethernet Port Settings

IEEE802.1X Settings

HTTP Client Settings

VPN Settings

Global Address Detection

Static IAP/PT Settings

**Ethernet Port Settings**

**Link Speed/Duplex Mode**

LAN Port	Auto Negotiation
PC Port	Auto Negotiation

**LLDP Settings**

LLDP	<input checked="" type="radio"/> Yes <input type="radio"/> No	
LLDP-MED Timer	30 [1-3600]	
IP Phone	VLAN ID Priority	2 7
PC	VLAN ID Priority	0 [0-4094] 0

**VLAN Settings**

Enable VLAN	<input type="radio"/> Yes <input checked="" type="radio"/> No	
IP Phone	VLAN ID Priority	2 [1-4094] 7
PC	VLAN ID Priority	1 [1-4094] 0

The phone reboots automatically if you change the settings on this screen.

Save Cancel

##### 4.3.2.1 Link Speed/Duplex Mode

###### LAN Port

Description	Selects the connection mode (link speed and duplex mode) of the LAN port.
Value Range	<ul style="list-style-type: none"><li>Auto Negotiation</li><li>100 Mbps/Full Duplex</li><li>100 Mbps/Half Duplex</li><li>10 Mbps/Full Duplex</li><li>10 Mbps/Half Duplex</li></ul> <p><b>Note</b></p> <ul style="list-style-type: none"><li>The KX-UT248 supports Gigabit Ethernet. When connecting to a network that supports Gigabit Ethernet, select <b>[Auto Negotiation]</b>.</li></ul>
Default Value	Auto Negotiation

###### PC Port (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only)

Description	Selects the connection mode (link speed and duplex mode) of the PC port.
-------------	--

<b>Value Range</b>	<ul style="list-style-type: none"> <li>Auto Negotiation</li> <li>100 Mbps/Full Duplex</li> <li>100 Mbps/Half Duplex</li> <li>10 Mbps/Full Duplex</li> <li>10 Mbps/Half Duplex</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>The KX-UT248 supports Gigabit Ethernet. When connecting to a network that supports Gigabit Ethernet, select <b>[Auto Negotiation]</b>.</li> </ul>
<b>Default Value</b>	Auto Negotiation

### 4.3.2.2 LLDP Settings

#### Enable LLDP

<b>Description</b>	Selects whether to enable or disable sending and receiving LLDP frames.
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>Y</b> (Enable)</li> <li><b>N</b> (Disable)</li> </ul>
<b>Default Value</b>	Y
<b>Configuration File Reference</b>	LLDP_ENABLE (Page 201)

#### LLDP-MED Interval timer

<b>Description</b>	Specifies the interval, in seconds, between sending each LLDP frame.
<b>Value Range</b>	1–3600
<b>Default Value</b>	30
<b>Configuration File Reference</b>	LLDP_INTERVAL (Page 202)

#### IP Phone (VLAN ID)

<b>Description</b>	Indicates the VLAN ID of the phone using LLDP (reference only).
<b>Value Range</b>	1–4094
<b>Default Value</b>	Not applicable.

#### IP Phone (Priority)

<b>Description</b>	Indicates the priority value of the phone using LLDP (reference only).
<b>Value Range</b>	0–7

#### 4.3.2 Ethernet Port Settings

---

<b>Default Value</b>	Not applicable.
----------------------	-----------------

#### PC (VLAN ID) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only)

---

<b>Description</b>	Specifies the VLAN ID of the PC when the LLDP feature is enabled.
<b>Value Range</b>	0–4094
<b>Default Value</b>	0
<b>Configuration File Reference</b>	LLDP_VLAN_ID_PC (Page 202)

#### PC (Priority) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only)

---

<b>Description</b>	Specifies the priority number of the PC when the LLDP feature is enabled.
<b>Value Range</b>	0–7
<b>Default Value</b>	0
<b>Configuration File Reference</b>	LLDP_VLAN_PRI_PC (Page 202)

### 4.3.2.3 VLAN Settings

#### Enable VLAN

---

<b>Description</b>	Selects whether to use the VLAN feature to perform VoIP communication securely.
<b>Note</b>	<ul style="list-style-type: none"><li>You cannot set this parameter if [Enable IEEE802.1X] is set to [Yes] (KX-UT248 only).</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>Yes</li><li>No</li></ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	VLAN_ENABLE (Page 194)

#### IP Phone (VLAN ID)

---

<b>Description</b>	Specifies the VLAN ID for this unit.
<b>Note</b>	<ul style="list-style-type: none"><li>You cannot set this parameter if [Enable IEEE802.1X] is set to [Yes] (KX-UT248 only).</li></ul>
<b>Value Range</b>	1–4094
<b>Default Value</b>	2

<b>Configuration File Reference</b>	VLAN_ID_IP_PHONE (Page 194)
-------------------------------------	-----------------------------

## IP Phone (Priority)

<b>Description</b>	Selects the priority number for the unit.
<b>Note</b>	<ul style="list-style-type: none"> <li>You cannot set this parameter if [Enable IEEE802.1X] is set to [Yes] (KX-UT248 only).</li> </ul>
<b>Value Range</b>	0–7
<b>Default Value</b>	7
<b>Configuration File Reference</b>	VLAN_PRI_IP_PHONE (Page 194)

## PC (VLAN ID) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only)

<b>Description</b>	Specifies the VLAN ID for the PC.
<b>Note</b>	<ul style="list-style-type: none"> <li>You cannot set this parameter if [Enable IEEE802.1X] is set to [Yes] (KX-UT248 only).</li> </ul>
<b>Value Range</b>	1–4094
<b>Default Value</b>	1
<b>Configuration File Reference</b>	VLAN_ID_PC (Page 195)

## PC (Priority) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only)

<b>Description</b>	Selects the priority number for the PC.
<b>Note</b>	<ul style="list-style-type: none"> <li>You cannot set this parameter if [Enable IEEE802.1X] is set to [Yes] (KX-UT248 only).</li> </ul>
<b>Value Range</b>	0–7
<b>Default Value</b>	0
<b>Configuration File Reference</b>	VLAN_PRI_PC (Page 195)

#### 4.3.3 IEEE802.1X Settings (KX-UT248 only)

### 4.3.3 IEEE802.1X Settings (KX-UT248 only)

This screen allows you to configure settings relating to the IEEE 802.1X networking protocol.

Panasonic

KX-UT248 Status Network System VoIP Telephone Maintenance

Web Port Close

Network

Basic Network Settings  
Ethernet Port Settings  
**IEEE802.1X Settings**  
HTTP Client Settings  
Global Address Detection  
Static NAPT Settings  
Application Settings

IEEE802.1X Settings

Enable IEEE802.1X  Yes  No

IEEE802.1X Authentication

Authentication Protocol EAP-MD5  
Authentication ID  
Authentication Password

The phone reboots automatically if you modify this page's parameter.

Save Cancel

#### 4.3.3.1 IEEE802.1X Settings

##### Enable IEEE802.1X

Description	Selects whether to use the IEEE 802.1X protocol.  <b>Note</b> <ul style="list-style-type: none"><li>You cannot set this parameter if [<b>Enable VLAN</b>] is set to [<b>Yes</b>].</li></ul>
Value Range	<ul style="list-style-type: none"><li>Yes</li><li>No</li></ul>
Default Value	No
Configuration File Reference	IEEE8021X_ENABLE (Page 195)

#### 4.3.3.2 IEEE802.1X Authentication

##### Authentication Protocol

Description	Specifies the authentication method used with the IEEE 802.1X protocol.  <b>Note</b> <ul style="list-style-type: none"><li>You cannot set this parameter if [<b>Enable VLAN</b>] is set to [<b>Yes</b>].</li></ul>
Value Range	<ul style="list-style-type: none"><li>EAP-MD5</li><li>PEAP</li></ul>
Default Value	EAP-MD5
Configuration File Reference	IEEE8021X_AUTH_PRTCL (Page 196)

## Authentication ID

<b>Description</b>	Specifies the authentication ID required for IEEE 802.1X authentication.
<b>Note</b>	<ul style="list-style-type: none"> <li>You cannot set this parameter if [Enable VLAN] is set to [Yes].</li> </ul>
<b>Value Range</b>	Max. 127 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	IEEE8021X_USER_ID (Page 196)

## Authentication Password

<b>Description</b>	Specifies the authentication password used for IEEE 802.1X authentication.
<b>Note</b>	<ul style="list-style-type: none"> <li>You cannot set this parameter if [Enable VLAN] is set to [Yes].</li> </ul>
<b>Value Range</b>	Max. 127 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	IEEE8021X_USER_PASS (Page 196)

## 4.3.4 HTTP Client Settings

This screen allows you to change the HTTP client settings for the unit in order to access the HTTP server of your phone system and download configuration files.

Panasonic

KX-UT136

Status | **Network** | System | VoIP | Telephone | Maintenance

Web Port Close

Network

- Basic Network Settings
- Ethernet Port Settings
- HTTP Client Settings**
- Global Address Detection
- Static NAPT Settings
- Application Settings

**HTTP Client Settings**

HTTP Version	<input checked="" type="radio"/> HTTP/1.0 <input type="radio"/> HTTP/1.1
HTTP User Agent	Panasonic_{MODEL}/{fwver} ({mac})

**HTTP Authentication**

Authentication ID	
Authentication Password	

**Proxy Server Settings**

Enable Proxy	<input type="radio"/> Yes <input checked="" type="radio"/> No
Proxy Server Address	
Proxy Server Port	8080 [1-65535]

Save | Cancel

#### 4.3.4 HTTP Client Settings

---

##### 4.3.4.1 HTTP Client Settings

###### HTTP Version

<b>Description</b>	Selects which version of the HTTP protocol to use for HTTP communication.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• HTTP/1.0</li><li>• HTTP/1.1</li></ul> <p><b>Note</b></p> <ul style="list-style-type: none"><li>• For this unit, it is strongly recommended that you select <b>[HTTP/1.0]</b>. However, if the HTTP server does not function well with HTTP/1.0, try changing the setting <b>[HTTP/1.1]</b>.</li></ul>
<b>Default Value</b>	HTTP/1.0
<b>Configuration File Reference</b>	HTTP_VER (Page 197)

###### HTTP User Agent

<b>Description</b>	Specifies the text string to send as the user agent in the header of HTTP requests.
<b>Value Range</b>	Max. 40 characters
<b>Note</b>	<ul style="list-style-type: none"><li>• You cannot leave this field empty.</li><li>• If "{mac}" is included in this field, it will be replaced with the unit's MAC address in lower-case.</li><li>• If "{MAC}" is included in this field, it will be replaced with the unit's MAC address in upper-case.</li><li>• If "{MODEL}" is included in this field, it will be replaced with the unit's model name.</li><li>• If "{fwver}" is included in this field, it will be replaced with the firmware version of the unit.</li></ul>
<b>Default Value</b>	Panasonic_{MODEL}/{fwver} ({mac})
<b>Configuration File Reference</b>	HTTP_USER_AGENT (Page 197)

##### 4.3.4.2 HTTP Authentication

###### Authentication ID

<b>Description</b>	Specifies the ID for the User account. If set, this name must be entered to access the Web user interface at the User access level.
<b>Value Range</b>	Max. 127 characters
<b>Default Value</b>	Not stored.

## Authentication Password

<b>Description</b>	Specifies the password for the User account. If set, this password must be entered to access the Web user interface at the User access level.
<b>Value Range</b>	Max. 127 characters
<b>Default Value</b>	Not stored.

### 4.3.4.3 Proxy Server Settings

#### Enable Proxy

<b>Description</b>	Selects whether to use the proxy server.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
<b>Default Value</b>	No

#### Proxy Server Address

<b>Description</b>	Specifies the IP address or FQDN of the proxy server.
<b>Value Range</b>	Max. 127 characters
<b>Note</b>	<ul style="list-style-type: none"> <li>• You cannot leave this field empty if [Enable Proxy] is set to [Yes].</li> </ul>
<b>Default Value</b>	Not stored.

#### Proxy Server Port

<b>Description</b>	Specifies the port number of the proxy server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	8080


### 4.3.5 Global Address Detection

This screen allows you to configure the Global Address Detection feature and STUN server settings. The global IP address of the network the unit is connected to will be detected periodically. If the global IP address has changed, the new address will be registered to the SIP server.

#### 4.3.5 Global Address Detection

##### Note

- If the unit is connected directly to the Internet, or the network global address is static (i.e., does not change), you do not need to configure Global Address Detection.



##### 4.3.5.1 Global Address Detection

###### Detection Method

Description	Selects the method to use for detecting the global IP address.
Value Range	<ul style="list-style-type: none"><li>STUN</li><li>SIP</li></ul>
Default Value	STUN

###### Detection Interval

Description	Specifies the interval, in seconds, to wait between attempts to detect the global IP address.
Value Range	0, 10–65535 (0: Disable)
<b>Note</b>	<ul style="list-style-type: none"><li>When [Detection Method] is set to [SIP], the value "0" disables detection and a value other than "0" enables detection.</li></ul>

##### 4.3.5.2 STUN Server

###### STUN Server Address


Description	Specifies the IP address or FQDN of the STUN server.
Value Range	Max. 127 characters
Default Value	Not stored.
Configuration File Reference	STUN_SERV_ADDR (Page 200)

## STUN Server Port

<b>Description</b>	Specifies the port number of the STUN server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	3478
<b>Configuration File Reference</b>	STUN_SERV_PORT (Page 200)

## 4.3.6 Static NAPT Settings

This screen allows you to configure the NAPT (Network Address Port Translation) settings. If the unit is connected behind a router that uses NAT/NAPT to translate between private and global IP addresses, VoIP packets might be blocked by the router, depending on the SIP server. To avoid this problem, this setting is required. For details, see **1.1.7.2 NAT (Network Address Translation) Setup**.



Panasonic

KX-UT136

Status Network System | VoIP | Telephone | Maintenance

Web Port Close

**Static NAPT Settings**

**Global IP Address**

Global IP Address [Null: Disable]

Even if you enter a value for this setting, if "Global Address Detection" is enabled, the detected global IP address will be used.

**Enable Global IP Address Usage per Line**

Line 1	<input type="radio"/> Yes <input checked="" type="radio"/> No
Line 2	<input type="radio"/> Yes <input checked="" type="radio"/> No
Line 3	<input type="radio"/> Yes <input checked="" type="radio"/> No
Line 4	<input type="radio"/> Yes <input checked="" type="radio"/> No

**External RTP Port**

Channel 1-25	0 0 0 0 0	0 0 0 0 0	0 0 0 0 0	0 0 0 0 0	0 0 0 0 0
--------------	-----------	-----------	-----------	-----------	-----------

[1024-49150: Even Number Only, 0: Disable]

Set a value for all fields, or set all fields to 0 (disable).

Save Cancel

### 4.3.6.1 Global IP Address

#### Global IP Address

<b>Description</b>	Specifies the global IP address of your network.
<b>Note</b>	<ul style="list-style-type: none"> <li>You must enter a value in this field if at least 1 of <b>[Line 1]–[Line x]</b> is set to <b>[Yes]</b>, or when port numbers are specified in <b>[Channel 1–25]</b>.</li> <li>The available line number and the channel number vary depending on the type of the unit being used.</li> <li>The global IP address will reflect SIP messages and RTP packets.</li> </ul>

#### 4.3.6 Static NAPT Settings

<b>Value Range</b>	IP address in dotted-decimal notation ("n.n.n.n" [n=0–255]) (Max. 15 digits)
<b>Default Value</b>	Not stored.

#### 4.3.6.2 Enable Global IP Address Usage per Line

##### Line 1–Line x

<b>Description</b>	Selects whether to enable the NAT Traversal feature for each line.
<b>Note</b>	<ul style="list-style-type: none"><li>• The number of lines available varies depending on the phone being used, as follows:<ul style="list-style-type: none"><li>– KX-UT113/KX-UT123: 1–2</li><li>– KX-UT133/KX-UT136: 1–4</li><li>– KX-UT248: 1–6</li></ul></li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>• Yes</li><li>• No</li></ul>
<b>Default Value</b>	No

#### 4.3.6.3 External RTP Port

##### Channel 1–25

<b>Description</b>	Specifies the external RTP port number used for voice communication for each channel.
<b>Note</b>	<ul style="list-style-type: none"><li>• The number of channels available varies depending on the phone being used, as follows:<ul style="list-style-type: none"><li>– KX-UT113/KX-UT123: 1–3</li><li>– KX-UT133/KX-UT136/KX-UT248: 1–25</li></ul></li></ul>
<b>Value Range</b>	0, 1024–49150 (0: Disable, even number only)
<b>Note</b>	<ul style="list-style-type: none"><li>• Each channel must be set to a unique port number, and all port numbers must be an even number.</li><li>• You cannot specify here the same port number as any of the port numbers specified for the individual lines in <b>[Source Port]</b> in 4.5.2.5 SIP Source Port. In addition, you cannot specify a port number that is 1 less than a port number specified in <b>[Source Port]</b> if the source port number is an odd number.</li><li>• All channels must be set to either enable or disable at the same time.</li></ul>
<b>Default Value</b>	0

## 4.3.7 Application Settings

This screen allows you to configure settings related to the XML application feature.

### 4.3.7.1 Application Settings

#### Application Port

<b>Description</b>	Specifies the port number for receiving XML application data.
<b>Value Range</b>	1–65535
<b>Default Value</b>	6666
<b>Configuration File Reference</b>	XML_HTTPD_PORT (Page 230)

#### Enable Application

<b>Description</b>	Selects whether to enable the XML application feature.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	XMLAPP_ENABLE (Page 225)

### 4.3.7.2 Application Authentication

#### Authentication ID

<b>Description</b>	Specifies the authentication ID required to access the XML application server.
<b>Value Range</b>	Max. 63 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_USERID (Page 225)

#### 4.4.1 Web Language

### Authentication Password

<b>Description</b>	Specifies the authentication password used to access the XML application server.
<b>Value Range</b>	Max. 63 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_USERPASS (Page 226)

## 4.4 System

This section provides detailed descriptions about all the settings classified under the [System] tab.

### 4.4.1 Web Language

This screen allows you to select the language used for the Web user interface. The language setting is only applicable when you log in to the Web user interface as User.

#### Note

- If you change the language while logged in to the Web user interface with the User account, the language will be changed after the message "Complete" is displayed. If you are logged in with the Administrator account, the language will be changed when a user logs in to the Web user interface as User.
- The language used for the Web user interface for the Administrator account is always English.
- The language used for the unit remains unchanged even if the language for the Web user interface is changed.



#### 4.4.1.1 Web Language

##### Language

<b>Description</b>	Selects the language used for the Web user interface.
--------------------	---

<b>Value Range</b>	<ul style="list-style-type: none"> <li>• English (US)</li> <li>• English (UK)</li> <li>• Deutsch</li> <li>• Français</li> <li>• Español</li> <li>• Italiano</li> <li>• Portugués</li> <li>• Русский</li> </ul>
<b>Default Value</b>	English (US)

## 4.4.2 Administrator Password

This screen allows you to change the password used to authenticate the Administrator account when logging in to the Web user interface.

### Note

- For security reasons, the characters entered for the password are masked by special characters, which differ depending on the Web browser.
- After you change the administrator password, the next time you access the Web user interface, the authentication dialog box appears. Two consecutive login failures will result in an error ("401 Unauthorized"). This restriction only applies the first time you attempt to log in after changing the password. In all other circumstances, an error occurs after 3 unsuccessful login attempts.

### 4.4.2.1 Change Administrator Password

#### Current Password

<b>Description</b>	Specifies the current password to use to authenticate the Administrator account when logging in to the Web user interface.
<b>Value Range</b>	6–16 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	adminpass
<b>Configuration File Reference</b>	ADMIN_PASS (Page 167)

#### New Password

<b>Description</b>	Specifies the new password to use to authenticate the Administrator account when logging in to the Web user interface.
--------------------	--

#### 4.4.3 Change User Password

<b>Value Range</b>	6–16 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	ADMIN_PASS (Page 167)

### Confirm New Password

<b>Description</b>	Specifies the same password that you entered in <b>[New Password]</b> for confirmation.
<b>Value Range</b>	6–16 characters (except ", &, :, <, >, and space)
<b>Note</b>	<ul style="list-style-type: none"><li>This value must be the same as the value entered in <b>[New Password]</b>.</li></ul>
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	ADMIN_PASS (Page 167)

## 4.4.3 Change User Password

This screen allows you to change the password used to authenticate the User account when logging in to the Web user interface.

### Note

- For security reasons, the characters entered for the password are masked by special characters, which differ depending on the Web browser.
- After you change the user password, the next time you access the Web user interface, the authentication dialog box appears. Two consecutive login failures will result in an error ("401 Unauthorized"). This restriction only applies the first time you attempt to log in after changing the password. In all other circumstances, an error occurs after 3 unsuccessful login attempts.



### 4.4.3.1 Change User Password

#### Current Password

<b>Description</b>	Specifies the current password to use to authenticate the User account when logging in to the Web user interface.
<b>Value Range</b>	6–16 characters (except ", &, :, <, >, and space)

<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	USER_PASS (Page 168)

## New Password

<b>Description</b>	Specifies the new password to use to authenticate the User account when logging in to the Web user interface.
<b>Value Range</b>	6–16 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	<p>Not stored.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>When a user logs in to the Web user interface for the first time, after clicking <b>OK</b> on the authentication dialog box, the <b>[Change User Password]</b> screen is displayed automatically to make the user set a password.</li> </ul>
<b>Configuration File Reference</b>	USER_PASS (Page 168)

## Confirm New Password

<b>Description</b>	Specifies the same password that you entered in <b>[New Password]</b> for confirmation.
<b>Value Range</b>	6–16 characters (except ", &, :, <, >, and space)
<b>Note</b>	<ul style="list-style-type: none"> <li>This value must be the same as the value entered in <b>[New Password]</b>.</li> </ul>
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	USER_PASS (Page 168)

## 4.4.4 Web Server Settings

This screen allows you to change the Web server settings.

KX-UT136

Status | Network | **System** | VoIP | Telephone | Maintenance

**Web Server Settings**

**Web Server Settings**

Web Server Port	80	[80, 1024-49151]
Port Close Timer	30	minute(s) [1-1440]

Save | Cancel

#### 4.4.4.1 Web Server Settings

##### Web Server Port

<b>Description</b>	Specifies the port number used by the Web server.
<b>Value Range</b>	80, 1024–49151  <b>Note</b> <ul style="list-style-type: none"> <li>You cannot specify here the same port number as any of the port numbers specified for the individual lines in <b>[Source Port]</b> in 4.5.2.5 SIP Source Port.</li> </ul>
<b>Default Value</b>	80  <b>Note</b> <ul style="list-style-type: none"> <li>When you change the default value of the port number to a value other than "80", such as "8080", enter the URL for accessing the Web user interface using the following format: "http://192.168.0.100:8080/" (192.168.0.100: IP address of the unit)</li> </ul>

##### Port Close Timer

<b>Description</b>	Specifies the length of time, in minutes, to keep the Web port open when there has been no communication between the unit and the PC. If the specified length of time elapses without any communication, the Web port closes automatically. Communication is detected when you click a tab, menu item, the <b>[Save]</b> button, or by reloading the application or pressing the F5 key.
<b>Value Range</b>	1–1440
<b>Default Value</b>	30

## 4.4.5 Time Adjust Settings

This screen allows you to enable automatic clock adjustment using an NTP server and configure the settings for DST (Daylight Saving Time), also known as Summer Time.

**Panasonic**

KX-UT136 Status Network **System** VoIP Telephone Maintenance

Web Port Close

**System**

- Web Language
- Administrator Password
- Change User Password
- Web Server Settings
- Time Adjust Settings**

**Time Adjust Settings**

**Synchronization**

Enable Synchronization by NTP  Yes  No

Synchronization Interval 43200 seconds [10-86400]

**Time Server**

NTP Server Address [ ]

**Time Zone**

Time Zone GMT

**Daylight Saving Time**

Enable DST  Yes  No

DST Offset 60 minute(s) [0-720]

**Start Day and Time of DST**

Month March

Day of Week Second Sunday

Time 120 minute(s) [0-1439]

**End Day and Time of DST**

Month October

Day of Week Second Sunday

Time 120 minute(s) [0-1439]

Save Cancel

### 4.4.5.1 Synchronization

#### Enable Synchronization by NTP

<b>Description</b>	Selects whether to enable the unit to automatically adjust its clock according to the time information provided by an NTP server.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Even if you select [<b>Yes</b>], this feature will not function properly if the NTP server address setting is invalid.</li> </ul>
<b>Default Value</b>	Yes

#### Synchronization Interval

<b>Description</b>	Specifies the interval, in seconds, between synchronizations with the NTP server.
<b>Value Range</b>	10–86400
<b>Default Value</b>	43200

#### 4.4.5 Time Adjust Settings

---

Configuration File Reference	TIME_QUERY_INVL (Page 199)
------------------------------	----------------------------

#### 4.4.5.2 Time Server

##### NTP Server Address

Description	Specifies the IP address or FQDN of the NTP server.
Value Range	Max. 127 characters
Default Value	Not stored.
Configuration File Reference	NTP_ADDR (Page 199)

#### 4.4.5.3 Time Zone

##### Time Zone

Description	Selects your time zone.
Value Range	GMT -12:00–GMT +13:00
Default Value	GMT
Configuration File Reference	TIME_ZONE (Page 168)

#### 4.4.5.4 Daylight Saving Time (Summer Time)

##### Enable DST (Enable Summer Time)

Description	Selects whether to enable DST (Summer Time).
Value Range	<ul style="list-style-type: none"><li>• Yes</li><li>• No</li></ul>
Default Value	No
Configuration File Reference	DST_ENABLE (Page 169)

##### DST Offset (Summer Time Offset)

Description	Specifies the amount of time, in minutes, to change the time when [Enable DST (Enable Summer Time)] is set to [Yes].
Value Range	0–720
Default Value	60
Configuration File Reference	DST_OFFSET (Page 169)

## 4.4.5.5 Start Day and Time of DST (Start Day and Time of Summer Time) Month

<b>Description</b>	Selects the month in which DST (Summer Time) starts.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• January</li> <li>• February</li> <li>• March</li> <li>• April</li> <li>• May</li> <li>• June</li> <li>• July</li> <li>• August</li> <li>• September</li> <li>• October</li> <li>• November</li> <li>• December</li> </ul>
<b>Default Value</b>	March
<b>Configuration File Reference</b>	DST_START_MONTH (Page 170)

## Day of Week

Using the 2 following settings, specify on which day of the selected month DST (Summer Time) starts. For example, to specify the second Sunday, select [Second] and [Sunday].

<b>Description</b>	Selects the number of the week on which DST (Summer Time) starts.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• First</li> <li>• Second</li> <li>• Third</li> <li>• Fourth</li> <li>• Last</li> </ul>
<b>Default Value</b>	Second
<b>Configuration File Reference</b>	DST_START_ORDINAL_DAY (Page 170)

<b>Description</b>	Selects the day of the week on which DST (Summer Time) starts.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Sunday</li> <li>• Monday</li> <li>• Tuesday</li> <li>• Wednesday</li> <li>• Thursday</li> <li>• Friday</li> <li>• Saturday</li> </ul>
<b>Default Value</b>	Sunday
<b>Configuration File Reference</b>	DST_START_DAY_OF_WEEK (Page 170)

#### 4.4.5 Time Adjust Settings

---

## Time

<b>Description</b>	Specifies the start time of DST (Summer Time) in minutes after 12:00 AM.
<b>Value Range</b>	0–1439
<b>Default Value</b>	120
<b>Configuration File Reference</b>	DST_START_TIME (Page 171)

## 4.4.5.6 End Day and Time of DST (End Day and Time of Summer Time) Month

<b>Description</b>	Selects the month in which DST (Summer Time) ends.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• January</li><li>• February</li><li>• March</li><li>• April</li><li>• May</li><li>• June</li><li>• July</li><li>• August</li><li>• September</li><li>• October</li><li>• November</li><li>• December</li></ul>
<b>Default Value</b>	October
<b>Configuration File Reference</b>	DST_STOP_MONTH (Page 171)

## Day of Week

Using the 2 following settings, specify on which day of the selected month DST (Summer Time) ends. For example, to specify the second Sunday, select [Second] and [Sunday].

<b>Description</b>	Selects the number of the week on which DST (Summer Time) ends.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• First</li><li>• Second</li><li>• Third</li><li>• Fourth</li><li>• Last</li></ul>
<b>Default Value</b>	Second
<b>Configuration File Reference</b>	DST_STOP_ORDINAL_DAY (Page 172)

<b>Description</b>	Selects the day of the week on which DST (Summer Time) ends.
--------------------	--

<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Sunday</li> <li>• Monday</li> <li>• Tuesday</li> <li>• Wednesday</li> <li>• Thursday</li> <li>• Friday</li> <li>• Saturday</li> </ul>
<b>Default Value</b>	Sunday
<b>Configuration File Reference</b>	DST_STOP_DAY_OF_WEEK (Page 172)

## Time

<b>Description</b>	Specifies the end time of DST (Summer Time) in minutes after 12:00 AM.
<b>Value Range</b>	0–1439
<b>Default Value</b>	120
<b>Configuration File Reference</b>	DST_STOP_TIME (Page 172)

# 4.5 VoIP

This section provides detailed descriptions about all the settings classified under the [VoIP] tab.

## 4.5.1 SIP Settings

This screen allows you to change the SIP settings that are common to all lines.

The screenshot shows the Panasonic KX-UT136 web interface. The top navigation bar includes tabs for Status, Network, System, VoIP (which is highlighted in red), Telephone, and Maintenance. On the left, there's a sidebar with sections for Web Port Close, VoIP (with 'SIP Settings' selected and highlighted in red), and VoIP Settings (with options for Line 1 through Line 4). The main content area is titled 'SIP Settings' and contains a single input field for 'SIP User Agent' with the value 'Panasonic\_{MODEL}/{fwver} ({mac})'. Below the input field are 'Save' and 'Cancel' buttons.

## 4.5.1.1 SIP Setting

### SIP User Agent

<b>Description</b>	Specifies the text string to send as the user agent in the headers of SIP messages.
<b>Value Range</b>	<p>Max. 40 characters</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• You cannot leave this field empty.</li> <li>• If "{mac}" is included in this field, it will be replaced with the unit's MAC address in lower-case.</li> <li>• If "{MAC}" is included in this field, it will be replaced with the unit's MAC address in upper-case.</li> <li>• If "{MODEL}" is included in this field, it will be replaced with the unit's model name.</li> <li>• If "{fwver}" is included in this field, it will be replaced with the firmware version of the unit.</li> </ul>
<b>Default Value</b>	Panasonic_{MODEL}/{fwver} ({mac})
<b>Configuration File Reference</b>	SIP_USER_AGENT (Page 243)

## 4.5.2 SIP Settings [Line 1]–[Line x]

This screen allows you to change the SIP settings that are specific to each line. The number of lines available varies depending on the phone being used, as follows:

- KX-UT113/KX-UT123: 1–2
- KX-UT133/KX-UT136: 1–4
- KX-UT248: 1–6

### Note

- When registering multiple phone numbers on a KX-UT133/KX-UT136/KX-UT248, it is necessary to set up DN buttons (flexible buttons). Otherwise, calls cannot be made.

For details about flexible buttons, see **4.6.3 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only)**.

**Panasonic**

KX-UT136 Status Network System **VoIP** Telephone Maintenance

Web Port Close

**SIP Settings [Line 1]**

**Phone Number**

Phone Number:

SIP URI:

**SIP Server**

Registrar Server Address:

Registrar Server Port: 5060 [1-65535]

Proxy Server Address:

Proxy Server Port: 5060 [1-65535]

Presence Server Address:

Presence Server Port: 5060 [1-65535]

**Outbound Proxy Server**

Outbound Proxy Server Address:

Outbound Proxy Server Port: 5060 [1-65535]

**SIP Service Domain**

Service Domain:

**SIP Source Port**

Source Port: 5060 [1024-49151]

**SIP Authentication**

Authentication ID:

Authentication Password:

**DNS**

## 4.5.2.1 Phone Number

### Phone Number

<b>Description</b>	Specifies the phone number to use as the user ID required for registration to the SIP registrar server.
<b>Note</b>	<ul style="list-style-type: none"> <li>When registering using a user ID that is not a phone number, you should use the <b>[SIP URI]</b> setting.</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	PHONE_NUMBER_n (Page 244)

## SIP URI

<b>Description</b>	Specifies the unique ID used by the SIP registrar server, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:user@example.com".
<b>Note</b>	<ul style="list-style-type: none"> <li>When registering using a user ID that is not a phone number, you should use this setting.</li> <li>In a SIP URI, the user part ("user" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters.</li> </ul>
<b>Value Range</b>	Max. 195 characters (except ", &, :, ;, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	SIP_URI_n (Page 244)

### 4.5.2.2 SIP Server

#### Registrar Server Address

<b>Description</b>	Specifies the IP address or FQDN of the SIP registrar server.
<b>Value Range</b>	Max. 127 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	SIP_RGSTR_ADDR_n (Page 247)

#### Registrar Server Port

<b>Description</b>	Specifies the port number to use for communication with the SIP registrar server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060
<b>Configuration File Reference</b>	SIP_RGSTR_PORT_n (Page 247)

#### Proxy Server Address

<b>Description</b>	Specifies the IP address or FQDN of the SIP proxy server.
<b>Value Range</b>	Max. 127 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	SIP_PRXY_ADDR_n (Page 246)

## Proxy Server Port

<b>Description</b>	Specifies the port number to use for communication with the SIP proxy server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060
<b>Configuration File Reference</b>	SIP_PRXY_PORT_n (Page 246)

## Presence Server Address

<b>Description</b>	Specifies the IP address or FQDN of the SIP presence server.
<b>Value Range</b>	Max. 127 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	SIP_PRSNC_ADDR_n (Page 254)

## Presence Server Port

<b>Description</b>	Specifies the port number to use for communication with the SIP presence server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060
<b>Configuration File Reference</b>	SIP_PRSNC_PORT_n (Page 255)

### 4.5.2.3 Outbound Proxy Server

## Outbound Proxy Server Address

<b>Description</b>	Specifies the IP address or FQDN of the SIP outbound proxy server.
<b>Value Range</b>	Max. 127 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	SIP_OUTPROXY_ADDR_n (Page 259)

## Outbound Proxy Server Port

<b>Description</b>	Specifies the port number to use for communication with the SIP outbound proxy server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060
<b>Configuration File Reference</b>	SIP_OUTPROXY_PORT_n (Page 260)

#### 4.5.2.4 SIP Service Domain

##### Service Domain

<b>Description</b>	Specifies the domain name provided by your phone system dealer. The domain name is the part of the SIP URI that comes after the "@" symbol.
<b>Value Range</b>	Max. 127 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	SIP_SVCDOMAIN_n (Page 247)

#### 4.5.2.5 SIP Source Port

##### Source Port

<b>Description</b>	Specifies the source port number used by the unit for SIP communication.
<b>Value Range</b>	1024–49151
<b>Note</b>	<ul style="list-style-type: none"> <li>• You cannot specify here the same port number as any of the port numbers in <b>[Channel 1–25]</b> in <b>4.3.6.3 External RTP Port</b> (if they are configured). In addition, you cannot specify a port number that is 1 greater than a port number specified in <b>[Channel 1–25]</b>.</li> <li>• The available channel number varies depending on the type of the unit being used.</li> <li>• The SIP port number for each line must be unique.</li> <li>• You cannot specify the same port number as the port number specified in <b>[Web Server Port]</b> in <b>4.4.4.1 Web Server Settings</b>.</li> </ul>
<b>Default Value</b>	5060 (for Line 1) 5070 (for Line 2) 5080 (for Line 3) 5090 (for Line 4) 5100 (for Line 5) 5110 (for Line 6)
<b>Configuration File Reference</b>	SIP_SRC_PORT_n (Page 246)

#### 4.5.2.6 SIP Authentication

##### Authentication ID

<b>Description</b>	Specifies the authentication ID required to access the SIP server.
<b>Value Range</b>	Max. 127 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Not stored.

<b>Configuration File Reference</b>	SIP_AUTHID_n (Page 245)
-------------------------------------	-------------------------

## Authentication Password

<b>Description</b>	Specifies the authentication password used to access the SIP server.
<b>Value Range</b>	Max. 127 characters (except ", &, ', :, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	SIP_PASS_n (Page 246)

## 4.5.2.7 DNS

### Enable DNS SRV lookup

<b>Description</b>	Selects whether to request the DNS server to translate domain names into IP addresses using the SRV record.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If you select [<b>Yes</b>], the unit will perform a DNS SRV lookup for a SIP registrar server, SIP proxy server, SIP outbound proxy server, or SIP presence server. If you select [<b>No</b>], the unit will not perform a DNS SRV lookup for a SIP registrar server, SIP proxy server, SIP outbound proxy server, or SIP presence server.</li> </ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	SIP_DNSSRV_ENA_n (Page 252)

### SRV lookup Prefix for UDP

<b>Description</b>	Specifies a prefix to add to the domain name when performing a DNS SRV lookup using UDP.
<b>Note</b>	<ul style="list-style-type: none"> <li>• This setting is available only when [<b>Enable DNS SRV lookup</b>] is set to [<b>Yes</b>].</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Default Value</b>	_sip._udp.
<b>Configuration File Reference</b>	SIP_UDP_SRV_PREFIX_n (Page 253)

## SRV lookup Prefix for TCP

<b>Description</b>	Specifies a prefix to add to the domain name when performing a DNS SRV lookup using TCP.
<b>Note</b>	<ul style="list-style-type: none"> <li>This setting is available only when <b>[Enable DNS SRV lookup]</b> is set to <b>[Yes]</b>.</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Default Value</b>	_sip._tcp.
<b>Configuration File Reference</b>	SIP_TCP_SRV_PREFIX_n (Page 253)

## 4.5.2.8 Transport Protocol of SIP

### Transport Protocol

<b>Description</b>	Selects which transport layer protocol to use for sending SIP packets.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>UDP</li> <li>TCP</li> </ul>
<b>Default Value</b>	UDP
<b>Configuration File Reference</b>	SIP_TRANSPORT_n (Page 260)

## 4.5.2.9 Timer Settings

### T1 Timer

<b>Description</b>	Selects the default interval, in milliseconds, between transmissions of SIP messages. For details, refer to RFC 3261.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>250</li> <li>500</li> <li>1000</li> <li>2000</li> <li>4000</li> </ul>
<b>Default Value</b>	500
<b>Configuration File Reference</b>	SIP_TIMER_T1_n (Page 250)

### T2 Timer

<b>Description</b>	Selects the maximum interval, in seconds, between transmissions of SIP messages. For details, refer to RFC 3261.
--------------------	--

<b>Value Range</b>	<ul style="list-style-type: none"> <li>• 2</li> <li>• 4</li> <li>• 8</li> <li>• 16</li> <li>• 32</li> </ul>
<b>Default Value</b>	4
<b>Configuration File Reference</b>	SIP_TIMER_T2_n (Page 250)

## Timer B

<b>Description</b>	Specifies the value of SIP timer B (INVITE transaction timeout timer), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	250–64000
<b>Default Value</b>	32000
<b>Configuration File Reference</b>	SIP_TIMER_B_n (Page 262)

## Timer D

<b>Description</b>	Specifies the value of SIP timer D (wait time for answer resending), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	0, 250–64000
<b>Default Value</b>	5000
<b>Configuration File Reference</b>	SIP_TIMER_D_n (Page 262)

## Timer F

<b>Description</b>	Specifies the value of SIP timer F (non-INVITE transaction timeout timer), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	250–64000
<b>Default Value</b>	32000
<b>Configuration File Reference</b>	SIP_TIMER_F_n (Page 263)

## Timer H

<b>Description</b>	Specifies the value of SIP timer H (wait time for ACK reception), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	250–64000
<b>Default Value</b>	32000
<b>Configuration File Reference</b>	SIP_TIMER_H_n (Page 263)

## Timer J

<b>Description</b>	Specifies the value of SIP timer J (wait time for non-INVITE request resending), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	0, 250–64000
<b>Default Value</b>	5000
<b>Configuration File Reference</b>	SIP_TIMER_J_n (Page 263)

### 4.5.2.10 Quality of Service (QoS)

#### SIP Packet QoS (DSCP)

<b>Description</b>	Selects the DSCP (Differentiated Services Code Point) level of DiffServ applied to SIP packets.
<b>Value Range</b>	0–63
<b>Default Value</b>	0
<b>Configuration File Reference</b>	DSCP_SIP_n (Page 249)

### 4.5.2.11 SIP extensions

#### Supports 100rel (RFC 3262)

<b>Description</b>	Selects whether to add the option tag 100rel to the "Supported" header of the INVITE message. For details, refer to RFC 3262.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If you select <b>[Yes]</b>, the Reliability of Provisional Responses function will be enabled. The option tag 100rel will be added to the "Supported" header of the INVITE message and to the "Require" header of the "1xx" provisional message. If you select <b>[No]</b>, the option tag 100rel will not be used.</li> </ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	SIP_100REL_ENABLE_n (Page 253)

#### Supports Session Timer (RFC 4028)

<b>Description</b>	Specifies the length of time, in seconds, that the unit waits before terminating SIP sessions when no reply to repeated requests is received. For details, refer to RFC 4028.
<b>Value Range</b>	0, 60–65535 (0: Disable)

<b>Default Value</b>	0
<b>Configuration File Reference</b>	SIP_SESSION_TIME_n (Page 248)

## 4.5.2.12 NAT Identity

### Keep Alive Interval

<b>Description</b>	Specifies the interval, in seconds, between transmissions of the Keep Alive packet to the unit in order to maintain the NAT binding information.
<b>Note</b>	<ul style="list-style-type: none"> <li>This setting is available only when [<b>Transport Protocol</b>] is set to [<b>UDP</b>].</li> </ul>
<b>Value Range</b>	0, 10–300 (0: Disable)
<b>Default Value</b>	0
<b>Configuration File Reference</b>	PORT_PUNCH_INVL_n (Page 256)

### Supports Rport (RFC 3581)

<b>Description</b>	Selects whether to add the 'rport' parameter to the top Via header field value of requests generated. For details, refer to RFC 3581.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	SIP_ADD_RPORT_n (Page 256)

## 4.5.2.13 Security

### Enable SSAF (SIP Source Address Filter)


<b>Description</b>	Selects whether to enable SSAF (SIP Source Address Filter) for the SIP servers (registrar server, proxy server, and presence server).
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>If you select [<b>Yes</b>], the unit receives SIP messages only from the source addresses stored in the SIP servers (registrar server, proxy server, and presence server), and not from other addresses. However, if [<b>Outbound Proxy Server Address</b>] in <b>4.5.2.3 Outbound Proxy Server</b> is specified, the unit also receives SIP messages from the source address stored in the SIP outbound proxy server.</li> </ul>

#### 4.5.3 VoIP Settings

<b>Default Value</b>	No
<b>Configuration File Reference</b>	SIP_DETECT_SSAF_n (Page 261)

### 4.5.3 VoIP Settings

This screen allows you to change the VoIP settings that are common to all lines.



#### 4.5.3.1 RTP Settings

##### RTP Packet Time

<b>Description</b>	Selects the interval, in milliseconds, between transmissions of RTP packets.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• 20</li><li>• 30</li><li>• 40</li></ul>
<b>Default Value</b>	20
<b>Configuration File Reference</b>	RTP_PTIME (Page 235)

##### Minimum RTP Port Number

<b>Description</b>	Specifies the lowest port number that the unit will use for RTP packets.
	<p><b>Note</b></p> <ul style="list-style-type: none"><li>• If port numbers are specified in <b>[Channel 1–25]</b> in <b>4.3.6.3 External RTP Port</b>, this setting is ignored and the corresponding external RTP port is enabled.</li><li>• The available channel number varies depending on the type of the unit being used.</li></ul>

<b>Value Range</b>	1024–48750 (even number only)
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>The value for this setting must be less than or equal to "[Maximum RTP Port Number] - 400".</li> <li>Changing this setting may affect the number of simultaneous calls that can be made. Therefore, when setting this parameter, be aware that the maximum number of necessary ports can be calculated as shown below: No. of lines × No. of channels × 2 × 10 (No. of terminals)</li> </ul>
<b>Default Value</b>	16000
<b>Configuration File Reference</b>	RTP_PORT_MIN (Page 234)

## Maximum RTP Port Number

<b>Description</b>	Specifies the highest port number that the unit will use for RTP packets.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>If port numbers are specified in [Channel 1–25] in 4.3.6.3 External RTP Port, this setting is ignored and the corresponding external RTP port is enabled.</li> <li>The available channel number varies depending on the type of the unit being used.</li> </ul>
<b>Value Range</b>	1424–49150 (even number only)
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>The value for this setting must be greater than or equal to "[Minimum RTP Port Number] + 400".</li> <li>Changing this setting may affect the number of simultaneous calls that can be made. Therefore, when setting this parameter, be aware that the maximum number of necessary ports can be calculated as shown below: No. of lines × No. of channels × 2 × 10 (No. of terminals)</li> </ul>
<b>Default Value</b>	20000
<b>Configuration File Reference</b>	RTP_PORT_MAX (Page 234)

## Telephone-event Payload Type

<b>Description</b>	Specifies the RFC 2833 payload type for DTMF tones.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>This setting is available only when [DTMF Type] is set to [Outband].</li> </ul>
<b>Value Range</b>	96–127
<b>Default Value</b>	101
<b>Configuration File Reference</b>	TELEVENT_PAYLOAD (Page 237)

#### 4.5.4 VoIP Settings [Line 1]–[Line x]

## 4.5.4 VoIP Settings [Line 1]–[Line x]

This screen allows you to change the VoIP settings that are specific to each line. The number of lines available varies depending on the phone being used, as follows:

- KX-UT113/KX-UT123: 1–2
- KX-UT133/KX-UT136: 1–4
- KX-UT248: 1–6

Panasonic

KX-UT136 Status Network System **VoIP** Telephone Maintenance

Web Port Close

**VoIP**

SIP Settings  
- Line 1  
- Line 2  
- Line 3  
- Line 4

VoIP Settings  
- Line 1  
- Line 2  
- Line 3  
- Line 4

**VoIP Settings [Line 1]**

**Quality of Service (QoS)**

RTP Packet QoS (DSCP)  [0-63]  
RTCP Packet QoS (DSCP)  [0-63]

**Statistical Information**

RTCP Enable  Yes  No  
RTCP Interval  seconds [5-65535]

**Jitter Buffer**

Maximum Delay  [3-50]  
Minimum Delay  [1-2]  
Initial Delay  [1-7]

**DTMF**

DTMF Type  Outband  Inband  
DTMF Relay  Yes  No

**Call Hold**

Supports RFC 2543 (c=0.0.0.0)  Yes  No

**CODEC Preferences**

G722	Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No
	Priority	<input type="text" value="1"/> [1-255]
	Enable	<input checked="" type="radio"/> Yes <input type="radio"/> No

### 4.5.4.1 Quality of Service (QoS)

#### RTP Packet QoS (DSCP)

<b>Description</b>	Selects the DSCP level of DiffServ applied to RTP packets.
<b>Value Range</b>	0–63
<b>Default Value</b>	0
<b>Configuration File Reference</b>	DSCP_RTP_n (Page 232)

#### RTCP Packet QoS (DSCP)

<b>Description</b>	Selects the DSCP level of DiffServ applied to RTCP packets.
<b>Value Range</b>	0–63
<b>Default Value</b>	0

<b>Configuration File Reference</b>	DSCP_RTCP_n (Page 232)
-------------------------------------	------------------------

## 4.5.4.2 Statistical Information

### RTCP Enable

<b>Description</b>	Selects whether to enable or disable RTCP (Real-Time Transport Control Protocol). For details, refer to RFC 3550.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	RTCP_ENABLE_n (Page 235)

### RTCP Interval

<b>Description</b>	Specifies the interval, in seconds, between RTCP packets.
<b>Value Range</b>	5–65535
<b>Default Value</b>	5
<b>Configuration File Reference</b>	RTCP_INTVL_n (Page 233)

## 4.5.4.3 Jitter Buffer

### Maximum Delay

<b>Description</b>	Specifies the maximum delay, in 10-millisecond units, of the jitter buffer.
<b>Value Range</b>	3–50 ( $\times 10$ ms)
<b>Note</b>	<ul style="list-style-type: none"> <li>• This setting is subject to the following conditions:           <ul style="list-style-type: none"> <li>– This value must be greater than <b>[Initial Delay]</b></li> <li>– This value must be greater than <b>[Minimum Delay]</b></li> <li>– <b>[Initial Delay]</b> must be greater than or equal to <b>[Minimum Delay]</b></li> </ul> </li> </ul>
<b>Default Value</b>	20 ( $\times 10$ ms)
<b>Configuration File Reference</b>	MAX_DELAY_n (Page 233)

### Minimum Delay

<b>Description</b>	Specifies the minimum delay, in 10-millisecond units, of the jitter buffer.
--------------------	---

#### 4.5.4 VoIP Settings [Line 1]–[Line x]

<b>Value Range</b>	1 or 2 ( $\times 10$ ms)
<b>Note</b>	<ul style="list-style-type: none"><li>This setting is subject to the following conditions:<ul style="list-style-type: none"><li>This value must be less than or equal to <b>[Initial Delay]</b></li><li>This value must be less than <b>[Maximum Delay]</b></li><li><b>[Maximum Delay]</b> must be greater than <b>[Initial Delay]</b></li></ul></li></ul>
<b>Default Value</b>	2 ( $\times 10$ ms)
<b>Configuration File Reference</b>	MIN_DELAY_n (Page 233)

### Initial Delay

<b>Description</b>	Specifies the initial delay, in 10-millisecond units, of the jitter buffer.
<b>Value Range</b>	1–7 ( $\times 10$ ms)
<b>Note</b>	<ul style="list-style-type: none"><li>This setting is subject to the following conditions:<ul style="list-style-type: none"><li>This value must be greater than or equal to <b>[Minimum Delay]</b></li><li>This value must be less than <b>[Maximum Delay]</b></li></ul></li></ul>
<b>Default Value</b>	2 ( $\times 10$ ms)
<b>Configuration File Reference</b>	NOM_DELAY_n (Page 234)

#### 4.5.4.4 DTMF

### DTMF Type

<b>Description</b>	Selects the method for transmitting DTMF (Dual Tone Multi-Frequency) tones.
<b>Value Range</b>	<ul style="list-style-type: none"><li>Outband</li><li>Inband</li></ul>
<b>Note</b>	<ul style="list-style-type: none"><li>If you select <b>[Outband]</b>, DTMF tones will be sent through SDP (Session Description Protocol), compliant with RFC 2833. If you select <b>[Inband]</b>, DTMF tones will be encoded in the RTP stream.</li></ul>
<b>Default Value</b>	Outband
<b>Configuration File Reference</b>	OUTBANDDTMF_n (Page 236)

### DTMF Relay

<b>Description</b>	Selects whether DTMF tones are sent in the SIP INFO message.
--------------------	--

<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If you select [<b>Yes</b>], DTMF tones will be sent in the SIP INFO message. If you select [<b>No</b>], the method selected in [<b>DTMF Type</b>] will be used.</li> </ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	DTMF_RELAY_n (Page 237)

#### 4.5.4.5 Call Hold

**Supports RFC 2543 (c=0.0.0.0)**

<b>Description</b>	Selects whether to enable the RFC 2543 Call Hold feature on this line.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If you select [<b>Yes</b>], the "c=0.0.0.0" syntax will be set in SDP when sending a re-INVITE message to hold the call. If you select [<b>No</b>], the "c=x.x.x.x" syntax will be set in SDP.</li> </ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	RFC2543_HOLD_ENABLE_n (Page 238)

#### 4.5.4.6 CODEC Preferences

**G722 (Enable)**

<b>Description</b>	Selects whether to enable the G.722 codec for voice data transmission.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	CODEC_ENABLEx_n (Page 231)

**G722 (Priority)**

<b>Description</b>	Specifies the numerical order usage priority for the G.722 codec.
<b>Value Range</b>	1–255
<b>Default Value</b>	1
<b>Configuration File Reference</b>	CODEC_PRIORITYx_n (Page 231)

#### 4.5.4 VoIP Settings [Line 1]–[Line x]

---

### PCMA (Enable)

<b>Description</b>	Selects whether to enable the PCMA codec for voice data transmission.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• Yes</li><li>• No</li></ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	CODEC_ENABLEx_n (Page 231)

### PCMA (Priority)

<b>Description</b>	Specifies the numerical order usage priority for the PCMA codec.
<b>Value Range</b>	1–255
<b>Default Value</b>	1
<b>Configuration File Reference</b>	CODEC_PRIORITYx_n (Page 231)

### G726–32 (Enable)

<b>Description</b>	Selects whether to enable the G.726-32 codec for voice data transmission.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• Yes</li><li>• No</li></ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	CODEC_ENABLEx_n (Page 231)

### G726–32 (Priority)

<b>Description</b>	Specifies the numerical order usage priority for the G.726-32 codec.
<b>Value Range</b>	1–255
<b>Default Value</b>	1
<b>Configuration File Reference</b>	CODEC_PRIORITYx_n (Page 231)

### G729A (Enable)

<b>Description</b>	Selects whether to enable the G.729A codec for voice data transmission.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• Yes</li><li>• No</li></ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	CODEC_ENABLEx_n (Page 231)

## G729A (Priority)

<b>Description</b>	Specifies the numerical order usage priority for the G.729A codec.
<b>Value Range</b>	1–255
<b>Default Value</b>	1
<b>Configuration File Reference</b>	CODEC_PRIORITYx_n (Page 231)

## PCMU (Enable)

<b>Description</b>	Selects whether to enable the PCMU codec for voice data transmission.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	CODEC_ENABLEx_n (Page 231)

## PCMU (Priority)

<b>Description</b>	Specifies the numerical order usage priority for the PCMU codec.
<b>Value Range</b>	1–255
<b>Default Value</b>	1
<b>Configuration File Reference</b>	CODEC_PRIORITYx_n (Page 231)

# 4.6 Telephone

This section provides detailed descriptions about all the settings classified under the [Telephone] tab.

#### 4.6.1 Call Control

## 4.6.1 Call Control

This screen allows you to configure various call features that are common to all lines.

The screenshot shows the Panasonic KX-UT136 web interface. The top navigation bar includes links for Status, Network, System, VoIP, Telephone (which is highlighted with a red border), and Maintenance. On the left, a sidebar menu lists Telephone, Call Control (which is also highlighted with a red border), Line 1, Line 2, Line 3, Line 4, Flexible Button Settings, Tone Settings, Telephone Settings, Import Phonebook, Export Phonebook, and Application Settings. The main content area is titled 'Call Control' and contains several configuration fields:

Send SUBSCRIBE to Voice Mail Server	<input type="radio"/> Yes <input checked="" type="radio"/> No
Conference Server URI	[Text input field]
Inter-digit Timeout	5 <input type="button" value="▼"/> seconds
Timer for Dial Plan	5 <input type="button" value="▼"/> seconds
International Call Prefix	[Text input field]
Country Calling Code	[Text input field]
National Access Code	[Text input field]
Default Line for Outgoing	1 <input type="button" value="▼"/>
Flash/Recall Button	<input checked="" type="radio"/> Terminate <input type="radio"/> Flash Hook
Flash Hook Event	<input checked="" type="radio"/> Signal <input type="radio"/> flashhook
Directed Call Pickup	[Text input field]

Below these fields is a section titled 'Call Rejection Phone Numbers' with two input fields and a page number indicator '2'.

### 4.6.1.1 Call Control

#### Send SUBSCRIBE to Voice Mail Server

<b>Description</b>	Selects whether to send the SUBSCRIBE request to a voice mail server.
<b>Note</b>	<ul style="list-style-type: none"><li>Your phone system must support voice mail.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>Yes</li><li>No</li></ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	VM_SUBSCRIBE_ENABLE (Page 202)

## Conference Server URI

<b>Description</b>	Specifies the URI for a conference server, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:conference@example.com".
<b>Note</b>	<ul style="list-style-type: none"> <li>In a SIP URI, the user part ("conference" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters.</li> <li>Availability depends on your phone system.</li> </ul>
<b>Value Range</b>	Max. 195 characters (except ", &, :, ;, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	CONFERENCE_SERVER_URI (Page 203)

## Inter-digit Timeout

<b>Description</b>	Specifies the length of time, in seconds, within which subsequent digits of a dial number must be dialed. When this timer expires after the last key was pressed, dialing will start.
<b>Value Range</b>	1–15
<b>Default Value</b>	5
<b>Configuration File Reference</b>	INTDIGIT_TIM (Page 203)

## Timer for Dial Plan

<b>Description</b>	Specifies the length of time, in seconds, that the unit waits when a "T" or "t" has been entered in the dial plan.
<b>Value Range</b>	1–15
<b>Default Value</b>	5
<b>Configuration File Reference</b>	MACRODIGIT_TIM (Page 203)

## International Call Prefix

<b>Description</b>	Specifies the number to be shown in the place of the first "+" symbol when the phone number for incoming international calls contains "+".
<b>Value Range</b>	Max. 8 characters (consisting of 0–9, *, and #)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	INTERNATIONAL_ACCESS_CODE (Page 204)

#### 4.6.1 Call Control

---

### Country Calling Code

<b>Description</b>	Specifies the country/area calling code to be used for comparative purposes when dialing a number from the incoming call log that contains a "+" symbol.
<b>Value Range</b>	Max. 8 characters (consisting of 0–9)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	COUNTRY_CALLING_CODE (Page 204)

### National Access Code

<b>Description</b>	When dialing a number from the incoming call log that contains a "+" symbol and the country calling code matches, the country calling code is removed and the national access code is added.
<b>Value Range</b>	Max. 8 characters (consisting of 0–9, *, and #)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	NATIONAL_ACCESS_CODE (Page 204)

### Default Line for Outgoing

<b>Description</b>	Specifies the line used to make an outgoing call when no line is specified in the dialing operation.  <b>Note</b> <ul style="list-style-type: none"><li>The available line number may vary depending on the type of the unit being used.</li></ul>
<b>Value Range</b>	1–2 (for KX-UT113/KX-UT123) 1–4 (for KX-UT133/KX-UT136) 1–6 (for KX-UT248)
<b>Default Value</b>	1
<b>Configuration File Reference</b>	DEFAULT_LINE_SELECT (Page 204)

### Flash/Recall Button

<b>Description</b>	Selects the function of the FLASH/RECALL button during a conversation.
<b>Value Range</b>	<ul style="list-style-type: none"><li>Terminate</li><li>Flash Hook</li></ul>
<b>Default Value</b>	Terminate
<b>Configuration File Reference</b>	FLASH_RECALL_TERMINATE (Page 242)

## Flash Hook Event

<b>Description</b>	Specifies the type of signal sent when sending a flash hook event.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Signal</li> <li>• flashhook</li> </ul>
<b>Default Value</b>	Signal
<b>Configuration File Reference</b>	FLASHHOOK_CONTENT_TYPE (Page 242)

## Direct Call Pickup

<b>Description</b>	Specifies the feature number assigned to a BLF for performing call pickup.
<b>Value Range</b>	Max. 4 characters (consisting of 0–9, *, and #)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	NUM_PLAN_PICKUP_DIRECT (Page 205)

### 4.6.1.2 Call Rejection Phone Numbers

#### 1–30

<b>Description</b>	Specifies the phone numbers to reject incoming calls from. A maximum of 30 phone numbers can be specified.  <b>Note</b> <ul style="list-style-type: none"><li>• You can also configure this setting through the phone user interface. If these settings are changed through the phone user interface while being changed through the Web user interface, the settings made through the phone user interface will be overwritten by the settings made through the Web user interface.</li></ul>
<b>Value Range</b>	Max. 32 characters  <b>Note</b> <ul style="list-style-type: none"><li>• Even if you specify nonconsecutive fields (e.g., fields 1, 5, and 30), they will be rearranged into consecutive fields after you save the settings (i.e., 1, 2, and 3).</li><li>• If the phone number contains characters other than 0–9, *, #, and +, the number may not be rejected correctly.</li></ul>
<b>Default Value</b>	Not stored.


## 4.6.2 Call Control [Line 1]–[Line x]

This screen allows you to configure various call features that are specific to each line. The number of lines available varies depending on the phone being used, as follows:

- KX-UT113/KX-UT123: 1–2

#### 4.6.2 Call Control [Line 1]–[Line x]

- KX-UT133/KX-UT136: 1–4
- KX-UT248: 1–6



##### 4.6.2.1 Call Control

###### Display Name

<b>Description</b>	Specifies the name to display as the caller on the other party's phone when you make a call.
<b>Value Range</b>	Max. 24 characters <b>Note</b> <ul style="list-style-type: none"><li>• You can use Unicode characters for this setting.</li></ul>
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	DISPLAY_NAME_n (Page 239)

###### Voice Mail Access Number

<b>Description</b>	Specifies the phone number used to access the voice mail server. <b>Note</b> <ul style="list-style-type: none"><li>• Your phone system must support voice mail.</li></ul>
<b>Value Range</b>	Max. 32 characters
<b>Default Value</b>	Not stored.

**Configuration File Reference**

VM\_NUMBER\_n (Page 239)

## Enable Shared Call

<b>Description</b>	Selects whether to enable the Shared Call feature of the SIP server, which is used to share one line among the units.
<b>Note</b>	<ul style="list-style-type: none"> <li>You cannot set both <b>[Enable Shared Call]</b> and <b>[Synchronize Do Not Disturb and Call Forward]</b> to <b>[Yes]</b> at the same time.</li> <li>Availability depends on your phone system.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul> <b>Note</b> <ul style="list-style-type: none"> <li>If you select <b>[Yes]</b>, the SIP server will control the line by using a shared-call signaling method. If you select <b>[No]</b>, the SIP server will control the line by using a standard signaling method.</li> </ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	SHARED_CALL_ENABLE_n (Page 240)

## Synchronize Do Not Disturb and Call Forward

<b>Description</b>	Selects whether to synchronize the Do Not Disturb and Call Forward settings, configured via the Web user interface or phone user interface, between the unit and the portal server that is provided by your phone system dealer.
<b>Note</b>	<ul style="list-style-type: none"> <li>Even if you select <b>[Yes]</b>, this feature may not function properly if your phone system does not support it. Before you configure this setting, consult your phone system dealer.</li> <li>You cannot set both <b>[Enable Shared Call]</b> and <b>[Synchronize Do Not Disturb and Call Forward]</b> to <b>[Yes]</b> at the same time.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	FWD_DND_SYNCHRO_ENABLE_n (Page 241)

## Resource List URI

<b>Description</b>	Specifies the Uniform Resource Identifier string for the resource list, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:user@example.com". For details, refer to RFC 4662.
<b>Note</b>	<ul style="list-style-type: none"> <li>In a SIP URI, the user part ("user" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters.</li> <li>When the BLF feature is assigned to a flexible button, it may be necessary to specify this parameter depending on your phone system. For details about flexible buttons, see <b>6.3 Flexible Buttons (KX-UT133/KX-UT136/KX-UT248 only)</b>.</li> </ul>
<b>Value Range</b>	Max. 195 characters (except ", &, :, ;, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	RESOURCELIST_URI_n (Page 241)

### 4.6.2.2 Dial Plan

#### Dial Plan (max 1000 columns)

<b>Description</b>	Specifies a dial format, such as specific phone numbers, that control which numbers can be dialed or how to handle the call when making a call. For details, see <b>6.2 Dial Plan</b> .
<b>Value Range</b>	Max. 1000 characters
<b>Note</b>	<ul style="list-style-type: none"> <li>Entering more than 1000 characters in this field causes an error and the previous value remains effective.</li> </ul>
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	DIAL_PLAN_n (Page 239)

#### Call Even If Dial Plan Does Not Match

<b>Description</b>	Selects whether to make a call even if the dialed number does not match any of the dial formats specified in <b>[Dial Plan]</b> .
--------------------	---

<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If you select [<b>Yes</b>], calls will be made even if the dialed number does not match the dial formats specified in [<b>Dial Plan</b>] (i.e., dial plan filtering is disabled). If you select [<b>No</b>], calls will not be made if the dialed number does not match one of the dial formats specified in [<b>Dial Plan</b>] (i.e., dial plan filtering is enabled).</li> </ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	DIAL_PLAN_NOT_MATCH_ENABLE_n (Page 240)

#### 4.6.2.3 Call Features

##### Block Caller ID

<b>Description</b>	Selects whether to make calls without transmitting the phone number to the called party.
<b>Note</b>	<ul style="list-style-type: none"> <li>• Availability depends on your phone system.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
<b>Default Value</b>	No

##### Block Anonymous Call

<b>Description</b>	Selects whether to reject incoming calls that do not show the caller's number.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
<b>Default Value</b>	No

## Do Not Disturb

<b>Description</b>	Selects whether to enable the Do Not Disturb feature for incoming calls.
<b>Note</b>	<ul style="list-style-type: none"> <li>If Do Not Disturb has been enabled on the server, the server rejects incoming calls and the unit does not receive any calls, even if you have selected <b>[No]</b> for this setting.</li> <li>If you change this setting when <b>[Synchronize Do Not Disturb and Call Forward]</b> is set to <b>[Yes]</b>, the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul>
<b>Default Value</b>	No

### 4.6.2.4 Call Forward

#### Unconditional (Enable Call Forward)

<b>Description</b>	Selects whether to forward all incoming calls to a specified destination.
<b>Note</b>	<ul style="list-style-type: none"> <li>If Do Not Disturb has been enabled on the server, the server rejects incoming calls and the unit does not receive any calls, even if you have selected <b>[Yes]</b> for this setting.</li> <li>If you have selected <b>[Yes]</b> for this setting and Call Forward has been enabled on the server, but the forwarding destinations differ, incoming calls are forwarded to the destination set on the server.</li> <li>If Call Forward has been enabled on the server, incoming calls are forwarded to the destination set on the server, even if you have selected <b>[No]</b> for this setting.</li> <li>You can synchronize the Do Not Disturb and Call Forward settings from the Web user interface (→ see <b>[Synchronize Do Not Disturb and Call Forward]</b> in 4.6.2.1 Call Control) or through configuration file programming (→ see "<b>FWD_DND_SYNCHRO_ENABLE_n</b>" in 5.7.1 Call Control Settings).</li> <li>If you change this setting when <b>[Synchronize Do Not Disturb and Call Forward]</b> is set to <b>[Yes]</b>, the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul>
<b>Default Value</b>	No

## Unconditional (Phone Number)

<b>Description</b>	Specifies the phone number of the destination to forward all incoming calls to.
<b>Note</b>	<ul style="list-style-type: none"> <li>If you change this setting when <b>[Synchronize Do Not Disturb and Call Forward]</b> is set to <b>[Yes]</b>, the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Note</b>	<ul style="list-style-type: none"> <li>You cannot leave this field empty if <b>[Unconditional (Enable Call Forward)]</b> is set to <b>[Yes]</b>.</li> </ul>
<b>Default Value</b>	Not stored.

## Busy (Enable Call Forward)

<b>Description</b>	Selects whether to forward incoming calls to a specified destination when the line is in use.
<b>Note</b>	<ul style="list-style-type: none"> <li>If Do Not Disturb has been enabled on the server, the server rejects incoming calls and the unit does not receive any calls, even if you have selected <b>[Yes]</b> for this setting.</li> <li>If you have selected <b>[Yes]</b> for this setting and Call Forward has been enabled on the server, but the forwarding destinations differ, incoming calls are forwarded to the destination set on the server.</li> <li>If Call Forward has been enabled on the server, incoming calls are forwarded to the destination set on the server, even if you have selected <b>[No]</b> for this setting.</li> <li>You can synchronize the Do Not Disturb and Call Forward settings from the Web user interface (→ see <b>[Synchronize Do Not Disturb and Call Forward]</b> in <b>4.6.2.1 Call Control</b>) or through configuration file programming (→ see <b>"FWD_DND_SYNCHRO_ENABLE_n"</b> in <b>5.7.1 Call Control Settings</b>).</li> <li>If you change this setting when <b>[Synchronize Do Not Disturb and Call Forward]</b> is set to <b>[Yes]</b>, the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul>
<b>Default Value</b>	No

## Busy (Phone Number)

<b>Description</b>	Specifies the phone number of the destination to forward calls to when the line is in use.
<b>Note</b>	<ul style="list-style-type: none"> <li>If you change this setting when <b>[Synchronize Do Not Disturb and Call Forward]</b> is set to <b>[Yes]</b>, the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Note</b>	<ul style="list-style-type: none"> <li>You cannot leave this field empty if <b>[Busy (Enable Call Forward)]</b> is set to <b>[Yes]</b>.</li> </ul>
<b>Default Value</b>	Not stored.

## No Answer (Enable Call Forward)

<b>Description</b>	Selects whether to forward incoming calls to a specified destination when a call is not answered after it has rung a specified number of times.
<b>Note</b>	<ul style="list-style-type: none"> <li>If Do Not Disturb has been enabled on the server, the server rejects incoming calls and the unit does not receive any calls, even if you have selected <b>[Yes]</b> for this setting.</li> <li>If you have selected <b>[Yes]</b> for this setting and Call Forward has been enabled on the server, but the forwarding destinations differ, incoming calls are forwarded to the destination set on the server.</li> <li>If Call Forward has been enabled on the server, incoming calls are forwarded to the destination set on the server, even if you have selected <b>[No]</b> for this setting.</li> <li>You can synchronize the Do Not Disturb and Call Forward from the Web user interface (→ see <b>[Synchronize Do Not Disturb and Call Forward]</b> in <b>4.6.2.1 Call Control</b>) or through configuration file programming (→ see <b>"FWD_DND_SYNCHRO_ENABLE_n"</b> in <b>5.7.1 Call Control Settings</b>).</li> <li>If you change this setting when <b>[Synchronize Do Not Disturb and Call Forward]</b> is set to <b>[Yes]</b>, the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul>
<b>Default Value</b>	No

## No Answer (Phone Number)

<b>Description</b>	Specifies the phone number of the destination to forward calls to when a call is not answered after it has rung a specified number of times.
<b>Note</b>	<ul style="list-style-type: none"> <li>If you change this setting when [<b>Synchronize Do Not Disturb and Call Forward</b>] is set to [<b>Yes</b>], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Note</b>	<ul style="list-style-type: none"> <li>You cannot leave this field empty if [<b>No Answer (Enable Call Forward)</b>] is set to [<b>Yes</b>].</li> </ul>
<b>Default Value</b>	Not stored.


## No Answer (Ring Count)

<b>Description</b>	Specifies the number of times that an incoming call rings until the call is forwarded.
<b>Note</b>	<ul style="list-style-type: none"> <li>If you change this setting when [<b>Synchronize Do Not Disturb and Call Forward</b>] is set to [<b>Yes</b>], the change to this setting is not immediately applied on this screen. In this case, reload the screen to confirm that the change is applied.</li> </ul>
<b>Value Range</b>	0, 2–20 (0: No ring)
<b>Default Value</b>	3

#### 4.6.3 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only)

### 4.6.3 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only)

This screen allows you to configure various features for each flexible button. For more details, see **6.3 Flexible Buttons (KX-UT133/KX-UT136/KX-UT248 only)**.



#### 4.6.3.1 Flexible Button Settings

##### Type (No. 1–24)

Description	Selects the feature to be assigned to each flexible button.
Value Range	<ul style="list-style-type: none"><li>DN</li><li>One-Touch</li><li>Headset</li><li>BLF</li><li>ACD</li><li>Wrap Up</li></ul>
Default Value	DN
Configuration File Reference	FLEX_BUTTON_FACILITY_ACTx (Page 224)

##### Parameter (No. 1–24)

Description	Specifies the necessary values for the features assigned to flexible buttons.
Value Range	Max. 32 characters
Default Value	1
Configuration File Reference	FLEX_BUTTON_FACILITY_ARGx (Page 224)

## Label Name (No. 1–24)

<b>Description</b>	Specifies the message to be displayed on the screen when the flexible button is pressed.
<b>Value Range</b>	Max. 10 characters  <b>Note</b> <ul style="list-style-type: none"><li>• You can use Unicode characters for this setting.</li></ul>
<b>Default Value</b>	<b>For KX-UT133/KX-UT136:</b> Not stored. <b>For KX-UT248:</b> No. 1: 1, No. 2: 2, No. 3: 3... No. 24: 24
<b>Configuration File Reference</b>	FLEX_BUTTON_LABELx (Page 225)

## 4.6.4 Tone Settings

This screen allows you to configure the dual-tone frequencies and ringtone patterns of each tone.

The screenshot shows the Panasonic KX-UT136 web interface. The top navigation bar includes 'Status', 'Network', 'System', 'VoIP', 'Telephone' (which is highlighted in red), and 'Maintenance'. On the left, a sidebar under the 'Telephone' heading lists 'Call Control', 'Flexible Button Settings', and 'Tone Settings' (which is also highlighted in red). The main content area is titled 'Tone Settings' and contains five sections: 'Dial Tone', 'Busy Tone', 'Ringing Tone', 'Stutter Tone', and 'Reorder Tone'. Each section has two input fields: 'Tone Frequencies' and 'Tone Timings'. At the bottom of the page are 'Save' and 'Cancel' buttons.

### 4.6.4.1 Dial Tone

#### Tone Frequencies

<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of dial tones using 2 whole numbers separated by a comma.
--------------------	--

#### 4.6.4 Tone Settings

---

<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Note</b>	<ul style="list-style-type: none"><li>If the value for this setting is "350,440", the unit will use a mixed signal of a 350 Hz tone and a 440 Hz tone.</li></ul>
<b>Default Value</b>	350,440
<b>Configuration File Reference</b>	DIAL_TONE1_FRQ (Page 209)

### Tone Timings

---

<b>Description</b>	Specifies the pattern, in milliseconds, of dial tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
<b>Note</b>	<ul style="list-style-type: none"><li>The unit will not play the tone for the duration of the first value, play it for the duration of the second value, stop it for the duration of the third value, play it again for the duration of the fourth value, and so on. The whole sequence will then repeat. For example, if the value for this setting is "100,100,100,0", the unit will not play the tone for 100 ms, play it for 100 ms, stop it for 100 ms, and then play it continuously.</li><li>It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).</li></ul>
<b>Value Range</b>	0–16000 (0: Infinite time)
<b>Note</b>	<ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	60,0
<b>Configuration File Reference</b>	DIAL_TONE1_TIMING (Page 209)

#### 4.6.4.2 Busy Tone

### Tone Frequencies

---

<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of busy tones using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	480,620
<b>Configuration File Reference</b>	BUSY_TONE_FRQ (Page 212)

## Tone Timings

<b>Description</b>	Specifies the pattern, in milliseconds, of busy tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
<b>Note</b>	<ul style="list-style-type: none"> <li>It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).</li> </ul>
<b>Value Range</b>	0–16000 (0: Infinite time)
<b>Note</b>	<ul style="list-style-type: none"> <li>Avoid setting 1–50 for any of the values.</li> </ul>
<b>Default Value</b>	60,500,440
<b>Configuration File Reference</b>	BUSY_TONE_TIMING (Page 212)

### 4.6.4.3 Ringing Tone

#### Tone Frequencies

<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of ringback tones using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	440,480
<b>Configuration File Reference</b>	RINGBACK_TONE_FRQ (Page 214)

## Tone Timings

<b>Description</b>	Specifies the pattern, in milliseconds, of ringback tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
<b>Note</b>	<ul style="list-style-type: none"> <li>It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).</li> </ul>
<b>Value Range</b>	0–16000 (0: Infinite time)
<b>Note</b>	<ul style="list-style-type: none"> <li>Avoid setting 1–50 for any of the values.</li> </ul>
<b>Default Value</b>	60,2000,3940
<b>Configuration File Reference</b>	RINGBACK_TONE_TIMING (Page 214)

#### **4.6.4 Tone Settings**

#### **4.6.4.4 Stutter Tone**

## Tone Frequencies

<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of stutter dial tones to notify that a voice mail is waiting, using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	350,440
<b>Configuration File Reference</b>	DIAL_TONE4_FRQ (Page 211)

# Tone Timings

<b>Description</b>	Specifies the pattern, in milliseconds, of stutter dial tones to notify that a voice mail is waiting, using up to 22 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>It is recommended that you set a value of 560 milliseconds or more for the first value (off 1).</li> </ul>
<b>Value Range</b>	0–16000 (0: Infinite time)
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>Avoid setting 1–50 for any of the values.</li> </ul>
<b>Default Value</b>	560,100,100,100,100,100,100,100,100,100,100,100,100,100,100,100,0,100,100,100,100,100,0
<b>Configuration File Reference</b>	DIAL_TONE4_TIMING (Page 211)

#### 4.6.4.5 Reorder Tone

## Tone Frequencies

<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of reorder tones using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	480,620
<b>Configuration File Reference</b>	REORDER_TONE_FRQ (Page 213)

## Tone Timings

<b>Description</b>	Specifies the pattern, in milliseconds, of reorder tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
<b>Note</b>	<ul style="list-style-type: none"> <li>It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).</li> </ul>
<b>Value Range</b>	0–16000 (0: Infinite time)
<b>Default Value</b>	60,250,190
<b>Note</b>	<ul style="list-style-type: none"> <li>Avoid setting 1–50 for any of the values.</li> </ul>
<b>Configuration File Reference</b>	REORDER_TONE_TIMING (Page 213)

## 4.6.5 Telephone Settings

This screen allows you to configure various telephone settings.

### 4.6.5.1 Telephone Settings

#### Key Click Tone

<b>Description</b>	Selects whether a tone is heard in response to key presses.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	KEY_PAD_TONE (Page 208)

## Extension PIN

<b>Description</b>	Specifies the Personal Identification Number (PIN) of the extension. This is used to lock access to the call log and phonebook list. For details, refer to the Operating Instructions on the Panasonic Web site (→ see <b>Introduction</b> ).
<b>Value Range</b>	Max. 10 digits
<b>Default Value</b>	0000000000
<b>Configuration File Reference</b>	EXTENSION_PIN (Page 221)

## Number Matching Lower Digit

<b>Description</b>	Specifies the minimum number of digits with which to match a phonebook entry with an incoming call's caller ID. To specify exact matching of entire numbers only, specify "0".
<b>Value Range</b>	0–15
<b>Default Value</b>	7
<b>Configuration File Reference</b>	NUMBER_MATCHING_LOWER_DIGIT (Page 219)

## Number Matching Upper Digit

<b>Description</b>	Specifies the maximum number of digits with which to match a phonebook entry with an incoming call's caller ID. To specify exact matching of entire numbers only, specify "0".
<b>Value Range</b>	0–15
<b>Default Value</b>	10
<b>Configuration File Reference</b>	NUMBER_MATCHING_UPPER_DIGIT (Page 220)


## 4.6.6 Import Phonebook

This screen allows you to import phonebook data from a PC to the specified unit. For details, see **6.1.1 Import/Export Operation**.

### Note

- If the existing phonebook data has an entry with the same name and phone number as an imported entry, the imported entry is not added as a new entry.
- When you begin transferring the phonebook data, the "Now Processing File Data" screen is displayed, and the screen is periodically reloaded. Depending on your Web browser, the screen might not reload

automatically, and you will need to click the text "HERE" before the timer expires in order for the import operation to function properly.



### 4.6.6.1 Import Phonebook

#### File Name

<b>Description</b>	Specifies the path of the TSV (Tab-separated Value) file to import from the PC.
<b>Value Range</b>	No limitation  <b>Note</b> <ul style="list-style-type: none"> <li>There are no limitations for the field entry. However, it is recommended that paths of less than 256 characters be used: longer paths may cause longer data transfer times and result in an internal error.</li> </ul>
<b>Default Value</b>	Not stored.

### 4.6.7 Export Phonebook

This screen allows you to save the phonebook data stored in the unit as a TSV file on a PC. For details, see [6.1.1 Import/Export Operation](#).

#### Note

- When you begin transferring the phonebook data, the "Now Processing File Data" screen is displayed, and the screen is periodically reloaded. Click the text "HERE" in the message to display the **[Export Phonebook]** screen again. If you do not, the "Now Processing File Data" screen remains displayed even if the export is complete. Depending on your Web browser, the screen might not reload automatically, and you will need to click the text "HERE" before the timer expires in order for the export operation to function properly.
- Depending on the security settings of your Web browser, pop-up menus might be blocked at the time of export. The security warning window may be displayed on another screen even if the Pop-up Blocker

#### 4.6.8 Application Settings

settings are set to enable, and the file may not be exported successfully. In this case, try the export operation again or disable the Pop-up Blocker feature of your Web browser.

The screenshot shows the Panasonic KX-UT136 web interface. The top navigation bar includes links for Status, Network, System, VoIP, Telephone (which is highlighted in red), and Maintenance. On the left, a sidebar menu under the Telephone heading lists Call Control, Flexible Button Settings, Tone Settings, Telephone Settings, Import Phonebook, Export Phonebook (which is also highlighted in red), and Application Settings. The main content area is titled "Export Phonebook" and contains a sub-section titled "Export Phonebook" with the instruction "Click [Export] button to export the phonebook from this unit." A single "Export" button is present at the bottom of this section.

## 4.6.8 Application Settings

This screen allows you to configure the various URLs used with the XML application feature.

The screenshot shows the Panasonic KX-UT136 web interface. The top navigation bar includes links for Status, Network, System, VoIP, Telephone (which is highlighted in red), and Maintenance. On the left, a sidebar menu under the Telephone heading lists Call Control, Flexible Button Settings, Tone Settings, Telephone Settings, Import Phonebook, Export Phonebook, and Application Settings (which is highlighted in red). The main content area is titled "Application Settings" and contains several URL configuration sections: Application Bootup URL, Application initial URL, Incoming call URL, Talking URL, Making call URL, Call log URL, Idling URL, Network Phonebook URL, and Network Phonebook URL Authentication. Each section has a "URL" input field. At the bottom of the page are "Save" and "Cancel" buttons.

### 4.6.8.1 Application Bootup URL

#### URL

Description	Specifies the URL that is accessed when the unit starts up, to check for XML data.
-------------	--

<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_START_URL (Page 226)

#### 4.6.8.2 Application initial URL

##### URL

<b>Description</b>	Specifies the URL that is accessed when the application is started from the unit's menu, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_INITIAL_URL (Page 226)

#### 4.6.8.3 Incoming call URL

##### URL

<b>Description</b>	Specifies the URL that is accessed when the unit receives a call, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_INCOMING_URL (Page 226)

#### 4.6.8.4 Talking URL

##### URL

<b>Description</b>	Specifies the URL that is accessed when the unit is on a call, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_TALKING_URL (Page 227)

#### 4.6.8.5 Making call URL

##### URL

<b>Description</b>	Specifies the URL that is accessed when the unit makes a call, to check for XML data.
--------------------	---

#### 4.6.8 Application Settings

---

<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_MAKECALL_URL (Page 227)

#### 4.6.8.6 Call log URL

##### URL

<b>Description</b>	Specifies the URL that is accessed when the call log is accessed, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_CALLLOG_URL (Page 227)

#### 4.6.8.7 Idling URL

##### URL

<b>Description</b>	Specifies the URL that is accessed when the unit is idle, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_IDLING_URL (Page 227)

#### 4.6.8.8 Network Phone Book URL

##### URL

<b>Description</b>	Specifies the URL that is accessed when the phonebook is accessed, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_LDAP_URL (Page 228)

#### 4.6.8.9 Network Phone Book URL Authentication

##### Authentication ID

<b>Description</b>	Specifies the authentication ID required to access the network phonebook server.
--------------------	--

<b>Value Range</b>	Max. 127 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_LDAP_USERID (Page 228)

## Authentication Password


<b>Description</b>	Specifies the authentication password used to access the network phonebook server.
<b>Value Range</b>	Max. 127 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	XMLAPP_LDAP_USERPASS (Page 228)

# 4.7 Maintenance

This section provides detailed descriptions about all the settings classified under the [Maintenance] tab.

## 4.7.1 Firmware Maintenance

This screen allows you to perform firmware updates automatically or manually.



### 4.7.1.1 Firmware Maintenance

#### Enable Firmware Update

<b>Description</b>	Selects whether to perform firmware updates when the unit detects a newer version of firmware.
<b>Note</b>	<ul style="list-style-type: none"> <li>Changing this setting may require restarting the unit.</li> <li>Local firmware updates from the Web user interface (→ see <b>4.7.2 Local Firmware Update</b>) can be performed regardless of this setting.</li> <li>Firmware updates using TR-069 can be performed regardless of this setting.</li> </ul>

#### 4.7.2 Local Firmware Update

---

<b>Value Range</b>	<ul style="list-style-type: none"><li>• Yes</li><li>• No</li></ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	FIRM_UPGRADE_ENABLE (Page 175)

### Update Type

<b>Description</b>	Selects whether to display a confirmation message asking the user to perform a firmware update (manual) or perform the firmware update without asking the user (automatic) when the unit detects a newer version of firmware.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when <b>[Enable Firmware Update]</b> is set to <b>[Yes]</b>.</li><li>• Changing this setting may require restarting the unit.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>• Automatic</li><li>• Manual</li></ul>
<b>Default Value</b>	Automatic
<b>Configuration File Reference</b>	FIRM_UPGRADE_AUTO (Page 176)

### Firmware File URL


<b>Description</b>	Specifies the URL where the firmware file is stored.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when <b>[Enable Firmware Update]</b> is set to <b>[Yes]</b>.</li><li>• Changing this setting may require restarting the unit.</li></ul>
<b>Value Range</b>	Max. 500 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	FIRM_FILE_PATH (Page 176)

## 4.7.2 Local Firmware Update

This screen allows you to manually update the unit's firmware from a PC by clicking **[Update Firmware]**.

**Note**

- After the firmware has been successfully updated, the unit will restart automatically.



### 4.7.2.1 Local Firmware Update

#### Encryption

<b>Description</b>	Selects whether the firmware files are encrypted or not.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul>
<b>Default Value</b>	Yes

#### File Name

<b>Description</b>	Specifies the path of the firmware file to be imported.
<b>Value Range</b>	No limitation
<b>Note</b>	<ul style="list-style-type: none"> <li>There are no limitations for the field entry. However, it is recommended that paths of less than 256 characters be used: longer paths may cause longer data transfer times and result in an internal error.</li> </ul>
<b>Default Value</b>	Not stored.

### 4.7.3 Provisioning Maintenance

This screen allows you to change the provisioning setup to download the configuration files from the provisioning server of your phone system.

#### 4.7.3 Provisioning Maintenance

##### Note

- Each unit can accept up to 3 configuration files. For details about provisioning, see [2.2 Provisioning](#).

Panasonic

KX-UT136

Status Network System VoIP Telephone Maintenance

Web Port Close

Maintenance

Firmware Maintenance  
Local Firmware Update  
**Provisioning Maintenance**  
Management Server  
Reset to Defaults  
Restart

**Provisioning Maintenance**

Enable Provisioning	<input checked="" type="radio"/> Yes <input type="radio"/> No
Standard File URL	http://provisioning.e-connecting.net/redirect/cor
Product File URL	[ ]
Master File URL	[ ]
Cyclic Auto Resync	<input type="radio"/> Yes <input checked="" type="radio"/> No
Resync Interval	10060 minute(s) [1-40320]
Header Value for Resync Event	check-sync

Save Cancel

#### 4.7.3.1 Provisioning Maintenance

##### Enable Provisioning

<b>Description</b>	Selects whether the unit is automatically configured by downloading the configuration files from the provisioning server of your phone system.
<b>Note</b>	<ul style="list-style-type: none"><li>• Downloading configuration files using TR-069 can be performed regardless of this setting.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>• Yes</li><li>• No</li></ul>
<b>Default Value</b>	Yes
<b>Configuration File Reference</b>	PROVISION_ENABLE (Page 178)

##### Standard File URL

<b>Description</b>	Specifies the URL of the standard configuration file, which is used when every unit needs different settings.
<b>Note</b>	<ul style="list-style-type: none"><li>• When you change this setting, set <b>[Enable Provisioning]</b> to <b>[Yes]</b> at the same time.</li></ul>
<b>Value Range</b>	Max. 500 characters
<b>Default Value</b>	http://provisioning.e-connecting.net/redirect/conf/{mac}.cfg
<b>Configuration File Reference</b>	CFG_STANDARD_FILE_PATH (Page 178)

## Product File URL

<b>Description</b>	Specifies the URL of the product configuration file, which is used when all units with the same model number need the same settings.
<b>Note</b>	<ul style="list-style-type: none"> <li>When you change this setting, set [<b>Enable Provisioning</b>] to [<b>Yes</b>] at the same time.</li> </ul>
<b>Value Range</b>	Max. 500 characters
<b>Default Value</b>	Not stored.
<b>Note</b>	<ul style="list-style-type: none"> <li>The URL specified by your phone system dealer may be preset in the unit.</li> </ul>
<b>Configuration File Reference</b>	CFG_PRODUCT_FILE_PATH (Page 179)

## Master File URL

<b>Description</b>	Specifies the URL of the master configuration file, which is used when all units need the same settings.
<b>Note</b>	<ul style="list-style-type: none"> <li>When you change this setting, set [<b>Enable Provisioning</b>] to [<b>Yes</b>] at the same time.</li> </ul>
<b>Value Range</b>	Max. 500 characters
<b>Default Value</b>	Not stored.
<b>Note</b>	<ul style="list-style-type: none"> <li>The URL specified by your phone system dealer may be preset in the unit.</li> </ul>
<b>Configuration File Reference</b>	CFG_MASTER_FILE_PATH (Page 180)

## Cyclic Auto Resync

<b>Description</b>	Selects whether the unit periodically checks for updates of configuration files.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Yes</li> <li>No</li> </ul>
<b>Default Value</b>	No
<b>Configuration File Reference</b>	CFG_CYCLIC (Page 182)

#### 4.7.4 Management Server

##### Resync Interval

<b>Description</b>	Specifies the interval, in minutes, between periodic checks for updates of the configuration files.
<b>Value Range</b>	1–40320
<b>Default Value</b>	10080
<b>Configuration File Reference</b>	CFG_CYCLIC_INTVL (Page 183)

##### Header Value for Resync Event

<b>Description</b>	Specifies the value of the "Event" header sent from the SIP server to the unit so that the unit can access the configuration files on the provisioning server.
<b>Value Range</b>	Max. 15 characters <b>Note</b> <ul style="list-style-type: none"><li>You cannot leave this field empty.</li></ul>
<b>Default Value</b>	check-sync
<b>Configuration File Reference</b>	CFG_RESYNC_FROM_SIP (Page 184)

#### 4.7.4 Management Server

This screen allows you to configure the management server.

The screenshot shows the Panasonic KX-UT136 web interface. The top navigation bar includes links for Status, Network, System, VoIP, Telephone, and Maintenance. The Maintenance tab is selected. On the left, a sidebar under the Maintenance heading lists options: Web Port Close, Firmware Maintenance, Local Firmware Update, Provisioning Maintenance, Management Server (which is highlighted with a red box), Reset to Defaults, and Restart. The main content area is titled 'Management Server'. It contains two sections: 'Management Server' (with a 'Management Server URL' input field) and 'Management Server Authentication' (with 'Authentication ID' and 'Authentication Password' input fields). At the bottom of the form are 'Save' and 'Cancel' buttons.

## 4.7.4.1 Management Server

### Management Server URL

<b>Description</b>	Specifies the URL of the Auto-Configuration Server for using TR-069.
<b>Note</b>	<ul style="list-style-type: none"> <li>This parameter must be in the form of a valid HTTP or HTTPS URL, as defined in RFC 3986.</li> </ul>
<b>Value Range</b>	Max. 256 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	ACS_URL (Page 184)

## 4.7.4.2 Management Server Authentication

### Authentication ID

<b>Description</b>	Specifies the user ID for the Auto-Configuration Server for using TR-069.
<b>Value Range</b>	Max. 255 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	ACS_USER_ID (Page 184)

### Authentication Password

<b>Description</b>	Specifies the user password for the Auto-Configuration Server for using TR-069.
<b>Value Range</b>	Max. 255 characters
<b>Default Value</b>	Not stored.
<b>Configuration File Reference</b>	ACS_PASS (Page 185)

## 4.7.5 Reset to Defaults

This screen allows you to reset the settings made through the Web user interface to their default values by clicking [Reset Web Settings]. After you click this button, a dialog box is displayed, asking whether you want to reset the settings. Click **OK** to reset, or **Cancel** not to. For details about the reset, see **1.2.1.3 Resetting the Settings Made through the Web User Interface (Reset Web Settings)**.

### Notice

- After resetting the settings, the unit will restart even if it is being accessed through the phone user interface, or on calls.

#### 4.7.6 Restart

##### Note

- If you have changed the default password for the Administrator account and successfully reset the settings (the message "Complete" is displayed), the next time you access the Web user interface, the authentication dialog box appears.




#### 4.7.6 Restart

This screen allows you to restart the unit by clicking [**Restart**]. After you click this button, a dialog box is displayed, asking whether you want to restart the unit. Click **OK** to perform a restart, or **Cancel** not to.

##### Notice

- The unit will restart even if it is being accessed through the phone user interface, or on calls.



---

## **Section 5**

# ***Configuration File Programming***

*This section provides information about the configuration parameters used in the configuration files.*

# 5.1 Configuration File Parameter List

The following tables show all the parameters that can be programmed using configuration file programming. For details about each parameter, see the reference pages listed.

For details about configuration file specifications, see [2.4 Configuration File Specifications](#).

## System Settings

Category	Parameter Name	Ref.
Login Account Settings	<b>ADMIN_ID</b>	Page 167
	<b>ADMIN_PASS<sup>**</sup></b>	Page 167
	<b>USER_ID</b>	Page 168
	<b>USER_PASS<sup>**</sup></b>	Page 168
System Time Settings	<b>TIME_ZONE<sup>**</sup></b>	Page 168
	<b>DST_ENABLE<sup>**</sup></b>	Page 169
	<b>DST_OFFSET<sup>**</sup></b>	Page 169
	<b>DST_START_MONTH<sup>**</sup></b>	Page 170
	<b>DST_START_ORDINAL_DAY<sup>**</sup></b>	Page 170
	<b>DST_START_DAY_OF_WEEK<sup>**</sup></b>	Page 170
	<b>DST_START_TIME<sup>**</sup></b>	Page 171
	<b>DST_STOP_MONTH<sup>**</sup></b>	Page 171
	<b>DST_STOP_ORDINAL_DAY<sup>**</sup></b>	Page 172
	<b>DST_STOP_DAY_OF_WEEK<sup>**</sup></b>	Page 172
	<b>DST_STOP_TIME<sup>**</sup></b>	Page 172
	<b>LOCAL_TIME_ZONE_POSIX</b>	Page 173
Syslog Settings	<b>SYSLOG_EVENT_SIP</b>	Page 173
	<b>SYSLOG_EVENT_CFG</b>	Page 174
	<b>SYSLOG_EVENT_VOIP</b>	Page 174
	<b>SYSLOG_EVENT_TEL</b>	Page 174
	<b>SYSLOG_ADDR</b>	Page 174
	<b>SYSLOG_PORT</b>	Page 175
	<b>SYSLOG_RTPSMLY_INTVL_n</b>	Page 175

Category	Parameter Name	Ref.
Firmware Update Settings	<b>FIRM_UPGRADE_ENABLE<sup>*1</sup></b>	Page 175
	<b>FIRM_VERSION</b>	Page 176
	<b>FIRM_UPGRADE_AUTO<sup>*1</sup></b>	Page 176
	<b>FIRM_FILE_PATH<sup>*1</sup></b>	Page 176
Provisioning Settings	<b>OPTION66_ENABLE</b>	Page 177
	<b>OPTION66_REBOOT</b>	Page 177
	<b>PROVISION_ENABLE<sup>*1</sup></b>	Page 178
	<b>CFG_STANDARD_FILE_PATH<sup>*1</sup></b>	Page 178
	<b>CFG_PRODUCT_FILE_PATH<sup>*1</sup></b>	Page 179
	<b>CFG_MASTER_FILE_PATH<sup>*1</sup></b>	Page 180
	<b>CFG_FILE_KEY1</b>	Page 181
	<b>CFG_FILE_KEY2</b>	Page 182
	<b>CFG_FILE_KEY3</b>	Page 182
	<b>CFG_FILE_KEY_LENGTH</b>	Page 182
	<b>CFG_CYCLIC<sup>*1</sup></b>	Page 182
	<b>CFG_CYCLIC_INTVL<sup>*1</sup></b>	Page 183
	<b>CFG_RTRY_INTVL</b>	Page 183
	<b>CFG_RESYNC_TIME</b>	Page 183
	<b>CFG_RESYNC_DURATION</b>	Page 184
	<b>CFG_RESYNC_FROM_SIP<sup>*1</sup></b>	Page 184

## 5.1 Configuration File Parameter List

---

Category	Parameter Name	Ref.
Management Server Settings	<b>ACS_URL<sup>*1</sup></b>	Page 184
	<b>ACS_USER_ID<sup>*1</sup></b>	Page 184
	<b>ACS_PASS<sup>*1</sup></b>	Page 185
	<b>PERIODIC_INFORM_ENABLE</b>	Page 185
	<b>PERIODIC_INFORM_INTERVAL</b>	Page 185
	<b>PERIODIC_INFORM_TIME</b>	Page 185
	<b>CON_REQ_USER_ID</b>	Page 186
	<b>CON_REQ_PASS</b>	Page 186
	<b>ANNEX_G_STUN_ENABLE</b>	Page 187
	<b>ANNEX_G_STUN_SERV_ADDR</b>	Page 187
	<b>ANNEX_G_STUN_SERV_PORT</b>	Page 187
	<b>ANNEX_G_STUN_USER_ID</b>	Page 187
	<b>ANNEX_G_STUN_PASS</b>	Page 188
	<b>ANNEX_G_STUN_MAX_KEEP_ALIVE</b>	Page 188
	<b>ANNEX_G_STUN_MIN_KEEP_ALIVE</b>	Page 188
	<b>UDP_CON_REQ_ADDR_NOTIFY_LIMIT</b>	Page 189

<sup>\*1</sup> This setting can also be configured through the Web user interface.

## Network Settings

---

Category	Parameter Name	Ref.
IP Settings	<b>CONNECTION_TYPE<sup>*1</sup></b>	Page 189
	<b>HOST_NAME<sup>*2</sup></b>	Page 190
	<b>DHCP_DNS_ENABLE<sup>*1</sup></b>	Page 190
	<b>STATIC_IP_ADDRESS<sup>*1</sup></b>	Page 190
	<b>STATIC_SUBNET<sup>*1</sup></b>	Page 191
	<b>STATIC_GATEWAY<sup>*1</sup></b>	Page 191
	<b>USER_DNS1_ADDR<sup>*1</sup></b>	Page 192
	<b>USER_DNS2_ADDR<sup>*1</sup></b>	Page 192
DNS Settings	<b>DNS_QRY_PRLL</b>	Page 192
	<b>DNS_PRIORITY</b>	Page 193
	<b>DNS1_ADDR</b>	Page 193
	<b>DNS2_ADDR</b>	Page 193

Category	Parameter Name	Ref.
Ethernet Port Settings	<b>VLAN_ENABLE</b> <sup>*1</sup>	Page 194
	<b>VLAN_ID_IP_PHONE</b> <sup>*1</sup>	Page 194
	<b>VLAN_PRI_IP_PHONE</b> <sup>*1</sup>	Page 194
	<b>VLAN_ID_PC</b> <sup>*1</sup>	Page 195
	<b>VLAN_PRI_PC</b> <sup>*1</sup>	Page 195
IEEE 802.1X Settings (KX-UT248 only)	<b>IEEE8021X_ENABLE</b> <sup>*2</sup>	Page 195
	<b>IEEE8021X_AUTH_PRTCL</b> <sup>*2</sup>	Page 196
	<b>IEEE8021X_USER_ID</b> <sup>*2</sup>	Page 196
	<b>IEEE8021X_USER_PASS</b> <sup>*2</sup>	Page 196
HTTP Settings	<b>HTTPD_PORTOPEN_AUTO</b>	Page 197
	<b>HTTP_VER</b> <sup>*2</sup>	Page 197
	<b>HTTP_USER_AGENT</b> <sup>*2</sup>	Page 197
	<b>HTTP_SSL_VERIFY</b>	Page 198
	<b>CFG_ROOT_CERTIFICATE_PATH</b>	Page 198
Time Adjust Settings	<b>NTP_ADDR</b> <sup>*2</sup>	Page 199
	<b>TIME_SYNC_INTVL</b>	Page 199
	<b>TIME_QUERY_INTVL</b> <sup>*2</sup>	Page 199
STUN Settings	<b>STUN_SERV_ADDR</b> <sup>*2</sup>	Page 200
	<b>STUN_SERV_PORT</b> <sup>*2</sup>	Page 200
	<b>STUN_2NDSERV_ADDR</b>	Page 200
	<b>STUN_2NDSERV_PORT</b>	Page 200
Miscellaneous Network Settings	<b>NW_SETTING_ENABLE</b>	Page 201
	<b>CUSTOM_WEB_PAGE</b>	Page 201
LLDP-MED Settings	<b>LLDP_ENABLE</b>	Page 201
	<b>LLDP_INTERVAL</b>	Page 202
	<b>LLDP_VLAN_ID_PC</b>	Page 202
	<b>LLDP_VLAN_PRI_PC</b>	Page 202

<sup>\*1</sup> This setting can also be configured through other programming methods (phone user interface programming or Web user interface programming).

<sup>\*2</sup> This setting can also be configured through the Web user interface.

## Telephone Settings

Category	Parameter Name	Ref.
Call Control Settings	<b>VM_SUBSCRIBE_ENABLE<sup>**</sup></b>	Page 202
	<b>CONFERENCE_SERVER_URI<sup>**</sup></b>	Page 203
	<b>FIRSTDIGIT_TIM</b>	Page 203
	<b>INTDIGIT_TIM<sup>**</sup></b>	Page 203
	<b>MACRODIGIT_TIM<sup>**</sup></b>	Page 203
	<b>INTERNATIONAL_ACCESS_CODE<sup>**</sup></b>	Page 204
	<b>COUNTRY_CALLING_CODE<sup>**</sup></b>	Page 204
	<b>NATIONAL_ACCESS_CODE<sup>**</sup></b>	Page 204
	<b>DEFAULT_LINE_SELECT<sup>**</sup></b>	Page 204
	<b>DATA_LINE_MODE</b>	Page 205
	<b>NUM_PLAN_PICKUP_DIRECT<sup>**</sup></b>	Page 205
	<b>TALK_PACKAGE</b>	Page 205
	<b>HOLD_PACKAGE</b>	Page 206
	<b>HOLD_RECALL_TIM</b>	Page 206
	<b>AUTO_ANS_RING_TIM</b>	Page 206
	<b>RINGING_OFF_SETTING_ENABLE</b>	Page 206
	<b>AUTO_CALL_HOLD</b>	Page 207
	<b>REDIALKEY_CALLOG_ENABLE</b>	Page 207
	<b>ONHOOK_TRANSFER_ENABLE</b>	Page 207
	<b>DISCONNECTION_MODE</b>	Page 207
	<b>TONE_LEN_DISCONNECT_HANDSET</b>	Page 207
	<b>TONE_LEN_DISCONNECT_HANDSFREE</b>	Page 208
	<b>KEY_PAD_TONE<sup>**</sup></b>	Page 208
	<b>HOLD_AND_CALL_ENABLE</b>	Page 208
	<b>HOLD_TRANSFER_OPERATION</b>	Page 208

Category	Parameter Name	Ref.
Tone Settings	DIAL_TONE1_FRQ <sup>*1</sup>	Page 209
	DIAL_TONE1_GAIN	Page 209
	DIAL_TONE1_RPT	Page 209
	DIAL_TONE1_TIMING <sup>*1</sup>	Page 209
	DIAL_TONE2_FRQ	Page 210
	DIAL_TONE2_GAIN	Page 210
	DIAL_TONE2_RPT	Page 210
	DIAL_TONE2_TIMING	Page 211
	DIAL_TONE4_FRQ <sup>*1</sup>	Page 211
	DIAL_TONE4_GAIN	Page 211
	DIAL_TONE4_RPT	Page 211
	DIAL_TONE4_TIMING <sup>*1</sup>	Page 211
	BUSY_TONE_FRQ <sup>*1</sup>	Page 212
	BUSY_TONE_GAIN	Page 212
	BUSY_TONE_RPT	Page 212
	BUSY_TONE_TIMING <sup>*1</sup>	Page 212
	REORDER_TONE_FRQ <sup>*1</sup>	Page 213
	REORDER_TONE_GAIN	Page 213
	REORDER_TONE_RPT	Page 213
	REORDER_TONE_TIMING <sup>*1</sup>	Page 213
	RINGBACK_TONE_FRQ <sup>*1</sup>	Page 214
	RINGBACK_TONE_GAIN	Page 214
	RINGBACK_TONE_RPT	Page 214
	RINGBACK_TONE_TIMING <sup>*1</sup>	Page 214
	HOLD_ALARM_FRQ	Page 215
	HOLD_ALARM_GAIN	Page 215
	HOLD_ALARM_RPT	Page 215
	HOLD_ALARM_TIMING	Page 215
	CW_TONE1_FRQ	Page 216
	CW_TONE1_GAIN	Page 216

## 5.1 Configuration File Parameter List

---

Category	Parameter Name	Ref.
	<b>CW_TONE1_RPT</b>	Page 216
	<b>CW_TONE1_TIMING</b>	Page 216
	<b>HOLD_TONE_FRQ</b>	Page 217
	<b>HOLD_TONE_GAIN</b>	Page 217
	<b>HOLD_TONE_RPT</b>	Page 217
	<b>HOLD_TONE_TIMING</b>	Page 217
	<b>BELL_CORE_PATTERN1_TIMING</b>	Page 218
	<b>BELL_CORE_PATTERN2_TIMING</b>	Page 218
	<b>BELL_CORE_PATTERN3_TIMING</b>	Page 218
	<b>BELL_CORE_PATTERN4_TIMING</b>	Page 219
Telephone Settings	<b>BELL_CORE_PATTERN5_TIMING</b>	Page 219
	<b>DISPLAY_NAME_REPLACE</b>	Page 219
	<b>NUMBER_MATCHING_LOWER_DIGIT<sup>1</sup></b>	Page 219
	<b>NUMBER_MATCHING_UPPER_DIGIT<sup>1</sup></b>	Page 220
	<b>DISPLAY_DATE_PATTERN</b>	Page 220
	<b>DISPLAY_TIME_PATTERN</b>	Page 220
	<b>DEFAULT_LANGUAGE</b>	Page 220
	<b>EXTENSION_PIN<sup>1</sup></b>	Page 221
Miscellaneous Telephone Settings	<b>POUND_KEY_DELIMITER_ENABLE</b>	Page 221
	<b>ADJDATA_GAIN</b>	Page 222
Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only)	<b>ADJDATA_ATT (KX-UT113/KX-UT123/KX-UT133/KX-UT136 only)</b>	Page 223
	<b>FLEX_BUTTON_FACILITY_ACTx<sup>1</sup></b>	Page 224
	<b>FLEX_BUTTON_FACILITY_ARGx<sup>1</sup></b>	Page 224
	<b>FLEX_BUTTON_QUICK_DIALx<sup>1</sup></b>	Page 224
	<b>FLEX_BUTTON_LABELx<sup>1</sup></b>	Page 225

Category	Parameter Name	Ref.
XML Application Settings	<code>XMLAPP_ENABLE</code> <sup>*</sup>	Page 225
	<code>XMLAPP_USERID</code> <sup>*</sup>	Page 225
	<code>XMLAPP_USERPASS</code> <sup>*</sup>	Page 226
	<code>XMLAPP_START_URL</code> <sup>*</sup>	Page 226
	<code>XMLAPP_INITIAL_URL</code> <sup>*</sup>	Page 226
	<code>XMLAPP_INCOMING_URL</code> <sup>*</sup>	Page 226
	<code>XMLAPP_TALKING_URL</code> <sup>*</sup>	Page 227
	<code>XMLAPP_MAKECALL_URL</code> <sup>*</sup>	Page 227
	<code>XMLAPP_CALLLOG_URL</code> <sup>*</sup>	Page 227
	<code>XMLAPP_IDLING_URL</code> <sup>*</sup>	Page 227
	<code>XMLAPP_LDAP_URL</code> <sup>*</sup>	Page 228
	<code>XMLAPP_LDAP_USERID</code> <sup>*</sup>	Page 228
	<code>XMLAPP_LDAP_USERPASS</code> <sup>*</sup>	Page 228
	<code>XML_INITIATE_KEY_SOFT1</code>	Page 228
	<code>XML_INITIATE_KEY_SOFT2</code>	Page 229
	<code>XML_INITIATE_KEY_SOFT3</code>	Page 229
	<code>XML_INITIATE_KEY_SOFT4</code>	Page 229
	<code>XML_INITIATE_KEY_FWDDND</code>	Page 229
	<code>XML_INITIATE_KEY_FLASH</code>	Page 229
	<code>XML_ERROR_INFORMATION</code>	Page 230
	<code>XML_HTTPD_PORT</code>	Page 230

\*1 This setting can also be configured through the Web user interface.

## VoIP Settings

Category	Parameter Name	Ref.
Codec Settings	<code>CODEC_G711_REQ</code>	Page 230
	<code>CODEC_G729_PARAM</code>	Page 231
	<code>CODEC_ENABLEx_n</code> <sup>*</sup>	Page 231
	<code>CODEC_PRIORITYx_n</code> <sup>*</sup>	Page 231

## 5.1 Configuration File Parameter List

---

Category	Parameter Name	Ref.
RTP Settings	<b>DSCP_RTP_n</b> <sup>*</sup>	Page 232
	<b>DSCP_RTCP_n</b> <sup>*</sup>	Page 232
	<b>RTCP_INTVL_n</b> <sup>*</sup>	Page 233
	<b>MAX_DELAY_n</b> <sup>*</sup>	Page 233
	<b>MIN_DELAY_n</b> <sup>*</sup>	Page 233
	<b>NOM_DELAY_n</b> <sup>*</sup>	Page 234
	<b>RTP_PORT_MIN</b> <sup>*</sup>	Page 234
	<b>RTP_PORT_MAX</b> <sup>*</sup>	Page 234
	<b>RTP_PTIME</b> <sup>*</sup>	Page 235
	<b>RTCP_ENABLE_n</b> <sup>*</sup>	Page 235
	<b>RTCP_SEND_BY_SDP_n</b>	Page 236
	<b>RTP_CLOSE_ENABLE_n</b>	Page 236
Miscellaneous VoIP Settings	<b>OUTBANDDTMF_n</b> <sup>*</sup>	Page 236
	<b>DTMF_RELAY_n</b> <sup>*</sup>	Page 237
	<b>OUTBANDDTMF_VOL</b>	Page 237
	<b>INBANDDTMF_VOL</b>	Page 237
	<b>TELEVENT_PAYLOAD</b> <sup>*</sup>	Page 237
	<b>RFC2543_HOLD_ENABLE_n</b> <sup>*</sup>	Page 238
	<b>DTMF_SIGNAL_LEN</b>	Page 238
	<b>DTMF_INTDIGIT_TIM</b>	Page 238

<sup>\*</sup>1 This setting can also be configured through the Web user interface.

## Line Settings

Category	Parameter Name	Ref.
Call Control Settings	<b>DISPLAY_NAME_n</b> <sup>*</sup>	Page 239
	<b>VM_NUMBER_n</b> <sup>*</sup>	Page 239
	<b>DIAL_PLAN_n</b> <sup>*</sup>	Page 239
	<b>DIAL_PLAN_NOT_MATCH_ENABLE_n</b> <sup>*</sup>	Page 240
	<b>SHARED_CALL_ENABLE_n</b> <sup>*</sup>	Page 240
	<b>FWD_DND_SYNCHRO_ENABLE_n</b> <sup>*</sup>	Page 241
	<b>RESOURCELIST_URI_n</b> <sup>*</sup>	Page 241
	<b>CW_ENABLE_n</b>	Page 242
	<b>RETURN_VOL_SET_DEFAULT_ENABLE</b>	Page 242
	<b>FLASH_RECALL_TERMINATE</b> <sup>*</sup>	Page 242
	<b>FLASHHOOK_CONTENT_TYPE</b> <sup>*</sup>	Page 242
	<b>VOICE_MESSAGE_AVAILABLE</b>	Page 243
	<b>HOLD_SOUND_PATH_n</b>	Page 243
SIP Settings	<b>SIP_USER_AGENT</b> <sup>*</sup>	Page 243
	<b>PHONE_NUMBER_n</b> <sup>*</sup>	Page 244
	<b>SIP_URI_n</b> <sup>*</sup>	Page 244
	<b>LINE_ENABLE_n</b>	Page 245
	<b>PROFILE_ENABLEn</b>	Page 245
	<b>SIP_AUTHID_n</b> <sup>*</sup>	Page 245
	<b>SIP_PASS_n</b> <sup>*</sup>	Page 246
	<b>SIP_SRC_PORT_n</b> <sup>*</sup>	Page 246
	<b>SIP_PRXY_ADDR_n</b> <sup>*</sup>	Page 246
	<b>SIP_PRXY_PORT_n</b> <sup>*</sup>	Page 246
	<b>SIP_RGSTR_ADDR_n</b> <sup>*</sup>	Page 247
	<b>SIP_RGSTR_PORT_n</b> <sup>*</sup>	Page 247
	<b>SIP_SVCDOMAIN_n</b> <sup>*</sup>	Page 247
	<b>REG_EXPIRE_TIME_n</b>	Page 248
	<b>REG_INTERVAL_RATE_n</b>	Page 248
	<b>SIP_SESSION_TIME_n</b> <sup>*</sup>	Page 248
	<b>SIP_SESSION_METHOD_n</b>	Page 248
	<b>DSCP_SIP_n</b> <sup>*</sup>	Page 249

## 5.1 Configuration File Parameter List

---

Category	Parameter Name	Ref.
	<b>SIP_2NDPROXY_ADDR_n</b>	Page 249
	<b>SIP_2NDPROXY_PORT_n</b>	Page 249
	<b>SIP_2NDRGSTR_ADDR_n</b>	Page 250
	<b>SIP_2NDRGSTR_PORT_n</b>	Page 250
	<b>SIP_TIMER_T1_n<sup>*</sup></b>	Page 250
	<b>SIP_TIMER_T2_n<sup>*</sup></b>	Page 250
	<b>SIP_TIMER_T4_n</b>	Page 251
	<b>SIP_FOVR_NORSP_n</b>	Page 251
	<b>SIP_FOVR_MAX_n</b>	Page 252
	<b>SIP_REFRESHER_n</b>	Page 252
	<b>SIP_DNSSRV_ENA_n<sup>*</sup></b>	Page 252
	<b>SIP_UDP_SRV_PREFIX_n<sup>*</sup></b>	Page 253
	<b>SIP_TCP_SRV_PREFIX_n<sup>*</sup></b>	Page 253
	<b>SIP_100REL_ENABLE_n<sup>*</sup></b>	Page 253
	<b>SIP_INVITE_EXPIRE_n</b>	Page 254
	<b>SIP_18X_RTX_INTVL_n</b>	Page 254
	<b>SIP_PRSNC_ADDR_n<sup>*</sup></b>	Page 254
	<b>SIP_PRSNC_PORT_n<sup>*</sup></b>	Page 255
	<b>SIP_2NDPRSNC_ADDR_n</b>	Page 255
	<b>SIP_2NDPRSNC_PORT_n</b>	Page 255
	<b>USE_DEL_REG_OPEN_n</b>	Page 255
	<b>USE_DEL_REG_CLOSE_n</b>	Page 256
	<b>PORT_PUNCH_INTVL_n<sup>*</sup></b>	Page 256
	<b>SIP_ADD_RPORT_n<sup>*</sup></b>	Page 256
	<b>SIP_REQURI_PORT_n</b>	Page 257
	<b>SIP_SUBS_EXPIRE_n</b>	Page 257
	<b>SUB_RTX_INTVL_n</b>	Page 257
	<b>REG_RTX_INTVL_n</b>	Page 258
	<b>SIP_P_PREFERRED_ID_n</b>	Page 258
	<b>SIP_PRIVACY_n</b>	Page 258
	<b>ADD_USER_PHONE_n</b>	Page 259
	<b>SDP_USER_ID_n</b>	Page 259
	<b>SUB_INTERVAL_RATE_n</b>	Page 259

Category	Parameter Name	Ref.
	SIP_OUTPROXY_ADDR_n <sup>*1</sup>	Page 259
	SIP_OUTPROXY_PORT_n <sup>*1</sup>	Page 260
	SIP_TRANSPORT_n <sup>*1</sup>	Page 260
	SIP_ANM_DISPNAME_n	Page 260
	SIP_ANM_USERNAME_n	Page 261
	SIP_ANM_HOSTNAME_n	Page 261
	SIP_DETECT_SSAF_n <sup>*1</sup>	Page 261
	SIP_RCV_DET_HEADER_n	Page 262
	SIP_CONTACT_ON_ACK_n	Page 262
	SIP_TIMER_B_n <sup>*1</sup>	Page 262
	SIP_TIMER_D_n <sup>*1</sup>	Page 262
	SIP_TIMER_F_n <sup>*1</sup>	Page 263
	SIP_TIMER_H_n <sup>*1</sup>	Page 263
	SIP_TIMER_J_n <sup>*1</sup>	Page 263
	ADD_TRANSPORT_UDP_n	Page 264
	ADD_EXPIRES_HEADER_n	Page 264
	SIP_HOLD_HOLDRECEIVE_n	Page 264
	SIP_ADD_DIVERSION_n	Page 264
	SIP_RESPONSE_CODE_DND	Page 265
	SIP_RESPONSE_CODE_CALL_REJECT	Page 265
	SIP_FOVR_MODE_n	Page 265
	SIP_FOVR_DURATION_n	Page 265
	SIP_ADD_ROUTE_n	Page 266
	SIP_403_REG_SUB_RTX_n	Page 266

<sup>\*1</sup> This setting can also be configured through the Web user interface.

## 5.2 General Information on the Configuration Files

### 5.2.1 Configuration File Parameters

The information on each parameter that can be written in a configuration file is shown in the tables below. The information includes parameter name (as the title of the table), value format, description, permitted value range, default value of each parameter, phone user interface reference, and Web user interface reference.

### Parameter Name

This is the system-predefined parameter name and cannot be changed.

### Note

- Certain parameter names end with "\_n". This signifies that these settings can be made to each line individually. The number of lines available varies depending on the phone being used, as follows:
  - KX-UT113/KX-UT123: 1–2
  - KX-UT133/KX-UT136: 1–4
  - KX-UT248: 1–6

### Value Format

Each parameter value is categorized into Integer, Boolean, or String. Some parameters require a composite form such as "Comma-separated Integer" or "Comma-separated String".

- **Integer:** a numerical value, described as a sequence of numerical characters, optionally preceded by a "-" (minus)  
An empty string is not allowed.
- **Boolean:** "Y" or "N"
- **String:** sequence of alphanumerical characters  
For details about available characters, see **5.2.2 Characters Available for String Values**.
- **Comma-separated Integer:** a list of integers, separated by commas  
No space characters are allowed.
- **Comma-separated String:** a list of strings, separated by commas  
No space characters are allowed.

### Description

Describes the details of the parameter.

### Value Range

Indicates the permitted value range of the parameter.

### Default Value

Indicates the factory default value of the parameter.

Actual default values may vary depending on your phone system dealer.

### Phone User Interface Reference

Provides the reference page of the corresponding parameter in phone user interface programming.

### Web User Interface Reference

Provides the reference page of the corresponding parameter in Web user interface programming.

## 5.2.2 Characters Available for String Values

Unless noted otherwise in "Value Range", only ASCII characters can be used for parameter values. Unicode characters can also be used in some parameter values.

Available ASCII characters are shown on a white background in the following table:

	<b>00</b>	<b>01</b>	<b>02</b>	<b>03</b>	<b>04</b>	<b>05</b>	<b>06</b>	<b>07</b>	<b>08</b>	<b>09</b>	<b>0A</b>	<b>0B</b>	<b>0C</b>	<b>0D</b>	<b>0E</b>	<b>0F</b>
<b>20</b>	SP	!	"	#	\$	%	&	'	(	)	*	+	,	-	.	/
<b>30</b>	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?
<b>40</b>	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O
<b>50</b>	P	Q	R	S	T	U	V	W	X	Y	Z	[	\	]	^	_
<b>60</b>	'	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o
<b>70</b>	p	q	r	s	t	u	v	w	x	y	z	{		}	~	

## 5.3 System Settings

### 5.3.1 Login Account Settings

#### [ADMIN\\_ID](#)

<b>Value Format</b>	String
<b>Description</b>	Specifies the account ID used to access the Web user interface with the Administrator account.
<b>Value Range</b>	Max. 16 characters (except ", & ', :, <, >, and space)
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>An empty string is not allowed.</li> </ul>
<b>Default Value</b>	admin

#### [ADMIN\\_PASS](#)

<b>Value Format</b>	String
<b>Description</b>	Specifies the password to use to authenticate the Administrator account when logging in to the Web user interface.
<b>Value Range</b>	6–16 characters (except ", & ', :, <, >, and space)
<b>Default Value</b>	adminpass
<b>Web User Interface Reference</b>	<ul style="list-style-type: none"> <li>Current Password (Page 95)</li> <li>New Password (Page 95)</li> <li>Confirm New Password (Page 96)</li> </ul>

### 5.3.2 System Time Settings

---

#### USER\_ID

<b>Value Format</b>	String
<b>Description</b>	Specifies the account ID used to access the Web user interface with the User account.
<b>Value Range</b>	Max. 16 characters (except ", &, :, <, >, and space) <b>Note</b> <ul style="list-style-type: none"><li>• An empty string is not allowed.</li></ul>
<b>Default Value</b>	user

#### USER\_PASS

<b>Value Format</b>	String
<b>Description</b>	Specifies the password to use to authenticate the User account when logging in to the Web user interface.
<b>Value Range</b>	6–16 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string (only before a user accesses the Web user interface for the first time)
<b>Web User Interface Reference</b>	<ul style="list-style-type: none"><li>• Current Password (Page 96)</li><li>• New Password (Page 97)</li><li>• Confirm New Password (Page 97)</li></ul>

### 5.3.2 System Time Settings

#### TIME\_ZONE

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the offset of local standard time from UTC (GMT), in minutes.

<b>Value Range</b>	-720–780
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>Only the following values are available: -720 (GMT -12:00), -660 (GMT -11:00), -600 (GMT -10:00), -540 (GMT -09:00), -480 (GMT -08:00), -420 (GMT -07:00), -360 (GMT -06:00), -300 (GMT -05:00), -240 (GMT -04:00), -210 (GMT -03:30), -180 (GMT -03:00), -120 (GMT -02:00), -60 (GMT -01:00), 0 (GMT), 60 (GMT +01:00), 120 (GMT +02:00), 180 (GMT +03:00), 210 (GMT +03:30), 240 (GMT +04:00), 270 (GMT +04:30), 300 (GMT +05:00), 330 (GMT +05:30), 345 (GMT +05:45), 360 (GMT +06:00), 390 (GMT +06:30), 420 (GMT +07:00), 480 (GMT +08:00), 540 (GMT +09:00), 570 (GMT +09:30), 600 (GMT +10:00), 660 (GMT +11:00), 720 (GMT +12:00), 780 (GMT +13:00)</li> <li>If your location is west of Greenwich (0 [GMT]), the value should be minus. For example, the value for New York City, U.S.A. is "-300" (Eastern Standard Time being 5 hours behind GMT).</li> <li>This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.</li> </ul>
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	Time Zone (Page 100)

## DST\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable DST (Summer Time).
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>Y</b> (Enable DST [Summer Time])</li> <li><b>N</b> (Disable DST [Summer Time])</li> </ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	Enable DST (Enable Summer Time) (Page 100)

## DST\_OFFSET

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the amount of time, in minutes, to change the time when "DST_ENABLE" is set to "Y".
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.</li> </ul>

### 5.3.2 System Time Settings

---

<b>Value Range</b>	0–720
	<b>Note</b> <ul style="list-style-type: none"><li>This parameter is usually set to "60".</li></ul>
<b>Default Value</b>	60
<b>Web User Interface Reference</b>	DST Offset (Summer Time Offset) (Page 100)

## DST\_START\_MONTH

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the month in which DST (Summer Time) starts.
	<b>Note</b> <ul style="list-style-type: none"><li>This parameter is disabled when the "<code>LOCAL_TIME_ZONE_POSIX</code>" parameter is specified.</li></ul>
<b>Value Range</b>	1–12
<b>Default Value</b>	3
<b>Web User Interface Reference</b>	Month (Page 101)

## DST\_START\_ORDINAL\_DAY

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the number of the week on which DST (Summer Time) starts. The actual start day is specified in " <code>DST_START_DAY_OF_WEEK</code> ". For example, to specify the second Sunday, specify "2" in this parameter, and "0" in the next parameter.
	<b>Note</b> <ul style="list-style-type: none"><li>This parameter is disabled when the "<code>LOCAL_TIME_ZONE_POSIX</code>" parameter is specified.</li></ul>
<b>Value Range</b>	1–5 <ul style="list-style-type: none"><li>1: the first week of the month</li><li>2: the second week of the month</li><li>3: the third week of the month</li><li>4: the fourth week of the month</li><li>5: the fifth week of the month</li></ul>
<b>Default Value</b>	2
<b>Web User Interface Reference</b>	Day of Week (Page 101)

## DST\_START\_DAY\_OF\_WEEK

---

<b>Value Format</b>	Integer
---------------------	---------

<b>Description</b>	Specifies the day of the week on which DST (Summer Time) starts.
<b>Note</b>	<ul style="list-style-type: none"> <li>This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.</li> </ul>
<b>Value Range</b>	0–6 – 0: Sunday – 1: Monday – 2: Tuesday – 3: Wednesday – 4: Thursday – 5: Friday – 6: Saturday
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	Day of Week (Page 101)

## DST\_START\_TIME

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the start time of DST (Summer Time) in minutes after 12:00 AM.
<b>Note</b>	<ul style="list-style-type: none"> <li>This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.</li> </ul>
<b>Value Range</b>	0–1439
<b>Default Value</b>	120
<b>Web User Interface Reference</b>	Time (Page 102)

## DST\_STOP\_MONTH

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the month in which DST (Summer Time) ends.
<b>Note</b>	<ul style="list-style-type: none"> <li>This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.</li> </ul>
<b>Value Range</b>	1–12
<b>Default Value</b>	10
<b>Web User Interface Reference</b>	Month (Page 102)

## DST\_STOP\_ORDINAL\_DAY

<b>Value Format</b>	Integer
<b>Description</b>	<p>Specifies the number of the week on which DST (Summer Time) ends. The actual end day is specified in "DST_STOP_DAY_OF_WEEK". For example, to specify the second Sunday, specify "2" in this parameter, and "0" in the next parameter.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.</li> </ul>
<b>Value Range</b>	<p>1–5</p> <ul style="list-style-type: none"> <li>– 1: the first week of the month</li> <li>– 2: the second week of the month</li> <li>– 3: the third week of the month</li> <li>– 4: the fourth week of the month</li> <li>– 5: the fifth week of the month</li> </ul>
<b>Default Value</b>	2
<b>Web User Interface Reference</b>	Day of Week (Page 102)

## DST\_STOP\_DAY\_OF\_WEEK

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the day of the week on which DST (Summer Time) ends.
<b>Note</b>	<ul style="list-style-type: none"> <li>• This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.</li> </ul>
<b>Value Range</b>	<p>0–6</p> <ul style="list-style-type: none"> <li>– 0: Sunday</li> <li>– 1: Monday</li> <li>– 2: Tuesday</li> <li>– 3: Wednesday</li> <li>– 4: Thursday</li> <li>– 5: Friday</li> <li>– 6: Saturday</li> </ul>
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	Day of Week (Page 102)

## DST\_STOP\_TIME

<b>Value Format</b>	Integer
---------------------	---------

<b>Description</b>	Specifies the end time of DST (Summer Time) in minutes after 12:00 AM.
<b>Note</b>	<ul style="list-style-type: none"> <li>This parameter is disabled when the "LOCAL_TIME_ZONE_POSIX" parameter is specified.</li> </ul>
<b>Value Range</b>	0–1439
<b>Default Value</b>	120
<b>Web User Interface Reference</b>	Time (Page 103)

## LOCAL\_TIME\_ZONE\_POSIX

<b>Value Format</b>	String
<b>Description</b>	Specifies a IEEE 1003.1 (POSIX)-compliant local time zone definition (e.g., "EST+5:00:00EDT+4:00:00,M4.1.0/2:00:00,M10.5.0/2:00:00").
<b>Note</b>	<ul style="list-style-type: none"> <li>If this parameter is specified, the following parameters are disabled, and operation will be based on this parameter.           <ul style="list-style-type: none"> <li>TIME_ZONE</li> <li>DST_ENABLE</li> <li>DST_OFFSET</li> <li>DST_START_MONTH</li> <li>DST_START_ORDINAL_DAY</li> <li>DST_START_DAY_OF_WEEK</li> <li>DST_START_TIME</li> <li>DST_STOP_MONTH</li> <li>DST_STOP_ORDINAL_DAY</li> <li>DST_STOP_DAY_OF_WEEK</li> <li>DST_STOP_TIME</li> </ul> </li> </ul>
<b>Value Range</b>	Max. 70 characters
<b>Default Value</b>	Empty string

## 5.3.3 Syslog Settings

### SYSLOG\_EVENT\_SIP

<b>Value Format</b>	Integer
<b>Description</b>	Specifies which SIP-related syslog events are sent to the syslog server.

**Note**

- If the level of the event is higher than or equal to the set value, the log is sent to the syslog server.

### 5.3.3 Syslog Settings

---

<b>Value Range</b>	0–6 <ul style="list-style-type: none"><li>– 0: no logs sent</li><li>– 1: emergency (highest)</li><li>– 2: alert</li><li>– 3: critical</li><li>– 4: error</li><li>– 5: warning</li><li>– 6: information (lowest)</li></ul>
<b>Default Value</b>	0

## SYSLOG\_EVENT\_CFG

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the threshold of syslog events regarding configuration.
<b>Value Range</b>	0–6
<b>Default Value</b>	0

## SYSLOG\_EVENT\_VOIP

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the threshold of syslog events regarding VoIP operation.
<b>Value Range</b>	0–6
<b>Default Value</b>	0

## SYSLOG\_EVENT\_TEL

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the threshold of syslog events regarding telephone functions.
	<b>Note</b> <ul style="list-style-type: none"><li>• This setting is not applicable for the current version. No logs will be sent to the syslog server, even if values "1–6" are specified.</li></ul>
<b>Value Range</b>	0–6
<b>Default Value</b>	0

## SYSLOG\_ADDR

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address or FQDN of the syslog server.
<b>Value Range</b>	Max. 127 characters (IP address in dotted-decimal notation or FQDN)

<b>Default Value</b>	Empty string
----------------------	--------------

## SYSLOG\_PORT

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number of the syslog server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	514

## SYSLOG\_RTPSMLY\_INTVL\_n

<b>Parameter Name Example</b>	<b>SYSLOG_RTPSMLY_INTVL_1, SYSLOG_RTPSMLY_INTVL_2, ..., SYSLOG_RTPSMLY_INTVL_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in seconds, to send summarized information of RTP packets to the syslog server.
<b>Value Range</b>	0, 5–65535 (0: No information sent)
<b>Default Value</b>	20

## 5.3.4 Firmware Update Settings

### FIRM\_UPGRADE\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to perform firmware updates when the unit detects a newer version of firmware.  <b>Note</b> <ul style="list-style-type: none"><li>• Changing this setting may require restarting the unit.</li><li>• Local firmware updates from the Web user interface (→ see <b>4.7.2 Local Firmware Update</b>) can be performed regardless of this setting.</li><li>• Firmware updates using TR-069 can be performed regardless of this setting.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Enable firmware updates)</li><li>• <b>N</b> (Disable firmware updates)</li></ul>
<b>Default Value</b>	<b>Y</b>
<b>Web User Interface Reference</b>	Enable Firmware Update (Page 145)

### 5.3.4 Firmware Update Settings

---

## FIRM\_VERSION

<b>Value Format</b>	String
<b>Description</b>	Specifies the firmware version of the unit.  <b>Note</b> <ul style="list-style-type: none"><li>• Changing this setting may require restarting the unit.</li></ul>
<b>Value Range</b>	00.000–15.999
<b>Default Value</b>	Empty string

## FIRM\_UPGRADE\_AUTO

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to display a confirmation message asking the user to perform a firmware update (manual) or perform the firmware update without asking the user (automatic) when the unit detects a newer version of firmware.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when "FIRM_UPGRADE_ENABLE" is set to "Y".</li><li>• Changing this setting may require restarting the unit.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>• Y (Enable automatic firmware update)</li><li>• N (Disable automatic firmware update)</li></ul>
<b>Default Value</b>	Y
<b>Web User Interface Reference</b>	Update Type (Page 146)

## FIRM\_FILE\_PATH

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL where the firmware file is stored.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when "FIRM_UPGRADE_ENABLE" is set to "Y".</li><li>• Changing this setting may require restarting the unit.</li></ul>

<b>Value Range</b>	Max. 500 characters
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩".<ul style="list-style-type: none"> <li>"⟨user⟩" must be less than 128 characters.</li> <li>"⟨password⟩" must be less than 128 characters.</li> <li>"⟨user⟩:⟨password⟩@" may be empty.</li> <li>The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters.</li> <li">":⟨port⟩" can be omitted if you do not need to specify the port number.</li"></ul></li> </ul> <li>If "{mac}" is included in this URL, it will be replaced with the unit's MAC address in lower-case.</li> <li>If "{MAC}" is included in this URL, it will be replaced with the unit's MAC address in upper-case.</li> <li>If "{MODEL}" is included in this URL, it will be replaced with the unit's model name.</li> <li>If "{fwver}" is included in this URL, it will be replaced with "<b>FIRM_VERSION</b>" depending on the system. Note that this rule differs from other parameters such as "<b>SIP_USER_AGENT</b>".</li>
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Firmware File URL (Page 146)

## 5.3.5 Provisioning Settings

### OPTION66\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable the unit to look for option 66 to receive the TFTP server address or FQDN from the DHCP server.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>The unit will try to download configuration files through the TFTP server, the IP address or FQDN of which is specified in the option number 66 field.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>Y</b> (Enable option 66)</li> <li><b>N</b> (Disable option 66)</li> </ul>
<b>Default Value</b>	<b>Y</b>

### OPTION66\_REBOOT

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether the unit restarts automatically after pre-provisioning has completed successfully using DHCP server option 66. For details, see <b>2.1.4 Pre-provisioning Setting Example</b> .

### 5.3.5 Provisioning Settings

---

<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Restart automatically)</li><li>• <b>N</b> (Do not restart automatically)</li></ul>
<b>Default Value</b>	<b>N</b>

## PROVISION\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether the unit is automatically configured by downloading the configuration files from the provisioning server of your phone system.  <b>Note</b> <ul style="list-style-type: none"><li>• Downloading configuration files using TR-069 can be performed regardless of this setting.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Enable configuration file download)</li><li>• <b>N</b> (Disable configuration file download)</li></ul>
<b>Default Value</b>	<b>Y</b>
<b>Web User Interface Reference</b>	Enable Provisioning (Page 148)

## CFG\_STANDARD\_FILE\_PATH

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL of the standard configuration file, which is used when every unit needs different settings.  <b>Note</b> <ul style="list-style-type: none"><li>• When you change this setting, set "PROVISION_ENABLE" to "Y" at the same time.</li></ul>

<b>Value Range</b>	Max. 500 characters
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩" <ul style="list-style-type: none"> <li>"⟨user⟩" must be less than 128 characters.</li> <li>"⟨password⟩" must be less than 128 characters.</li> <li>"⟨user⟩:⟨password⟩@" may be empty.</li> <li>The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters.</li> <li">":⟨port⟩" can be omitted if you do not need to specify the port number.</li"></ul></li> </ul> <li>If "{mac}" is included in this URL, it will be replaced with the unit's MAC address in lower-case.</li> <li>If "{MAC}" is included in this URL, it will be replaced with the unit's MAC address in upper-case.</li> <li>If "{MODEL}" is included in this URL, it will be replaced with the unit's model name.</li> <li>If "{fwver}" is included in this URL, it will be replaced with the unit's firmware version.</li> <li>If this URL ends with "/" (slash), "Config{mac}.cfg" is automatically added at the end of the URL. For example, <code>CFG_STANDARD_FILE_PATH="http://host/dir/"</code> becomes <code>CFG_STANDARD_FILE_PATH="http://host/dir/Config{mac}.cfg"</code>.</li>
<b>Default Value</b>	<a href="http://provisioning.e-connecting.net/redirect/conf/{mac}.cfg">http://provisioning.e-connecting.net/redirect/conf/{mac}.cfg</a>
<b>Web User Interface Reference</b>	Standard File URL (Page 148)

## CFG\_PRODUCT\_FILE\_PATH

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL of the product configuration file, which is used when all units with the same model number need the same settings.

**Note**

- When you change this setting, set "PROVISION\_ENABLE" to "Y" at the same time.

### 5.3.5 Provisioning Settings

<b>Value Range</b>	Max. 500 characters
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>The format must be RFC 1738 compliant, as follows: "&lt;scheme&gt;://&lt;user&gt;:&lt;password&gt;@&lt;host&gt;:&lt;port&gt;/&lt;url-path&gt;" – "&lt;user&gt;" must be less than 128 characters.</li> <li>"&lt;password&gt;" must be less than 128 characters.</li> <li>"&lt;user&gt;:&lt;password&gt;@" may be empty.</li> <li>The total of "&lt;scheme&gt;://" and "&lt;host&gt;:&lt;port&gt;/&lt;url-path&gt;" must be less than 245 characters.</li> <li>"&lt;port&gt;" can be omitted if you do not need to specify the port number.</li> </ul> <ul style="list-style-type: none"> <li>If "{mac}" is included in this URL, it will be replaced with the unit's MAC address in lower-case.</li> <li>If "{MAC}" is included in this URL, it will be replaced with the unit's MAC address in upper-case.</li> <li>If "{MODEL}" is included in this URL, it will be replaced with the unit's model name.</li> <li>If "{fwver}" is included in this URL, it will be replaced with the unit's firmware version.</li> <li>If this URL ends with "/" (slash), "{MODEL}.cfg" is automatically added at the end of the URL. For example, <code>CFG_PRODUCT_FILE_PATH="http://host/dir/"</code> becomes <code>CFG_PRODUCT_FILE_PATH="http://host/dir/{MODEL}.cfg"</code>.</li> </ul>
<b>Default Value</b>	Empty string
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>The URL specified by your phone system dealer may be preset in the unit.</li> </ul>
<b>Web User Interface Reference</b>	Product File URL (Page 149)

## CFG\_MASTER\_FILE\_PATH

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL of the master configuration file, which is used when all units need the same settings.

<b>Value Range</b>	Max. 500 characters  <b>Note</b> <ul style="list-style-type: none"> <li>The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩"           <ul style="list-style-type: none"> <li>"⟨user⟩" must be less than 128 characters.</li> <li>"⟨password⟩" must be less than 128 characters.</li> <li>"⟨user⟩:⟨password⟩@" may be empty.</li> <li>The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters.</li> <li">":⟨port⟩" can be omitted if you do not need to specify the port number.</li"></ul></li> </ul> <li>If "{mac}" is included in this URL, it will be replaced with the unit's MAC address in lower-case.</li> <li>If "{MAC}" is included in this URL, it will be replaced with the unit's MAC address in upper-case.</li> <li>If "{MODEL}" is included in this URL, it will be replaced with the unit's model name.</li> <li>If "{fwver}" is included in this URL, it will be replaced with the unit's firmware version.</li> <li>If this URL ends with "/" (slash), "sip.cfg" is automatically added at the end of the URL. For example, CFG_MASTER_FILE_PATH="http://host/dir/" becomes CFG_MASTER_FILE_PATH="http://host/dir/sip.cfg".</li>
<b>Default Value</b>	Empty string  <b>Note</b> <ul style="list-style-type: none"> <li>The URL specified by your phone system dealer may be preset in the unit.</li> </ul>
<b>Web User Interface Reference</b>	Master File URL (Page 149)

## CFG\_FILE\_KEY1

<b>Value Format</b>	String
<b>Description</b>	Specifies the encryption key (password) used to decrypt configuration files.  <b>Note</b> <ul style="list-style-type: none"> <li>If the extension of the configuration file is ".e1c", the configuration file will be decrypted using this key.</li> </ul>
<b>Value Range</b>	32-byte characters  <b>Note</b> <ul style="list-style-type: none"> <li>If an empty string is set for this parameter, decryption with this value is disabled.</li> </ul>
<b>Default Value</b>	A unique value is preset to each unit.

### 5.3.5 Provisioning Settings

---

## CFG\_FILE\_KEY2

<b>Value Format</b>	String
<b>Description</b>	Specifies the encryption key (password) used to decrypt configuration files.  <b>Note</b> <ul style="list-style-type: none"><li>If the extension of the configuration file is ".e2c", the configuration file will be decrypted using this key.</li></ul>
<b>Value Range</b>	32-byte characters  <b>Note</b> <ul style="list-style-type: none"><li>If an empty string is set for this parameter, decryption with this value is disabled.</li></ul>
<b>Default Value</b>	Empty string

## CFG\_FILE\_KEY3

<b>Value Format</b>	String
<b>Description</b>	Specifies the encryption key (password) used to decrypt configuration files.  <b>Note</b> <ul style="list-style-type: none"><li>If the extension of the configuration file is ".e3c", the configuration file will be decrypted using this key.</li></ul>
<b>Value Range</b>	32-byte characters  <b>Note</b> <ul style="list-style-type: none"><li>If an empty string is set for this parameter, decryption with this value is disabled.</li></ul>
<b>Default Value</b>	Empty string

## CFG\_FILE\_KEY\_LENGTH

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the key lengths in bits used to decrypt configuration files.
<b>Value Range</b>	128
<b>Default Value</b>	128

## CFG\_CYCLIC

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether the unit periodically checks for updates of configuration files.

<b>Value Range</b>	<ul style="list-style-type: none"> <li>Y (Enable periodic synchronization of configuration files)</li> <li>N (Disable periodic synchronization of configuration files)</li> </ul>
<b>Default Value</b>	N
<b>Web User Interface Reference</b>	Cyclic Auto Resync (Page 149)

## CFG\_CYCLIC\_INTVL

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in minutes, between periodic checks for updates of the configuration files.
<b>Value Range</b>	1–40320
<b>Default Value</b>	10080
<b>Web User Interface Reference</b>	Resync Interval (Page 150)

## CFG\_RTRY\_INTVL

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the period of time, in minutes, that the unit will retry checking for an update of the configuration files after a configuration file access error has occurred.
<b>Note</b>	<ul style="list-style-type: none"> <li>This setting is available only when "CFG_CYCLIC" is set to "Y".</li> </ul>
<b>Value Range</b>	1–1440
<b>Default Value</b>	30

## CFG\_RESYNC\_TIME

<b>Value Format</b>	String
<b>Description</b>	Specifies the time (hour:minute) that the unit checks for updates of configuration files.
<b>Value Range</b>	00:00–23:59
<b>Note</b>	<ul style="list-style-type: none"> <li>If the value for this setting is any valid value other than an empty string, the unit downloads the configuration files at the fixed time, and the settings specified in "CFG_CYCLIC", "CFG_CYCLIC_INTVL", and "CFG_RTRY_INTVL" are disabled.</li> <li>If the value for this setting is an empty string, downloading the configuration files at the fixed time are disabled.</li> </ul>
<b>Default Value</b>	Empty string

### 5.3.6 Management Server Settings

---

#### CFG\_RESYNC\_DURATION

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the time period, in minutes, added to "CFG_RESYNC_TIME" to create a range within which the unit checks for updates of configuration files. The check will be performed at a random time within this range.
<b>Value Range</b>	0–1439
<b>Default Value</b>	0

#### CFG\_RESYNC\_FROM\_SIP

<b>Value Format</b>	String
<b>Description</b>	Specifies the value of the "Event" header sent from the SIP server to the unit so that the unit can access the configuration files on the provisioning server.
<b>Value Range</b>	Max. 15 characters
	<b>Note</b> <ul style="list-style-type: none"><li>An empty string is not allowed.</li></ul>
<b>Default Value</b>	check-sync
<b>Web User Interface Reference</b>	Header Value for Resync Event (Page 150)

### 5.3.6 Management Server Settings

#### ACS\_URL

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL of the Auto-Configuration Server for using TR-069.
	<b>Note</b> <ul style="list-style-type: none"><li>This parameter must be in the form of a valid HTTP or HTTPS URL, as defined in RFC 3986.</li></ul>
<b>Value Range</b>	Max. 256 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Management Server URL (Page 151)

#### ACS\_USER\_ID

<b>Value Format</b>	String
<b>Description</b>	Specifies the user ID for the Auto-Configuration Server for using TR-069.

<b>Value Range</b>	Max. 255 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication ID (Page 151)

## ACS\_PASS

<b>Value Format</b>	String
<b>Description</b>	Specifies the user password for the Auto-Configuration Server for using TR-069.
<b>Value Range</b>	Max. 255 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication Password (Page 151)

## PERIODIC\_INFORM\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether or not the CPE (Customer Premises Equipment) must periodically send CPE information to the ACS (Auto-Configuration Server) using the Inform method call.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable)</li> <li>• <b>N</b> (Disable)</li> </ul>
<b>Default Value</b>	<b>N</b>

## PERIODIC\_INFORM\_INTERVAL

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval length, in seconds, when the CPE must attempt to connect with the ACS and call the Inform method.
<b>Note</b>	<ul style="list-style-type: none"> <li>• This setting is available only when "PERIODIC_INFORM_ENABLE" is set to "Y".</li> </ul>
<b>Value Range</b>	30–2419200
<b>Default Value</b>	86400

## PERIODIC\_INFORM\_TIME

<b>Value Format</b>	String
---------------------	--------

### 5.3.6 Management Server Settings

---

<b>Description</b>	Specifies the time (UTC) to determine when the CPE will initiate the periodic Inform method calls.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>Each Inform call must occur at this reference time plus or minus an integer multiple of the "PERIODIC_INFORM_INTERVAL". This "PERIODIC_INFORM_TIME" parameter is used only to set the "phase" of the periodic Informs. The actual value can be arbitrarily set far into the past or future. For example, if "PERIODIC_INFORM_INTERVAL" is set to 86400 (one day) and if "PERIODIC_INFORM_TIME" is set to midnight on a certain day, then periodic Informs will occur every day at midnight, starting from the set date.</li> <li>If the time is set to "unknown time", the start time depends on the CPE's settings. However, the "PERIODIC_INFORM_INTERVAL" must still be adhered to. If absolute time is not available to the CPE, its periodic Inform behavior must be the same as if the "PERIODIC_INFORM_TIME" parameter was set to the "unknown time".</li> <li>Time zones other than UTC are not supported.</li> </ul>
<b>Value Range</b>	4–32 characters
<b>Default Value</b>	0001-01-01T00:00:00Z (unknown time)

## CON\_REQ\_USER\_ID

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the username used to authenticate an ACS making a Connection Request to the CPE.
<b>Value Range</b>	Max. 63 characters (except ", &, ', :, <, >, and space)
<b>Default Value</b>	Empty string

## CON\_REQ\_PASS

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the password used to authenticate an ACS making a Connection Request to the CPE.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>When the "CON_REQ_USER_ID" parameter is specified, an empty string for this parameter is not allowed.</li> </ul>
<b>Value Range</b>	Max. 63 characters (except ", &, ', :, <, >, and space)
<b>Default Value</b>	Empty string

## ANNEX\_G\_STUN\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether or not the CPE can use STUN. This applies only to the use of STUN in association with the ACS to allow UDP Connection Requests.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable)</li> <li>• <b>N</b> (Disable)</li> </ul>
<b>Default Value</b>	<b>N</b>

## ANNEX\_G\_STUN\_SERV\_ADDR

<b>Value Format</b>	String
<b>Description</b>	Specifies the host name or IP address of the STUN server for the CPE to send Binding Requests.
<b>Note</b>	<ul style="list-style-type: none"> <li>• This setting is available only when "ANNEX_G_STUN_ENABLE" is set to "Y".</li> <li>• If the value for this setting is an empty string and "ANNEX_G_STUN_ENABLE" is set to "Y", the CPE must use the address of the ACS extracted from the host portion of the ACS URL.</li> </ul>
<b>Value Range</b>	Max. 256 characters
<b>Default Value</b>	Empty string

## ANNEX\_G\_STUN\_SERV\_PORT

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number of the STUN server for the CPE to send Binding Requests.
<b>Note</b>	<ul style="list-style-type: none"> <li>• This setting is available only when "ANNEX_G_STUN_ENABLE" is set to "Y".</li> </ul>
<b>Value Range</b>	1-65535
<b>Default Value</b>	3478

## ANNEX\_G\_STUN\_USER\_ID

<b>Value Format</b>	String
---------------------	--------

### 5.3.6 Management Server Settings

---

<b>Description</b>	Specifies the STUN username to be used in Binding Requests (only if message integrity has been requested by the STUN server).
<b>Note</b>	<ul style="list-style-type: none"><li>If the value for this setting is an empty string, the CPE must not send STUN Binding Requests with message integrity.</li></ul>
<b>Value Range</b>	Max. 256 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string

## ANNEX\_G\_STUN\_PASS

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the STUN password to be used in computing the MESSAGE-INTEGRITY attribute used in Binding Requests (only if message integrity has been requested by the STUN server). When read, this parameter returns an empty string, regardless of the actual value.
<b>Value Range</b>	Max. 256 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string

## ANNEX\_G\_STUN\_MAX\_KEEP\_ALIVE

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the maximum period, in seconds, that STUN Binding Requests must be sent by the CPE for the purpose of maintaining the binding in the Gateway. This applies specifically to Binding Requests sent from the UDP Connection Request address and port.  <b>Note</b> <ul style="list-style-type: none"><li>This setting is available only when "ANNEX_G_STUN_ENABLE" is set to "Y".</li></ul>
<b>Value Range</b>	1–3600
<b>Default Value</b>	300

## ANNEX\_G\_STUN\_MIN\_KEEP\_ALIVE

---

<b>Value Format</b>	Integer
---------------------	---------

<b>Description</b>	Specifies the minimum period, in seconds, that STUN Binding Requests can be sent by the CPE for the purpose of maintaining the binding in the Gateway. This limit applies only to Binding Requests sent from the UDP Connection Request address and port, and only those that do not contain the BINDING-CHANGE attribute.
<b>Note</b>	<ul style="list-style-type: none"> <li>This setting is available only when "ANNEGX_G_STUN_ENABLE" is set to "Y".</li> </ul>
<b>Value Range</b>	1–3600
<b>Default Value</b>	30

## UDP\_CON\_REQ\_ADDR\_NOTIFY\_LIMIT

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the minimum time, in seconds, between Active Notifications resulting from changes to the "UDPConnectionRequestAddress" (if Active Notification is enabled).
<b>Value Range</b>	0–65535
<b>Default Value</b>	0

# 5.4 Network Settings

## 5.4.1 IP Settings

### CONNECTION\_TYPE

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether to assign the IP address automatically (DHCP) or manually (static).
<b>Note</b>	<ul style="list-style-type: none"> <li>This setting is available only when "NW_SETTING_ENABLE" is set to "N".</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>1 (DHCP)</li> <li>0 (Static)</li> </ul>
<b>Default Value</b>	1
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Web User Interface Reference</b>	Connection Mode (Page 78)

#### 5.4.1 IP Settings

---

## HOST\_NAME

<b>Value Format</b>	String
<b>Description</b>	Specifies the host name for the unit to send to the DHCP server.  <b>Note</b> <ul style="list-style-type: none"><li>This setting is available only when "CONNECTION_TYPE" is set to "1".</li></ul>
<b>Value Range</b>	Max. 63 characters  <b>Note</b> <ul style="list-style-type: none"><li>An empty string is not allowed.</li><li>If "{MODEL}" is included in this parameter, it will be replaced with the unit's model name.</li></ul>
<b>Default Value</b>	{MODEL}
<b>Web User Interface Reference</b>	Host Name (Page 78)

## DHCP\_DNS\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to receive DNS server addresses automatically or to assign a DNS server addresses (up to 2) manually.  <b>Note</b> <ul style="list-style-type: none"><li>This setting is available only when "CONNECTION_TYPE" is set to "1" and when "NW_SETTING_ENABLE" is set to "N".</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>Y (Use "USER_DNS1_ADDR" or, "USER_DNS1_ADDR" and "USER_DNS2_ADDR")</li><li>N (Receive DNS server address automatically)</li></ul>
<b>Default Value</b>	N
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Web User Interface Reference</b>	Domain Name Server (Page 79)

## STATIC\_IP\_ADDRESS

<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address for the unit.  <b>Note</b> <ul style="list-style-type: none"><li>This setting is available only when "CONNECTION_TYPE" is set to "0" and when "NW_SETTING_ENABLE" is set to "N".</li><li>When you specify this parameter, you must specify "STATIC_SUBNET" together in a configuration file.</li></ul>

<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Web User Interface Reference</b>	Static IP Address (Page 79)

## STATIC\_SUBNET

<b>Value Format</b>	String
<b>Description</b>	<p>Specifies the subnet mask for the unit.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>This setting is available only when "CONNECTION_TYPE" is set to "0" and when "NW_SETTING_ENABLE" is set to "N".</li> <li>When you specify this parameter, you must specify "STATIC_IP_ADDRESS" together in a configuration file.</li> </ul>
<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Web User Interface Reference</b>	Subnet Mask (Page 80)

## STATIC\_GATEWAY

<b>Value Format</b>	String
<b>Description</b>	<p>Specifies the IP address of the default gateway for the network where the unit is connected.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>This setting is available only when "CONNECTION_TYPE" is set to "0" and when "NW_SETTING_ENABLE" is set to "N".</li> <li>When you specify this parameter, you must specify "STATIC_IP_ADDRESS" and "STATIC_SUBNET" together in a configuration file.</li> </ul>
<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Web User Interface Reference</b>	Default Gateway (Page 80)

#### 5.4.2 DNS Settings

---

### USER\_DNS1\_ADDR

<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address of the primary DNS server.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when "CONNECTION_TYPE" is set to "0" and when "NW_SETTING_ENABLE" is set to "N".</li></ul>
<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Web User Interface Reference</b>	DNS1 (Page 80)

### USER\_DNS2\_ADDR

<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address of the secondary DNS server.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when "CONNECTION_TYPE" is set to "0" and when "NW_SETTING_ENABLE" is set to "N".</li></ul>
<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string
<b>Phone User Interface Reference</b>	Configuring the Network Settings of the Unit (Page 19)
<b>Web User Interface Reference</b>	DNS2 (Page 81)

## 5.4.2 DNS Settings

### DNS\_QRY\_PRL

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies the DNS query method as parallel or sequential.

<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Parallel)</li> <li>• <b>N</b> (Sequential)</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If set to "Y", the unit sends out all DNS queries at the same time. The first DNS reply will be accepted and used by the unit.</li> <li>• If set to "N", the unit sends DNS queries sequentially. The unit sends a request to the DNS server with the highest priority for a preprogrammed time period (5 seconds). When the timer expires, the unit sends a request to the DNS server with the second priority.</li> </ul>
<b>Default Value</b>	<b>Y</b>

## DNS\_PRIORITY

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies the priority of the DNS server.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> ("DNS1_ADDR" and "DNS2_ADDR" have first priority.)</li> <li>• <b>N</b> ("DNS1_ADDR" and "DNS2_ADDR" have no priority.)</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If set to "Y", the DNS servers specified in "DNS1_ADDR" and "DNS2_ADDR" will be queried first. If the queries fail, the DNS server specified by the user (DHCP or static) will be queried.</li> <li>• If set to "N", the DNS server specified by the user (DHCP or static) will be queried first. If the query fails, the DNS servers specified in "DNS1_ADDR" and "DNS2_ADDR" will be queried.</li> </ul>
<b>Default Value</b>	<b>N</b>

## DNS1\_ADDR

<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address of the primary DNS server for your phone system dealer.
<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string

## DNS2\_ADDR

<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address of the secondary DNS server for your phone system dealer.
<b>Value Range</b>	IP address in dotted-decimal notation

#### 5.4.3 Ethernet Port Settings

---

<b>Default Value</b>	Empty string
----------------------	--------------

### 5.4.3 Ethernet Port Settings

#### VLAN\_ENABLE

---

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to use the VLAN feature to perform VoIP communication securely.
<b>Note</b>	<ul style="list-style-type: none"><li>This setting is available only when both "NW_SETTING_ENABLE" and "IEEE8021X_ENABLE" (KX-UT248 only) are set to "N".</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li><b>Y</b> (Enable)</li><li><b>N</b> (Disable)</li></ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	Enable VLAN (Page 84)

#### VLAN\_ID\_IP\_PHONE

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the VLAN ID for this unit.
<b>Note</b>	<ul style="list-style-type: none"><li>This setting is available only when both "NW_SETTING_ENABLE" and "IEEE8021X_ENABLE" (KX-UT248 only) are set to "N".</li></ul>
<b>Value Range</b>	1–4094
<b>Default Value</b>	2
<b>Web User Interface Reference</b>	IP Phone (VLAN ID) (Page 84)

#### VLAN\_PRI\_IP\_PHONE

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the priority number for the unit.
<b>Note</b>	<ul style="list-style-type: none"><li>This setting is available only when both "NW_SETTING_ENABLE" and "IEEE8021X_ENABLE" (KX-UT248 only) are set to "N".</li></ul>
<b>Value Range</b>	0–7

<b>Default Value</b>	7
<b>Web User Interface Reference</b>	IP Phone (Priority) (Page 85)

## VLAN\_ID\_PC

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the VLAN ID for the PC.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>This setting is available only when both "NW_SETTING_ENABLE" and "IEEE8021X_ENABLE" (KX-UT248 only) are set to "N".</li> </ul>
<b>Value Range</b>	1–4094
<b>Default Value</b>	1
<b>Web User Interface Reference</b>	PC (VLAN ID) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only) (Page 85)

## VLAN\_PRI\_PC

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the priority number for the PC.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>This setting is available only when both "NW_SETTING_ENABLE" and "IEEE8021X_ENABLE" (KX-UT248 only) are set to "N".</li> </ul>
<b>Value Range</b>	0–7
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	PC (Priority) (KX-UT123/KX-UT133/KX-UT136/KX-UT248 only) (Page 85)

## 5.4.4 IEEE 802.1X Settings (KX-UT248 only)

### IEEE8021X\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Selects whether to use the IEEE 802.1X protocol.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>This setting is available only when "VLAN_ENABLE" is set to "N".</li> </ul>

#### 5.4.4 IEEE 802.1X Settings (KX-UT248 only)

---

<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Enable)</li><li>• <b>N</b> (Disable)</li></ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	Enable IEEE802.1X (Page 86)

### IEEE8021X\_AUTH\_PRTCL

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the authentication method used with the IEEE 802.1X protocol.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when "<b>VLAN_ENABLE</b>" is set to "<b>N</b>".</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>• 1 (PEAP)</li><li>• 0 (EAP-MD5)</li></ul>
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	Authentication Protocol (Page 86)

### IEEE8021X\_USER\_ID

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the authentication ID required for IEEE 802.1X authentication.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when "<b>VLAN_ENABLE</b>" is set to "<b>N</b>".</li></ul>
<b>Value Range</b>	Max. 127 characters (except ", & ', :, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication ID (Page 87)

### IEEE8021X\_USER\_PASS

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the authentication password used for IEEE 802.1X authentication.  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when "<b>VLAN_ENABLE</b>" is set to "<b>N</b>".</li></ul>
<b>Value Range</b>	Max. 127 characters (except ", & ', :, <, >, and space)

<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication Password (Page 87)

## 5.4.5 HTTP Settings

### HTTPD\_PORTOPEN\_AUTO

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether the unit's Web port is always open.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Web port is always open)</li> <li>• <b>N</b> (Web port is closed [can be opened temporarily through phone user interface programming])</li> </ul> <p><b>Notice</b></p> <ul style="list-style-type: none"> <li>• If you want to set to "Y", please fully recognize the possibility of unauthorized access to the unit through the Web user interface and change this setting at your own risk. In addition, please take full security measures for connecting to an external network and control all passwords for logging in to the Web user interface.</li> </ul>
<b>Default Value</b>	<b>N</b>

### HTTP\_VER

<b>Value Format</b>	Integer
<b>Description</b>	Specifies which version of the HTTP protocol to use for HTTP communication.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• 1 (Use HTTP 1.0)</li> <li>• 0 (Use HTTP 1.1)</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• For this unit, it is strongly recommended that you specify "1" for this setting. However, if the HTTP server does not function well with HTTP 1.0, try changing the setting "0".</li> </ul>
<b>Default Value</b>	1
<b>Web User Interface Reference</b>	HTTP Version (Page 88)

### HTTP\_USER\_AGENT

<b>Value Format</b>	String
<b>Description</b>	Specifies the text string to send as the user agent in the header of HTTP requests.

#### 5.4.5 HTTP Settings

---

<b>Value Range</b>	Max. 40 characters
	<b>Note</b> <ul style="list-style-type: none"><li>• An empty string is not allowed.</li><li>• If "{mac}" is included in this parameter, it will be replaced with the unit's MAC address in lower-case.</li><li>• If "{MAC}" is included in this parameter, it will be replaced with the unit's MAC address in upper-case.</li><li>• If "{MODEL}" is included in this parameter, it will be replaced with the unit's model name.</li><li>• If "{fwver}" is included in this parameter, it will be replaced with the firmware version of the unit.</li></ul>
<b>Default Value</b>	Panasonic_{MODEL}/{fwver} ({mac})
<b>Web User Interface Reference</b>	HTTP User Agent (Page 88)

### HTTP\_SSL\_VERIFY

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether to enable the verification of the root certificate.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• 0 (No verification of root certificate)</li><li>• 1 (Simple verification of root certificate)</li><li>• 2 (Precise verification of root certificate)</li></ul>
	<b>Note</b> <ul style="list-style-type: none"><li>• If set to "0", the verification of the root certificate is disabled.</li><li>• If set to "1", the verification of the root certificate is enabled. In this case, the validity of the certificate's date, certificate's chain, and the confirmation of the root certificate will be verified.</li><li>• If set to "2", precise certificate verification is enabled. In this case, the validity of the server name will be verified in addition to the items verified when "1" is set.</li><li>• If the unit has not obtained the current time, verification will not be performed irrelevant of this setting. In order to perform verification it is necessary to first set up the NTP server.</li></ul>
<b>Default Value</b>	0

### CFG\_ROOT\_CERTIFICATE\_PATH

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the URI of the root certificate.
	<b>Note</b> <ul style="list-style-type: none"><li>• Changing this setting may require restarting the unit.</li></ul>

<b>Value Range</b>	Max. 500 characters  <b>Note</b> <ul style="list-style-type: none"><li>• The format must be RFC 1738 compliant, as follows: "⟨scheme⟩://⟨user⟩:⟨password⟩@⟨host⟩:⟨port⟩/⟨url-path⟩"<ul style="list-style-type: none"><li>– "⟨user⟩" must be less than 128 characters.</li><li>– "⟨password⟩" must be less than 128 characters.</li><li>– "⟨user⟩:⟨password⟩@" may be empty.</li><li>– The total of "⟨scheme⟩://" and "⟨host⟩:⟨port⟩/⟨url-path⟩" must be less than 245 characters.</li><li>– ":⟨port⟩" can be omitted if you do not need to specify the port number.</li></ul></li></ul>
<b>Default Value</b>	Empty string

## 5.4.6 Time Adjust Settings

### NTP\_ADDR

<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address or FQDN of the NTP server.
<b>Value Range</b>	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	NTP Server Address (Page 100)

### TIME\_SYNC\_INTVL

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in seconds, to resynchronize after having detected no reply from the NTP server.
<b>Value Range</b>	10–86400
<b>Default Value</b>	60

### TIME\_QUERY\_INTVL

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in seconds, between synchronizations with the NTP server.
<b>Value Range</b>	10–86400
<b>Default Value</b>	43200
<b>Web User Interface Reference</b>	Synchronization Interval (Page 99)

## 5.4.7 STUN Settings

### [STUN\\_SERV\\_ADDR](#)

<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address or FQDN of the STUN server.
<b>Value Range</b>	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	STUN Server Address (Page 90)

### [STUN\\_SERV\\_PORT](#)

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number of the STUN server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	3478
<b>Web User Interface Reference</b>	STUN Server Port (Page 91)

### [STUN\\_2NDSERV\\_ADDR](#)

<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address of the secondary STUN server.
<b>Note</b>	<ul style="list-style-type: none"> <li>This setting is available only when "STUN_SERV_ADDR" is specified in IP address notation.</li> </ul>
<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string

### [STUN\\_2NDSERV\\_PORT](#)

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number of the secondary STUN server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	3478

## 5.4.8 Miscellaneous Network Settings

### NW\_SETTING\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	<p>Specifies whether to enable the network settings from the unit.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>If you change this setting to "N" when the network settings (with the exception of "<b>HOST_NAME</b>") in <b>5.4.1 IP Settings</b> have been made through Web user interface programming, clear these settings once by performing Reset Web Settings from the Web user interface, and then change this setting to "N".</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Y (Enable network settings)</li> <li>N (Disable network settings)</li> </ul>
<b>Default Value</b>	Y

### CUSTOM\_WEB\_PAGE

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether to enable the settings in <b>4.3.1 Basic Network Settings</b> and <b>4.4.5 Time Adjust Settings</b> from the Web user interface when logged in with the User account.
<b>Value Range</b>	<p>0–3</p> <ul style="list-style-type: none"> <li>0: Enable "Basic Network Settings" and "Time Adjust Settings"</li> <li>1: Disable "Basic Network Settings"</li> <li>2: Disable "Time Adjust Settings"</li> <li>3: Disable "Basic Network Settings" and "Time Adjust Settings"</li> </ul>
<b>Default Value</b>	0

## 5.4.9 LLDP-MED Settings

### LLDP\_ENABLE

<b>Value Format</b>	Integer
<b>Description</b>	Selects whether to enable or disable sending and receiving LLDP frames.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Y: Enable</li> <li>N: Disable</li> </ul>
<b>Default Value</b>	Y

## 5.5.1 Call Control Settings

---

### LLDP\_INTERVAL

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in seconds, between sending each LLDP frame.
<b>Value Range</b>	1–3600
<b>Default Value</b>	30

### LLDP\_VLAN\_ID\_PC

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the VLAN ID for the PC port when LLDP is on.
<b>Value Range</b>	0–4094
<b>Default Value</b>	0

### LLDP\_VLAN\_PRI\_PC

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the VLAN Priority for the PC port when LLDP is on.
<b>Value Range</b>	0–7
<b>Default Value</b>	0

## 5.5 Telephone Settings

---

### 5.5.1 Call Control Settings

#### VM\_SUBSCRIBE\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to send the SUBSCRIBE request to a voice mail server.
<b>Note</b>	<ul style="list-style-type: none"><li>Your phone system must support voice mail.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li><b>Y</b> (Send the SUBSCRIBE request)</li><li><b>N</b> (Do not send the SUBSCRIBE request)</li></ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	Send SUBSCRIBE to Voice Mail Server (Page 122)

## CONFERENCE\_SERVER\_URI

<b>Value Format</b>	String
<b>Description</b>	<p>Specifies the URI for a conference server, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:conference@example.com".</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>In a SIP URI, the user part ("conference" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters.</li> <li>Availability depends on your phone system.</li> </ul>
<b>Value Range</b>	Max. 195 characters (except ", &, :, ;, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Conference Server URI (Page 123)

## FIRSTDIGIT\_TIM

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the length of time, in seconds, within which the first digits of a dial number must be dialed. When this timer expires, the unit will play a busy tone.
<b>Value Range</b>	1–600
<b>Default Value</b>	30

## INTDIGIT\_TIM

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the length of time, in seconds, within which subsequent digits of a dial number must be dialed. When this timer expires after the last key was pressed, dialing will start.
<b>Value Range</b>	1–15
<b>Default Value</b>	5
<b>Web User Interface Reference</b>	Inter-digit Timeout (Page 123)

## MACRODIGIT\_TIM

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the length of time, in seconds, that the unit waits when a "T" or "t" has been entered in the dial plan.
<b>Value Range</b>	1–15

### 5.5.1 Call Control Settings

---

<b>Default Value</b>	5
<b>Web User Interface Reference</b>	Timer for Dial Plan (Page 123)

## INTERNATIONAL\_ACCESS\_CODE

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the number to be shown in the place of the first "+" symbol when the phone number for incoming international calls contains "+".
<b>Value Range</b>	Max. 8 characters (consisting of 0–9, *, and #) <b>Note</b> <ul style="list-style-type: none"><li>No other characters are allowed.</li></ul>
<b>Default Value</b>	Empty string ("+" is deleted)
<b>Web User Interface Reference</b>	International Call Prefix (Page 123)

## COUNTRY\_CALLING\_CODE

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the country/area calling code to be used for comparative purposes when dialing a number from the incoming call log that contains a "+" symbol.
<b>Value Range</b>	Max. 8 characters (consisting of 0–9)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Country Calling Code (Page 124)

## NATIONAL\_ACCESS\_CODE

---

<b>Value Format</b>	String
<b>Description</b>	When dialing a number from the incoming call log that contains a "+" symbol and the country calling code matches, the country calling code is removed and the national access code is added.
<b>Value Range</b>	Max. 8 characters (consisting of 0–9, *, and #)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	National Access Code (Page 124)

## DEFAULT\_LINE\_SELECT

---

<b>Value Format</b>	Integer
---------------------	---------

<b>Description</b>	Specifies the line used to make an outgoing call when no line is specified in the dialing operation.
<b>Note</b>	<ul style="list-style-type: none"> <li>The available line number varies depending on the type of the unit being used.</li> </ul>
<b>Value Range</b>	1–2 (for KX-UT113/KX-UT123) 1–4 (for KX-UT133/KX-UT136) 1–6 (for KX-UT248)
<b>Default Value</b>	1
<b>Web User Interface Reference</b>	Default Line for Outgoing (Page 124)

## DATA\_LINE\_MODE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable sending and receiving using data line mode.
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>Y</b> (Enable Data Line Mode)</li> <li><b>N</b> (Disable Data Line Mode)</li> </ul>
<b>Default Value</b>	<b>N</b>

## NUM\_PLAN\_PICKUP\_DIRECT

<b>Value Format</b>	String
<b>Description</b>	Specifies the feature number assigned to a BLF for performing call pickup.
<b>Value Range</b>	Max. 4 characters (consisting of 0–9, *, and #)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Direct Call Pickup (Page 125)

## TALK\_PACKAGE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable the Click to Answer/Retrieve functions.
<b>Note</b>	<ul style="list-style-type: none"> <li>When this parameter is set to "Y", "talk" is added to the Allow-Events header.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>Y</b> (Enable Talk Package)</li> <li><b>N</b> (Disable Talk Package)</li> </ul>
<b>Default Value</b>	<b>N</b>

## 5.5.1 Call Control Settings

---

### HOLD\_PACKAGE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable the Click to Hold function.  <b>Note</b> <ul style="list-style-type: none"><li>• When this parameter is set to "Y", "hold" is added to the Allow-Events header.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>• Y (Enable Hold Package)</li><li>• N (Disable Hold Package)</li></ul>
<b>Default Value</b>	N

### HOLD\_RECALL\_TIM

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the duration of the hold recall timer. If set to "0", the function is disabled.
<b>Value Range</b>	0–240 (0: Disable)
<b>Default Value</b>	60

### AUTO\_ANS\_RING\_TIM

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the number of seconds a phone in Auto Answer mode will ring before a conversation is established automatically when it receives a call.
<b>Value Range</b>	0–15
<b>Default Value</b>	5

### RINGING\_OFF\_SETTING\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether incoming call ringing can be turned off for the phone. If disabled, users cannot prevent incoming calls from ringing.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• Y (Enable Ringing Off setting)</li><li>• N (Disable Ringing Off setting)</li></ul>
<b>Default Value</b>	Y

## AUTO\_CALL\_HOLD

<b>Value Format</b>	Boolean
<b>Description</b>	Selects whether calls are disconnected or held when a DN button is pressed while having a conversation.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable Auto Call Hold)</li> <li>• <b>N</b> (Disable Auto Call Hold)</li> </ul>
<b>Default Value</b>	<b>N</b>

## REDIALKEY\_CALLOG\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether the call log is displayed when the Redial button is pressed while on-hook.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Displays outgoing call log by pressing the Redial button.)</li> <li>• <b>N</b> (Not display call log by pressing the Redial button.)</li> </ul>
<b>Default Value</b>	<b>N</b>

## ONHOOK\_TRANSFER\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether transfer operations are permitted while on-hook.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable On-hook Transfer)</li> <li>• <b>N</b> (Disable On-hook Transfer)</li> </ul>
<b>Default Value</b>	<b>Y</b>

## DISCONNECTION\_MODE

<b>Value Format</b>	Integer
<b>Description</b>	Selects the tone heard (reorder tone or busy tone) when a dial operation fails.
<b>Value Range</b>	1–2 – 1: Mode1 (ROT) – 2: Mode2 (BT)
<b>Default Value</b>	1

## TONE\_LEN\_DISCONNECT\_HANDSET

<b>Value Format</b>	Integer
---------------------	---------

### 5.5.1 Call Control Settings

---

<b>Description</b>	Specifies the duration, in seconds, that a disconnect tone will be heard when the other party ends a call and the handset is being used.
<b>Value Range</b>	1–15
<b>Default Value</b>	10

## TONE\_LEN\_DISCONNECT\_HANDSFREE

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the duration, in seconds, that a disconnect tone will be heard while in hands-free mode when the other party ends a call.
<b>Value Range</b>	1–15
<b>Default Value</b>	3

## KEY\_PAD\_TONE

<b>Value Format</b>	Boolean
<b>Description</b>	Selects whether a tone is heard in response to key presses.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Enable Key Pad Tone)</li><li>• <b>N</b> (Disable Key Pad Tone)</li></ul>
<b>Default Value</b>	<b>Y</b>
<b>Web User Interface Reference</b>	Key Click Tone (Page 139)

## HOLD\_AND\_CALL\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether or not to enable making a call while having a call on hold.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b>: Hold and Call</li><li>• <b>N</b>: Hold and Idle</li></ul>
<b>Default Value</b>	<b>Y</b>

## HOLD\_TRANSFER\_OPERATION

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies the method of transferring calls.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b>: Enable (Press the Hold button to transfer a call.)</li><li>• <b>N</b>: Disable (Press the Transfer button to transfer a call.)</li></ul>
<b>Default Value</b>	<b>N</b>

## 5.5.2 Tone Settings

### DIAL\_TONE1\_FRQ

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of Dial Tone 1 using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	350,440
<b>Web User Interface Reference</b>	Tone Frequencies (Page 135)

### DIAL\_TONE1\_GAIN

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the gain, in decibels, of Dial Tone 1.
<b>Value Range</b>	-24–6
<b>Default Value</b>	0

### DIAL\_TONE1\_RPT

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether Dial Tone 1 is repeated.
<b>Value Range</b>	0–1 – 0: No Repeat – 1: Repeat
<b>Default Value</b>	0

### DIAL\_TONE1\_TIMING

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the pattern, in milliseconds, of Dial Tone 1 using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.  <b>Note</b> <ul style="list-style-type: none"><li>It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).</li></ul>
<b>Value Range</b>	0–16000 (0: Infinite time)  <b>Note</b> <ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	60,0

## 5.5.2 Tone Settings

---

Web User Interface Reference	Tone Timings (Page 136)
------------------------------	-------------------------

### DIAL\_TONE2\_FRQ

---

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of Dial Tone 2 using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	350,440

### DIAL\_TONE2\_GAIN

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the gain, in decibels, of Dial Tone 2.
<b>Value Range</b>	-24–6
<b>Default Value</b>	0

### DIAL\_TONE2\_RPT

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether Dial Tone 2 is repeated.
<b>Value Range</b>	0–1 — 0: No Repeat — 1: Repeat
<b>Default Value</b>	0

### DIAL\_TONE2\_TIMING

---

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the pattern, in milliseconds, of Dial Tone 2 using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.  <b>Note</b> <ul style="list-style-type: none"><li>It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).</li></ul>
<b>Value Range</b>	0–16000 (0: Infinite time)  <b>Note</b> <ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	60,0

## DIAL\_TONE4\_FRQ

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of Dial Tone 4 (stutter dial tones) to notify that a voice mail is waiting, using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	350,440
<b>Web User Interface Reference</b>	Tone Frequencies (Page 138)

## DIAL\_TONE4\_GAIN

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the gain, in decibels, of Dial Tone 4 (stutter-type dial tone).
<b>Value Range</b>	-24–6
<b>Default Value</b>	0

## DIAL\_TONE4\_RPT

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether Dial Tone 4 (stutter-type dial tone) is repeated.
<b>Value Range</b>	0–1 – 0: No Repeat – 1: Repeat
<b>Default Value</b>	0

## DIAL\_TONE4\_TIMING

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the pattern, in milliseconds, of Dial Tone 4 (stutter dial tones) to notify that a voice mail is waiting, using up to 22 whole numbers (off 1, on 1, off 2, on 2...) separated by commas. <b>Note</b> <ul style="list-style-type: none"><li>• It is recommended that you set a value of 560 milliseconds or more for the first value (off 1).</li></ul>
<b>Value Range</b>	0–16000 (0: Infinite time) <b>Note</b> <ul style="list-style-type: none"><li>• Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	560,100,100,100,100,100,100,100,100,100,100,100,100,100,100,100,100,0,100,100,100,100,100,0

## 5.5.2 Tone Settings

---

Web User Interface Reference	Tone Timings (Page 138)
------------------------------	-------------------------

### BUSY\_TONE\_FRQ

---

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of busy tones using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	480,620
<b>Web User Interface Reference</b>	Tone Frequencies (Page 136)

### BUSY\_TONE\_GAIN

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the gain, in decibels, of the busy tone.
<b>Value Range</b>	-24–6
<b>Default Value</b>	0

### BUSY\_TONE\_RPT

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether the busy tone is repeated.
<b>Value Range</b>	0–1 – 0: No Repeat – 1: Repeat
<b>Default Value</b>	1

### BUSY\_TONE\_TIMING

---

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the pattern, in milliseconds, of busy tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.  <b>Note</b> <ul style="list-style-type: none"><li>It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).</li></ul>
<b>Value Range</b>	0–16000 (0: Infinite time)  <b>Note</b> <ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>

<b>Default Value</b>	60,500,440
<b>Web User Interface Reference</b>	Tone Timings (Page 137)

## REORDER\_TONE\_FRQ

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of reorder tones using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	480,620
<b>Web User Interface Reference</b>	Tone Frequencies (Page 138)

## REORDER\_TONE\_GAIN

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the gain, in decibels, of the reorder tone.
<b>Value Range</b>	-24–6
<b>Default Value</b>	0

## REORDER\_TONE\_RPT

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether the reorder tone is repeated.
<b>Value Range</b>	0–1 – 0: No Repeat – 1: Repeat
<b>Default Value</b>	1

## REORDER\_TONE\_TIMING

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the pattern, in milliseconds, of reorder tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
<b>Note</b>	<ul style="list-style-type: none"> <li>• It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).</li> </ul>

### 5.5.2 Tone Settings

---

<b>Value Range</b>	0–16000 (0: Infinite time)
<b>Note</b>	<ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	60,250,190
<b>Web User Interface Reference</b>	Tone Timings (Page 139)

## RINGBACK\_TONE\_FRQ

---

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of ringback tones using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	440,480
<b>Web User Interface Reference</b>	Tone Frequencies (Page 137)

## RINGBACK\_TONE\_GAIN

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the gain, in decibels, of the ringback tone.
<b>Value Range</b>	-24–6
<b>Default Value</b>	0

## RINGBACK\_TONE\_RPT

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether the ringback tone is repeated.
<b>Value Range</b>	0–1 <ul style="list-style-type: none"><li>0: No Repeat</li><li>1: Repeat</li></ul>
<b>Default Value</b>	1

## RINGBACK\_TONE\_TIMING

---

<b>Value Format</b>	Comma-separated Integer
---------------------	-------------------------

<b>Description</b>	Specifies the pattern, in milliseconds, of ringback tones using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
<b>Note</b>	<ul style="list-style-type: none"> <li>It is recommended that you set a value of 60 milliseconds or more for the first value (off 1).</li> </ul>
<b>Value Range</b>	0–16000 (0: Infinite time)
<b>Note</b>	<ul style="list-style-type: none"> <li>Avoid setting 1–50 for any of the values.</li> </ul>
<b>Default Value</b>	60,2000,3940
<b>Web User Interface Reference</b>	Tone Timings (Page 137)

## HOLD\_ALARM\_FRQ

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of the hold alarm using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	425

## HOLD\_ALARM\_GAIN

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the gain, in decibels, of the hold alarm.
<b>Value Range</b>	-24–6
<b>Default Value</b>	0

## HOLD\_ALARM\_RPT

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether the hold alarm is repeated.
<b>Value Range</b>	0–1 – 0: No Repeat – 1: Repeat
<b>Default Value</b>	1

## HOLD\_ALARM\_TIMING

<b>Value Format</b>	Comma-separated Integer
---------------------	-------------------------

### 5.5.2 Tone Settings

---

<b>Description</b>	Specifies the pattern, in milliseconds, of the hold alarm using up to 10 whole numbers (on 1, off 1, on 2, off 2...) separated by commas.
<b>Value Range</b>	0–16000 (0: Infinite time)  <b>Note</b> <ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	120,14880

## CW\_TONE1\_FRQ

---

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of call waiting tone 1 using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	425

## CW\_TONE1\_GAIN

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the gain, in decibels, of call waiting tone 1.
<b>Value Range</b>	-24–6
<b>Default Value</b>	0

## CW\_TONE1\_RPT

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether call waiting tone 1 is repeated.
<b>Value Range</b>	0–1 <ul style="list-style-type: none"><li>0: No Repeat</li><li>1: Repeat</li></ul>
<b>Default Value</b>	1

## CW\_TONE1\_TIMING

---

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the pattern, in milliseconds, of call waiting tone 1 using up to 10 whole numbers (on 1, off 1, on 2, off 2...) separated by commas.

<b>Value Range</b>	0–16000 (0: Infinite time)
<b>Note</b>	<ul style="list-style-type: none"> <li>Avoid setting 1–50 for any of the values.</li> </ul>
<b>Default Value</b>	120,120,120,120,120,14400

## HOLD\_TONE\_FRQ

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the dual-tone frequencies, in hertz, of the hold tone using 2 whole numbers separated by a comma.
<b>Value Range</b>	0, 200–2000 (0: No tone)
<b>Default Value</b>	425

## HOLD\_TONE\_GAIN

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the gain, in decibels, of the hold tone.
<b>Value Range</b>	-24–6
<b>Default Value</b>	0

## HOLD\_TONE\_RPT

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether the hold tone is repeated.
<b>Value Range</b>	0–1 – 0: No Repeat – 1: Repeat
<b>Default Value</b>	1

## HOLD\_TONE\_TIMING

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the pattern, in milliseconds, of the hold tone using up to 10 whole numbers (off 1, on 1, off 2, on 2...) separated by commas.
<b>Note</b>	<ul style="list-style-type: none"> <li>It is recommended that you set a value of 500 milliseconds or more for the first value (off 1).</li> </ul>

### 5.5.2 Tone Settings

---

<b>Value Range</b>	0–16000 (0: Infinite time)  <b>Note</b> <ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	500,190,190,190,2890

## BELL\_CORE\_PATTERN1\_TIMING

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the cadence, in milliseconds, of pattern ID 1, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas.
<b>Value Range</b>	0–5000 (0: Infinite time)  <b>Note</b> <ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	2000,4000

## BELL\_CORE\_PATTERN2\_TIMING

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the cadence, in milliseconds, of pattern ID 2, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas.
<b>Value Range</b>	0–5000 (0: Infinite time)  <b>Note</b> <ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	800,400,800,4000

## BELL\_CORE\_PATTERN3\_TIMING

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the cadence, in milliseconds, of pattern ID 3, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas.
<b>Value Range</b>	0–5000 (0: Infinite time)  <b>Note</b> <ul style="list-style-type: none"><li>Avoid setting 1–50 for any of the values.</li></ul>
<b>Default Value</b>	400,200,400,200,800,4000

## BELL\_CORE\_PATTERN4\_TIMING

<b>Value Format</b>	Comma-separated Integer
<b>Description</b>	Specifies the cadence, in milliseconds, of pattern ID 4, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas.
<b>Value Range</b>	0–5000 (0: Infinite time)
<b>Note</b>	<ul style="list-style-type: none"> <li>Avoid setting 1–50 for any of the values.</li> </ul>
<b>Default Value</b>	300,200,1000,200,300,4000

## BELL\_CORE\_PATTERN5\_TIMING

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the cadence, in milliseconds, of pattern ID 5, described in the LSSGR, GR-506-CORE, "Signaling for Analog Interfaces" section 14, using up to 8 whole numbers (on 1, off 1, on 2, off 2...) separated by commas.
<b>Value Range</b>	0–5000 (0: Infinite time)
<b>Note</b>	<ul style="list-style-type: none"> <li>Avoid setting 1–50 for any of the values.</li> </ul>
<b>Default Value</b>	500

## 5.5.3 Telephone Settings

### DISPLAY\_NAME\_REPLACE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether the name saved in the phonebook is used in place of the name display if a matching entry is found.
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>Y</b> (Enable Display Name Replace)</li> <li><b>N</b> (Disable Display Name Replace)</li> </ul>
<b>Default Value</b>	<b>Y</b>

### NUMBER\_MATCHING\_LOWER\_DIGIT

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the minimum number of digits with which to match a phonebook entry with an incoming call's caller ID. To specify exact matching of entire numbers only, specify "0".

### 5.5.3 Telephone Settings

---

<b>Value Range</b>	0–15
<b>Default Value</b>	7
<b>Web User Interface Reference</b>	Number Matching Lower Digit (Page 140)

## NUMBER\_MATCHING\_UPPER\_DIGIT

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the maximum number of digits with which to match a phonebook entry with an incoming call's caller ID. To specify exact matching of entire numbers only, specify "0".
<b>Value Range</b>	0–15
<b>Default Value</b>	10
<b>Web User Interface Reference</b>	Number Matching Upper Digit (Page 140)

## DISPLAY\_DATE\_PATTERN

---

<b>Value Format</b>	Integer
<b>Description</b>	Selects the display order pattern for the day and month of the date.
<b>Value Range</b>	0–2 <ul style="list-style-type: none"><li>– 0: Not specified</li><li>– 1: DDMM</li><li>– 2: MMDD</li></ul>
<b>Default Value</b>	0

## DISPLAY\_TIME\_PATTERN

---

<b>Value Format</b>	Integer
<b>Description</b>	Selects the display type for the time (12- or 24-hour format).
<b>Value Range</b>	0–2 <ul style="list-style-type: none"><li>– 0: Not specified</li><li>– 1: 12H</li><li>– 2: 24H</li></ul>
<b>Default Value</b>	0

## DEFAULT\_LANGUAGE

---

<b>Value Format</b>	String
<b>Description</b>	Selects the language to use for the menus and display items on the phone.

<b>Value Range</b>	<p>Only the following values are available:</p> <ul style="list-style-type: none"> <li>• <b>en-GB</b> (English (UK))</li> <li>• <b>de</b> (German)</li> <li>• <b>fr</b> (French)</li> <li>• <b>it</b> (Italian)</li> <li>• <b>es</b> (Spanish)</li> <li>• <b>nl</b> (Dutch)</li> <li>• <b>sv</b> (Swedish)</li> <li>• <b>da</b> (Danish)</li> <li>• <b>pt</b> (Portuguese)</li> <li>• <b>ru</b> (Russian)</li> <li>• <b>el</b> (Greek)</li> <li>• <b>pl</b> (Polish)</li> <li>• <b>cs</b> (Czech)</li> <li>• <b>sk</b> (Slovak)</li> <li>• <b>hu</b> (Hungarian)</li> <li>• <b>hr</b> (Croatian)</li> <li>• <b>uk</b> (Ukrainian)</li> <li>• <b>en-US</b> (English (US))</li> <li>• <b>fr-CA</b> (French (Canadian))</li> <li>• <b>bs</b> (Bosnian)</li> <li>• <b>ro</b> (Romanian)</li> <li>• <b>sl</b> (Slovene)</li> <li>• <b>sr</b> (Serbian)</li> <li>• <b>tr</b> (Turkish)</li> </ul>
<b>Default Value</b>	<b>en-US</b>

## EXTENSION\_PIN

<b>Value Format</b>	String
<b>Description</b>	Specifies the PIN (Personal Identification Number) of the extension. This is used to lock access to the call log and phonebook list. For details, refer to the Operating Instructions on the Panasonic Web site (→ see <b>Introduction</b> ).
<b>Value Range</b>	Max. 10 digits (consisting of 0–9)
<b>Default Value</b>	0000000000
<b>Web User Interface Reference</b>	Extension PIN (Page 140)

## POUND\_KEY\_DELIMITER\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether the # key is treated as a regular dialed digit or a delimiter, when dialed as or after the second digit.

#### 5.5.4 Miscellaneous Telephone Settings

---

<b>Value Range</b>	<ul style="list-style-type: none"><li>Y (# is treated as the end of dialing delimiter)</li><li>N (# is treated as a regular dialed digit)</li></ul>
<b>Default Value</b>	Y

#### 5.5.4 Miscellaneous Telephone Settings

##### [ADJDATA\\_GAIN](#)

<b>Value Format</b>	String
<b>Description</b>	Specifies the gain, in decibels, of 30 separate acoustic settings. Each setting is denoted by a 2 digit hexadecimal number. Enter the change in gain from the default value for each setting. Enter "00" if you do not want to change the setting.
<b>Value Range</b>	06: +6dB 05: +5dB 04: +4dB 03: +3dB 02: +2dB 01: +1dB 00: No change FF: -1dB FE: -2dB FD: -3dB FC: -4dB FB: -5dB FA: -6dB

	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>It is necessary to specify 2 digits for each of the 30 acoustic settings (i.e., a total of 60 digits in succession). Even if you are not changing a value, you must enter "00". The digit order (offset) of each setting is as follows:</li> </ul> <ul style="list-style-type: none"> <li>– 00 = Handset Sending Level (Wide Band)</li> <li>– 02 = Handset Sending Level (Narrow Band)</li> <li>– 04 = Handset Receiving Level (Wide Band)</li> <li>– 06 = Handset Receiving Level (Narrow Band)</li> <li>– 08 = Handset Sidetone Level (Wide Band)</li> <li>– 10 = Handset Sidetone Level (Narrow Band)</li> <li>– 12 = EHS Sending Level (Wide Band)</li> <li>– 14 = EHS Sending Level (Narrow Band)</li> <li>– 16 = EHS Receiving Level (Wide Band)</li> <li>– 18 = EHS Receiving Level (Narrow Band)</li> <li>– 20 = EHS Sidetone Level (Wide Band)</li> <li>– 22 = EHS Sidetone Level (Narrow Band)</li> <li>– 24 = Headset Sending Level (Wide Band)</li> <li>– 26 = Headset Sending Level (Narrow Band)</li> <li>– 28 = Headset Receiving Level (Wide Band)</li> <li>– 30 = Headset Receiving Level (Narrow Band)</li> <li>– 32 = Headset Sidetone Level (Wide Band)</li> <li>– 34 = Headset Sidetone Level (Narrow Band)</li> <li>– 36 = Reserved</li> <li>– 38 = Reserved</li> <li>– 40 = Reserved</li> <li>– 42 = Reserved</li> <li>– 44 = Reserved</li> <li>– 46 = Reserved</li> <li>– 48 = SP-PHONE Sending Level (Wide Band)</li> <li>– 50 = SP-PHONE Sending Level (Narrow Band)</li> <li>– 52 = SP-PHONE Receiving Level (Wide Band)</li> <li>– 54 = SP-PHONE Receiving Level (Narrow Band)</li> <li>– 56 = Reserved</li> <li>– 58 = Ringer Volume Level</li> </ul> <p>For example, the following line in a configuration file would change the Handset Receiving Level (Wide Band) gain -3 decibels.</p> <p><b>ADJDATA_GAIN = "0000FD00...00"</b>  (... is the equivalent of fifty 0s.)</p>
<b>Default Value</b>	Empty string

## ADJDATA\_ATT (KX-UT113/KX-UT123/KX-UT133/KX-UT136 only)

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the switching parameter for using the handset to make a call.
<b>Value Range</b>	0: Regular parameter 1: Extended parameter

## 5.5.5 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only)

Default Value	0
---------------	---

## 5.5.5 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only)

### FLEX\_BUTTON\_FACILITY\_ACTx

Value Format	String
Description	Specifies a particular Facility Action for the flexible button. No facility action will be taken for the button if the string is empty or invalid.  <b>Note</b> <ul style="list-style-type: none"><li>If this parameter is specified, "FLEX_BUTTON_QUICK_DIALx" should be an empty string.</li></ul>
Value Range	Only the following values are available: X_PANASONIC_IPTEL_DN, X_PANASONIC_IPTEL_HEADSET, X_PANASONIC_IPTEL_CONTACT, X_PANASONIC_IPTEL_ONETOUCH, X_PANASONIC_IPTEL_ACD, X_PANASONIC_IPTEL_WRAPUP
Default Value	X_PANASONIC_IPTEL_DN
Web User Interface Reference	Type (No. 1–24) (Page 134)

### FLEX\_BUTTON\_FACILITY\_ARGx

Value Format	String
Description	Optional argument associated with the specified Facility Action for the flexible button. For details, see <b>6.3.1 Flexible Button Settings</b> .
Value Range	Max. 32 characters
Default Value	1
Web User Interface Reference	Parameter (No. 1–24) (Page 134)

### FLEX\_BUTTON\_QUICK\_DIALx

Value Format	String
--------------	--------

<b>Description</b>	Specifies a quick dial destination number to be used for the flexible button.
<b>Note</b>	<ul style="list-style-type: none"> <li>If this parameter is specified, "<b>FLEX_BUTTON_FACILITY_ACTx</b>" should be an empty string.</li> <li>This parameter cannot be specified via Web user interface programming. Therefore, when using Web user programming and configuration file programming in conjunction, "<b>FLEX_BUTTON_FACILITY_ACTx</b>" should be set to "<b>X_PANASONIC_IPTEL_ONETOUCH</b>".</li> </ul>
<b>Value Range</b>	Max. 32 characters (consisting of 0–9, *, and #)
<b>Default Value</b>	Empty string

## **FLEX\_BUTTON\_LABELx**

<b>Value Format</b>	String
<b>Description</b>	Specifies the message to be displayed on the screen when the flexible button is pressed.
<b>Value Range</b>	Max. 10 characters
<b>Note</b>	<ul style="list-style-type: none"> <li>You can use Unicode characters for this setting.</li> </ul>
<b>Default Value</b>	<b>For KX-UT133/KX-UT136:</b> Not stored. <b>For KX-UT248:</b> No. 1: 1, No. 2: 2, No. 3: 3... No. 24: 24
<b>Web User Interface Reference</b>	Label Name (No. 1–24) (Page 135)

## **5.5.6 XML Application Settings**

### **XMLAPP\_ENABLE**

<b>Value Format</b>	Boolean
<b>Description</b>	Selects whether to enable the XML application feature.
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>y</b> (The port is opened.)</li> <li><b>n</b> (The port is closed.)</li> </ul>
<b>Default Value</b>	<b>n</b>
<b>Web User Interface Reference</b>	Enable Application (Page 93)

### **XMLAPP\_USERID**

<b>Value Format</b>	String
---------------------	--------

### 5.5.6 XML Application Settings

---

<b>Description</b>	Specifies the authentication ID required to access the XML application server.
<b>Value Range</b>	Max. 63 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication ID (Page 93)

## XMLAPP\_USERPASS

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the authentication password used to access the XML application server.
<b>Value Range</b>	Max. 63 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication Password (Page 94)

## XMLAPP\_START\_URL

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL that is accessed when the unit starts up, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	URL (Page 142)

## XMLAPP\_INITIAL\_URL

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL that is accessed when the application is started from the unit's menu, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	URL (Page 143)

## XMLAPP\_INCOMING\_URL

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL that is accessed when the unit receives a call, to check for XML data.

<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	URL (Page 143)

## [XMLAPP\\_TALKING\\_URL](#)

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL that is accessed when the unit is on a call, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	URL (Page 143)

## [XMLAPP\\_MAKECALL\\_URL](#)

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL that is accessed when the unit makes a call, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	URL (Page 143)

## [XMLAPP\\_CALLLOG\\_URL](#)

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL that is accessed when the call log is accessed, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	URL (Page 144)

## [XMLAPP\\_IDLING\\_URL](#)

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL that is accessed when the unit is idle, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Empty string

## 5.5.6 XML Application Settings

---

<b>Web User Interface Reference</b>	URL (Page 144)
-------------------------------------	----------------

### **XMLAPP\_LDAP\_URL**

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the URL that is accessed when the phonebook is accessed, to check for XML data.
<b>Value Range</b>	Max. 244 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	URL (Page 144)

### **XMLAPP\_LDAP\_USERID**

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the authentication ID required to access the network phonebook server.
<b>Value Range</b>	Max. 127 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication ID (Page 144)

### **XMLAPP\_LDAP\_USERPASS**

---

<b>Value Format</b>	String
<b>Description</b>	Specifies the authentication password used to access the networkphonebook server.
<b>Value Range</b>	Max. 127 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication Password (Page 145)

### **XML\_INITIATE\_KEY\_SOFT1**

---

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to activate the XML application or operate normally when the corresponding button is pressed during standby mode.
<b>Value Range</b>	<b>Y:</b> Activate XML application <b>N:</b> Normal operation
<b>Default Value</b>	<b>N</b>

## XML\_INITIATE\_KEY\_SOFT2

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to activate the XML application or operate normally when the corresponding button is pressed during standby mode.
<b>Value Range</b>	<b>Y:</b> Activate XML application <b>N:</b> Normal operation
<b>Default Value</b>	<b>N</b>

## XML\_INITIATE\_KEY\_SOFT3

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to activate the XML application or operate normally when the corresponding button is pressed during standby mode.
<b>Value Range</b>	<b>Y:</b> Activate XML application <b>N:</b> Normal operation
<b>Default Value</b>	<b>N</b>

## XML\_INITIATE\_KEY\_SOFT4

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to activate the XML application or operate normally when the corresponding button is pressed during standby mode.
<b>Value Range</b>	<b>Y:</b> Activate XML application <b>N:</b> Normal operation
<b>Default Value</b>	<b>N</b>

## XML\_INITIATE\_KEY\_FWDDND

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to activate the XML application or operate normally when the corresponding button is pressed during standby mode.
<b>Value Range</b>	<b>Y:</b> Activate XML application <b>N:</b> Normal operation
<b>Default Value</b>	<b>N</b>

## XML\_INITIATE\_KEY\_FLASH

<b>Value Format</b>	Boolean
---------------------	---------

### 5.6.1 Codec Settings

---

<b>Description</b>	Specifies whether to activate the XML application or operate normally when the corresponding button is pressed during standby mode.
<b>Value Range</b>	<b>Y:</b> Activate XML application <b>N:</b> Normal operation
<b>Default Value</b>	<b>N</b>

## XML\_ERROR\_INFORMATION

---

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to display an error when an error occurs while operating an XML application.
<b>Value Range</b>	<b>Y:</b> Error displayed <b>N:</b> Error not displayed
<b>Default Value</b>	<b>Y</b>

## XML\_HTTPPD\_PORT

---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the destination port number for XML feature connection requests.
<b>Value Range</b>	1024-49151
<b>Default Value</b>	6666

## 5.6 VoIP Settings

---

### 5.6.1 Codec Settings

#### CODEC\_G711\_REQ

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether to set "PCM" as a codec selection automatically when the codec is set to any codec selection other than "PCM".
<b>Value Range</b>	<ul style="list-style-type: none"><li>• 0 (Do not set "PCM")</li><li>• 1 (Set "PCM")</li></ul>
<b>Default Value</b>	1

## CODEC\_G729\_PARAM

<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether to add an attribute line, "a=fmtp:18 annexb=no", to SDP when the codec is set to "G729A".
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• 0 (Do not add "a=fmtp:18 annexb=no")</li> <li>• 1 (Add "a=fmtp:18 annexb=no")</li> </ul>
<b>Default Value</b>	0

## CODEC\_ENABLEEx\_n

<b>Parameter Name Example</b>	CODEC_ENABLEEx_1, CODEC_ENABLEEx_2, ..., CODEC_ENABLEEx_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable the codec specified in the parameter list.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• The "x" character in the parameter title should be changed to one of the following numbers, according to the codec to be changed.           <ul style="list-style-type: none"> <li>– 0: G.722</li> <li>– 1: PCMA</li> <li>– 2: G.726-32</li> <li>– 3: G.729A</li> <li>– 4: PCMU</li> </ul> </li> <li>• For codec setting examples, see <a href="#">2.5.1 Examples of Codec Settings</a>.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable)</li> <li>• <b>N</b> (Disable)</li> </ul>
<b>Default Value</b>	<b>Y</b>
<b>Web User Interface Reference</b>	<ul style="list-style-type: none"> <li>• G722 (Enable) (Page 119)</li> <li>• PCMA (Enable) (Page 120)</li> <li>• G726-32 (Enable) (Page 120)</li> <li>• G729A (Enable) (Page 120)</li> <li>• PCMU (Enable) (Page 121)</li> </ul>

## CODEC\_PRIORITYx\_n

<b>Parameter Name Example</b>	CODEC_PRIORITYx_1, CODEC_PRIORITYx_2, ..., CODEC_PRIORITYx_6
<b>Value Format</b>	Integer

## 5.6.2 RTP Settings

<b>Description</b>	Specifies the priority order for the codec.
<b>Note</b>	<ul style="list-style-type: none"><li>The "x" character in the parameter title should be changed to one of the following numbers, according to the codec to be changed.<ul style="list-style-type: none"><li>0: G.722</li><li>1: PCMA</li><li>2: G.726-32</li><li>3: G.729A</li><li>4: PCMU</li></ul></li><li>For codec setting examples, see <b>2.5.1 Examples of Codec Settings</b>.</li></ul>
<b>Value Range</b>	1–255
<b>Default Value</b>	1
<b>Web User Interface Reference</b>	<ul style="list-style-type: none"><li>G722 (Priority) (Page 119)</li><li>PCMA (Priority) (Page 120)</li><li>G726-32 (Priority) (Page 120)</li><li>G729A (Priority) (Page 121)</li><li>PCMU (Priority) (Page 121)</li></ul>

## 5.6.2 RTP Settings

### DSCP\_RTP\_n

<b>Parameter Name Example</b>	<b>DSCP_RTP_1, DSCP_RTP_2, ..., DSCP_RTP_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Selects the DSCP level of DiffServ applied to RTP packets.
<b>Value Range</b>	0–63
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	RTP Packet QoS (DSCP) (Page 116)

### DSCP\_RTCP\_n

<b>Parameter Name Example</b>	<b>DSCP_RTCP_1, DSCP_RTCP_2, ..., DSCP_RTCP_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Selects the DSCP level of DiffServ applied to RTCP packets.
<b>Value Range</b>	0–63
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	RTCP Packet QoS (DSCP) (Page 116)

## RTCP\_INTVL\_n

<b>Parameter Name Example</b>	RTCP_INTVL_1, RTCP_INTVL_2, ..., RTCP_INTVL_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in seconds, between RTCP packets.
<b>Value Range</b>	5–65535
<b>Default Value</b>	5
<b>Web User Interface Reference</b>	RTCP Interval (Page 117)

## MAX\_DELAY\_n

<b>Parameter Name Example</b>	MAX_DELAY_1, MAX_DELAY_2, ..., MAX_DELAY_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the maximum delay, in 10-millisecond units, of the jitter buffer.
<b>Value Range</b>	3–50 ( $\times 10$ ms)
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>This setting is subject to the following conditions:           <ul style="list-style-type: none"> <li>This value must be greater than "NOM_DELAY"</li> <li>This value must be greater than "MIN_DELAY"</li> <li>"NOM_DELAY" must be greater than or equal to "MIN_DELAY"</li> </ul> </li> </ul>
<b>Default Value</b>	20
<b>Web User Interface Reference</b>	Maximum Delay (Page 117)

## MIN\_DELAY\_n

<b>Parameter Name Example</b>	MIN_DELAY_1, MIN_DELAY_2, ..., MIN_DELAY_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the minimum delay, in 10-millisecond units, of the jitter buffer.
<b>Value Range</b>	1 or 2 ( $\times 10$ ms)
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>This setting is subject to the following conditions:           <ul style="list-style-type: none"> <li>This value must be less than or equal to "NOM_DELAY"</li> <li>This value must be less than "MAX_DELAY"</li> <li>"MAX_DELAY" must be greater than "NOM_DELAY"</li> </ul> </li> </ul>
<b>Default Value</b>	2
<b>Web User Interface Reference</b>	Minimum Delay (Page 117)

## 5.6.2 RTP Settings

---

### NOM\_DELAY\_n

<b>Parameter Name Example</b>	NOM_DELAY_1, NOM_DELAY_2, ..., NOM_DELAY_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the initial delay, in 10-millisecond units, of the jitter buffer.
<b>Value Range</b>	1–7 ( $\times$ 10 ms)  <b>Note</b> <ul style="list-style-type: none"><li>• This setting is subject to the following conditions:<ul style="list-style-type: none"><li>– This value must be greater than or equal to "<b>MIN_DELAY</b>"</li><li>– This value must be less than "<b>MAX_DELAY</b>"</li></ul></li></ul>
<b>Default Value</b>	2
<b>Web User Interface Reference</b>	Initial Delay (Page 118)

### RTP\_PORT\_MIN

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the lowest port number that the unit will use for RTP packets.  <b>Note</b> <ul style="list-style-type: none"><li>• If port numbers are specified in <b>[Channel 1–25]</b> in <b>4.3.6.3 External RTP Port</b> in the Web user interface, this setting is ignored and the corresponding external RTP port is enabled.</li></ul>
<b>Value Range</b>	1024–48750 (even number only)  <b>Note</b> <ul style="list-style-type: none"><li>• The value for this setting must be less than or equal to "<b>RTP_PORT_MAX</b>" - 400.</li><li>• Changing this setting may affect the number of simultaneous calls that can be made. Therefore, when setting this parameter, be aware that the maximum number of necessary ports can be calculated as shown below: No. of lines <math>\times</math> No. of channels <math>\times</math> 2 <math>\times</math> 10 (No. of terminals)</li></ul>
<b>Default Value</b>	16000
<b>Web User Interface Reference</b>	Minimum RTP Port Number (Page 114)

### RTP\_PORT\_MAX

<b>Value Format</b>	Integer
---------------------	---------

<b>Description</b>	Specifies the highest port number that the unit will use for RTP packets.
<b>Note</b>	<ul style="list-style-type: none"> <li>If port numbers are specified in [Channel 1–25] in <b>4.3.6.3 External RTP Port</b> in the Web user interface, this setting is ignored and the corresponding external RTP port is enabled.</li> </ul>
<b>Value Range</b>	1424–49150 (even number only)
<b>Note</b>	<ul style="list-style-type: none"> <li>The value for this setting must be greater than or equal to "<b>RTP_PORT_MIN</b>" + 400.</li> <li>Changing this setting may affect the number of simultaneous calls that can be made. Therefore, when setting this parameter, be aware that the maximum number of necessary ports can be calculated as shown below: No. of lines × No. of channels × 2 × 10 (No. of terminals)</li> </ul>
<b>Default Value</b>	20000
<b>Web User Interface Reference</b>	Maximum RTP Port Number (Page 115)

## RTP\_PTIME

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in milliseconds, between transmissions of RTP packets.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>20</li> <li>30</li> <li>40</li> </ul>
<b>Default Value</b>	20
<b>Web User Interface Reference</b>	RTP Packet Time (Page 114)

## RTCP\_ENABLE\_n

<b>Parameter Name Example</b>	RTCP_ENABLE_1, RTCP_ENABLE_2, ..., RTCP_ENABLE_6
<b>Value Format</b>	Boolean
<b>Description</b>	Selects whether to enable or disable RTCP (Real-Time Transport Control Protocol). For details, refer to RFC 3550.
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>y</b> (Enable RTCP)</li> <li><b>n</b> (Disable RTCP)</li> </ul>
<b>Default Value</b>	<b>n</b>
<b>Web User Interface Reference</b>	RTCP Enable (Page 117)

### 5.6.3 Miscellaneous VoIP Settings

---

#### RTCP\_SEND\_BY\_SDP\_n

<b>Parameter Name Example</b>	RTCP_SEND_BY_SDP_1, RTCP_SEND_BY_SDP_2, ..., RTCP_SEND_BY_SDP_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether to send RTCP signals by SDP (Session Description Protocol).
<b>Value Range</b>	0–1 <ul style="list-style-type: none"><li>– 0: Send RTCP signals using the value specified in "RTCP_INTVL_n", if the "RTCP_ENABLE_n" parameter is enabled.</li><li>– 1: Send RTCP signals using the value specified in the SDP attribute "a=rtcp:".</li></ul>
<b>Default Value</b>	0

#### RTP\_CLOSE\_ENABLE\_n

<b>Parameter Name Example</b>	RTP_CLOSE_ENABLE_1, RTP_CLOSE_ENABLE_2, ..., RTP_CLOSE_ENABLE_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable processing to close held RTP sockets.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Enable RTP Close)</li><li>• <b>N</b> (Disable RTP Close)</li></ul>
<b>Default Value</b>	Y

### 5.6.3 Miscellaneous VoIP Settings

#### OUTBANDDTMF\_n

<b>Parameter Name Example</b>	OUTBANDDTMF_1, OUTBANDDTMF_2, ..., OUTBANDDTMF_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies the method for transmitting DTMF tones.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Outband [use telephone-event])</li><li>• <b>N</b> (Inband)</li></ul>
<b>Note</b>	<ul style="list-style-type: none"><li>• If set to "Y", DTMF tones will be sent through SDP, compliant with RFC 2833.</li><li>• If set to "N", DTMF tones will be encoded in the RTP stream.</li></ul>
<b>Default Value</b>	Y
<b>Web User Interface Reference</b>	DTMF Type (Page 118)

## DTMF\_RELAY\_n

<b>Parameter Name Example</b>	DTMF_RELAY_1, DTMF_RELAY_2, ..., DTMF_RELAY_6
<b>Value Format</b>	Boolean
<b>Description</b>	Selects whether DTMF tones are sent in the SIP INFO message.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b></li> <li>• <b>N</b></li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If set to "Y", DTMF tones will be sent in the SIP INFO message.</li> <li>• If set to "N", the method selected in "OUTBANDDTMF_n" will be used.</li> </ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	DTMF Relay (Page 118)

## OUTBANDDTMF\_VOL

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the volume (in decibels [dB]) of the DTMF tone using RFC 2833.
<b>Value Range</b>	-63–0
<b>Default Value</b>	-5

## INBANDDTMF\_VOL

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the volume (in decibels [dB]) of in-band DTMF tones.
<b>Value Range</b>	-46–0
<b>Default Value</b>	-5

## TELEVENT\_PAYLOAD

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the RFC 2833 payload type for DTMF tones.
<b>Note</b>	<ul style="list-style-type: none"> <li>• This setting is available only when "OUTBANDDTMF_n" is set to "Y".</li> </ul>
<b>Value Range</b>	96–127
<b>Default Value</b>	101

<b>Web User Interface Reference</b>	Telephone-event Payload Type (Page 115)
-------------------------------------	---

## RFC2543\_HOLD\_ENABLE\_n

<b>Parameter Name Example</b>	RFC2543_HOLD_ENABLE_1, RFC2543_HOLD_ENABLE_2, ..., RFC2543_HOLD_ENABLE_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable the RFC 2543 Call Hold feature on this line.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable RFC 2543 Call Hold)</li> <li>• <b>N</b> (Disable RFC 2543 Call Hold)</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If set to "Y", the "c=0.0.0.0" syntax will be set in SDP when sending a re-INVITE message to hold the call.</li> <li>• If set to "N", the "c=x.x.x.x" syntax will be set in SDP.</li> </ul>
<b>Default Value</b>	Y
<b>Web User Interface Reference</b>	Supports RFC 2543 (c=0.0.0.0) (Page 119)

## DTMF\_SIGNAL\_LEN

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the length of the DTMF signal, in milliseconds.
<b>Value Range</b>	60–200
<b>Default Value</b>	180

## DTMF\_INTDIGIT\_TIM

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in milliseconds, between DTMF signals.
<b>Value Range</b>	60–200
<b>Default Value</b>	90

## 5.7 Line Settings

### 5.7.1 Call Control Settings

#### DISPLAY\_NAME\_n

<b>Parameter Name Example</b>	DISPLAY_NAME_1, DISPLAY_NAME_2, ..., DISPLAY_NAME_6
<b>Value Format</b>	String
<b>Description</b>	Specifies the name to display as the caller on the other party's phone when you make a call.
<b>Value Range</b>	Max. 24 characters
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• You can use Unicode characters for this setting.</li> </ul>
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Display Name (Page 126)

#### VM\_NUMBER\_n

<b>Parameter Name Example</b>	VM_NUMBER_1, VM_NUMBER_2, ..., VM_NUMBER_6
<b>Value Format</b>	String
<b>Description</b>	Specifies the phone number used to access the voice mail server.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• Your phone system must support voice mail.</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Voice Mail Access Number (Page 126)

#### DIAL\_PLAN\_n

<b>Parameter Name Example</b>	DIAL_PLAN_1, DIAL_PLAN_2, ..., DIAL_PLAN_6
<b>Value Format</b>	String
<b>Description</b>	Specifies a dial format, such as specific phone numbers, that control which numbers can be dialed or how to handle the call when making a call. For details, see <b>6.2 Dial Plan</b> .
<b>Value Range</b>	Max. 500 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Dial Plan (max 1000 columns) (Page 128)

### 5.7.1 Call Control Settings

## DIAL\_PLAN\_NOT\_MATCH\_ENABLE\_n

<b>Parameter Name Example</b>	DIAL_PLAN_NOT_MATCH_ENABLE_1, DIAL_PLAN_NOT_MATCH_ENABLE_2, ..., DIAL_PLAN_NOT_MATCH_ENABLE_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable dial plan filtering so that a call is not made when the dialed number does not match any of the dial formats specified in "DIAL_PLAN_n".
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable dial plan filtering)</li> <li>• <b>N</b> (Disable dial plan filtering)</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If set to "Y", the dialed number will not be sent to the line when the number dialed by the user does not match any of the dial formats specified in the dial plan.</li> <li>• If set to "N", the dialed number will be sent to the line, even if the number dialed by the user does not match any of the dial formats specified in the dial plan.</li> </ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	Call Even If Dial Plan Does Not Match (Page 128)

## SHARED\_CALL\_ENABLE\_n

<b>Parameter Name Example</b>	SHARED_CALL_ENABLE_1, SHARED_CALL_ENABLE_2, ..., SHARED_CALL_ENABLE_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable the Shared Call feature of the SIP server, which is used to share one line among the units.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable shared call)</li> <li>• <b>N</b> (Disable shared call)</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• You cannot set both "SHARED_CALL_ENABLE_n" and "FWD_DND_SYNCHRO_ENABLE_n" to "Y" at the same time.</li> <li>• Availability depends on your phone system.</li> </ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	Enable Shared Call (Page 127)

## FWD\_DND\_SYNCHRO\_ENABLE\_n

<b>Parameter Name Example</b>	<code>FWD_DND_SYNCHRO_ENABLE_1, FWD_DND_SYNCHRO_ENABLE_2, ..., FWD_DND_SYNCHRO_ENABLE_6</code>
<b>Value Format</b>	Boolean
<b>Description</b>	<p>Specifies whether to synchronize the Do Not Disturb and Call Forward settings, configured via the Web user interface or phone user interface, between the unit and the portal server that is provided by your phone system dealer.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>Even if you specify "Y", this feature may not function properly if your phone system does not support it. Before you configure this setting, consult your phone system dealer.</li> <li>You cannot set both "<code>SHARED_CALL_ENABLE_n</code>" and "<code>FWD_DND_SYNCHRO_ENABLE_n</code>" to "Y" at the same time.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>Y</b> (Enable Do Not Disturb/Call Forward synchronization)</li> <li><b>N</b> (Disable Do Not Disturb/Call Forward synchronization)</li> </ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	Synchronize Do Not Disturb and Call Forward (Page 127)

## RESOURCELIST\_URI\_n

<b>Parameter Name Example</b>	<code>RESOURCELIST_URI_1, RESOURCELIST_URI_2, ..., RESOURCELIST_URI_6</code>
<b>Value Format</b>	String
<b>Description</b>	<p>Specifies the Uniform Resource Identifier string for the resource list, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:user@example.com". For details, refer to RFC 4662.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>In a SIP URI, the user part ("user" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters.</li> <li>When the BLF feature is assigned to a flexible button, it may be necessary to specify this parameter depending on your phone system. For details about flexible buttons, see <b>6.3 Flexible Buttons (KX-UT133/KX-UT136/KX-UT248 only)</b>.</li> </ul>
<b>Value Range</b>	Max. 195 characters (except ", &, :, ;, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Resource List URI (Page 128)

## 5.7.1 Call Control Settings

---

### CW\_ENABLE\_n

<b>Parameter Name Example</b>	<code>CW_ENABLE_1, CW_ENABLE_2, ..., CW_ENABLE_6</code>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether automatic call waiting is enabled.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <code>Y</code> (Enable Call Waiting)</li><li>• <code>N</code> (Disable Call Waiting)</li></ul>
<b>Default Value</b>	<code>Y</code>

### RETURN\_VOL\_SET\_DEFAULT\_ENABLE

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether the volume is returned to its default setting after each call.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <code>Y</code> (Volume returns to the default setting after each call)</li><li>• <code>N</code> (Volume does not change after each call)</li></ul>
<b>Default Value</b>	<code>N</code>

### FLASH\_RECALL\_TERMINATE

<b>Value Format</b>	Boolean
<b>Description</b>	Selects the function of the FLASH/RECALL button during a conversation.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <code>Y</code> (Terminate)</li><li>• <code>N</code> (EFA)</li></ul>
<b>Default Value</b>	<code>Y</code>
<b>Web User Interface Reference</b>	Flash/Recall Button (Page 124)

### FLASHHOOK\_CONTENT\_TYPE

<b>Value Format</b>	String
<b>Description</b>	Specifies the type of signal sent when sending a flash hook event.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <code>Signal</code></li><li>• <code>flashhook</code></li></ul>
<b>Default Value</b>	<code>Signal</code>
<b>Web User Interface Reference</b>	Flash Hook Event (Page 125)

## **VOICE\_MESSAGE\_AVAILABLE**

<b>Value Format</b>	Boolean
<b>Description</b>	Selects how the existence of voice messages is determined when a "Messages-Waiting: yes" message is received.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Determines that voice messages exist when "Messages-Waiting: yes" is received with a "Voice-Message" line included.)</li> <li>• <b>N</b> (Determines that voice messages exist when "Messages-Waiting: yes" is received even without a "Voice-Message" line included.)</li> </ul>
<b>Default Value</b>	<b>Y</b>

## **HOLD\_SOUND\_PATH\_n**

<b>Parameter Name Example</b>	<b>HOLD_SOUND_PATH_1, HOLD_SOUND_PATH_2, ..., HOLD_SOUND_PATH_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Selects whether the unit's hold tone or the network server's hold tone (Music on hold) is played when a party is put on hold.  <b>Note</b> <ul style="list-style-type: none"> <li>• It is necessary to set the following parameters to play the unit's hold tone.           <ul style="list-style-type: none"> <li>– <b>HOLD_TONE_FRQ</b></li> <li>– <b>HOLD_TONE_GAIN</b></li> <li>– <b>HOLD_TONE_RPT</b></li> <li>– <b>HOLD_TONE_TIMING</b></li> </ul> </li> </ul>
<b>Value Range</b>	0–1 <ul style="list-style-type: none"> <li>– 0: The unit's hold tone is played.</li> <li>– 1: The network server's hold tone (Music on hold) is played.</li> </ul>
<b>Default Value</b>	0

## **5.7.2 SIP Settings**

### **SIP\_USER\_AGENT**

<b>Value Format</b>	String
<b>Description</b>	Specifies the text string to send as the user agent in the headers of SIP messages.

### 5.7.2 SIP Settings

<b>Value Range</b>	Max. 40 characters
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• An empty string is not allowed.</li> <li>• If "{mac}" is included in this parameter, it will be replaced with the unit's MAC address in lower-case.</li> <li>• If "{MAC}" is included in this parameter, it will be replaced with the unit's MAC address in upper-case.</li> <li>• If "{MODEL}" is included in this parameter, it will be replaced with the unit's model name.</li> <li>• If "{fwver}" is included in this parameter, it will be replaced with the firmware version of the unit.</li> </ul>
<b>Default Value</b>	Panasonic_{MODEL}/{fwver} ({mac})
<b>Web User Interface Reference</b>	SIP User Agent (Page 104)

## PHONE\_NUMBER\_n

<b>Parameter Name Example</b>	PHONE_NUMBER_1, PHONE_NUMBER_2, ..., PHONE_NUMBER_6
<b>Value Format</b>	String
<b>Description</b>	Specifies the phone number to use as the user ID required for registration to the SIP registrar server.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• When registering using a user ID that is not a phone number, you should use the "SIP_URI_n" setting.</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Phone Number (Page 105)

## SIP\_URI\_n

<b>Parameter Name Example</b>	SIP_URI_1, SIP_URI_2, ..., SIP_URI_6
<b>Value Format</b>	String
<b>Description</b>	Specifies the unique ID used by the SIP registrar server, which consists of "sip:", a user part, the "@" symbol, and a host part, for example, "sip:user@example.com".
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• When registering using a user ID that is not a phone number, you should use this setting.</li> <li>• In a SIP URI, the user part ("user" in the example above) can contain up to 63 characters, and the host part ("example.com" in the example above) can contain up to 127 characters.</li> </ul>
<b>Value Range</b>	Max. 195 characters (except ", &, :, ;, <, >, and space)

<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	SIP URI (Page 106)

## LINE\_ENABLE\_n

<b>Parameter Name Example</b>	<code>LINE_ENABLE_1, LINE_ENABLE_2, ..., LINE_ENABLE_6</code>
<b>Value Format</b>	String
<b>Description</b>	Specifies whether a line is enabled or disabled.  <b>Note</b> <ul style="list-style-type: none"> <li>Even when this parameter is enabled, if the "PROFILE_ENABLEn" parameter is disabled, the line will be disabled.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>Disabled</b></li> <li><b>Enabled</b></li> </ul>
<b>Default Value</b>	<b>Enabled</b>

## PROFILE\_ENABLEn

<b>Parameter Name Example</b>	<code>PROFILE_ENABLE1, PROFILE_ENABLE2, ..., PROFILE_ENABLE6</code>
<b>Value Format</b>	String
<b>Description</b>	Specifies whether a line is enabled or disabled.  <b>Note</b> <ul style="list-style-type: none"> <li>Even when this parameter is enabled, if the "LINE_ENABLE_n" parameter is disabled, the line will be disabled.</li> </ul>
<b>Value Range</b>	<ul style="list-style-type: none"> <li><b>Disabled</b></li> <li><b>Enabled</b></li> </ul>
<b>Default Value</b>	<b>Enabled</b>

## SIP\_AUTHID\_n

<b>Parameter Name Example</b>	<code>SIP_AUTHID_1, SIP_AUTHID_2, ..., SIP_AUTHID_6</code>
<b>Value Format</b>	String
<b>Description</b>	Specifies the authentication ID required to access the SIP server.
<b>Value Range</b>	Max. 127 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication ID (Page 108)

## 5.7.2 SIP Settings

---

### SIP\_PASS\_n

<b>Parameter Name Example</b>	<code>SIP_PASS_1, SIP_PASS_2, ..., SIP_PASS_6</code>
<b>Value Format</b>	String
<b>Description</b>	Specifies the authentication password used to access the SIP server.
<b>Value Range</b>	Max. 127 characters (except ", &, :, <, >, and space)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Authentication Password (Page 109)

### SIP\_SRC\_PORT\_n

<b>Parameter Name Example</b>	<code>SIP_SRC_PORT_1, SIP_SRC_PORT_2, ..., SIP_SRC_PORT_6</code>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the source port number used by the unit for SIP communication.
<b>Value Range</b>	1024–49151
<b>Note</b>	<ul style="list-style-type: none"><li>The SIP port number for each line must be unique.</li></ul>
<b>Default Value</b>	5060 (for <code>SIP_SRC_PORT_1</code> ) 5070 (for <code>SIP_SRC_PORT_2</code> ) 5080 (for <code>SIP_SRC_PORT_3</code> ) 5090 (for <code>SIP_SRC_PORT_4</code> ) 5100 (for <code>SIP_SRC_PORT_5</code> ) 5110 (for <code>SIP_SRC_PORT_6</code> )
<b>Web User Interface Reference</b>	Source Port (Page 108)

### SIP\_PRXY\_ADDR\_n

<b>Parameter Name Example</b>	<code>SIP_PRXY_ADDR_1, SIP_PRXY_ADDR_2, ..., SIP_PRXY_ADDR_6</code>
<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address or FQDN of the SIP proxy server.
<b>Value Range</b>	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Proxy Server Address (Page 106)

### SIP\_PRXY\_PORT\_n

<b>Parameter Name Example</b>	<code>SIP_PRXY_PORT_1, SIP_PRXY_PORT_2, ..., SIP_PRXY_PORT_6</code>
-------------------------------	---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number to use for communication with the SIP proxy server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060
<b>Web User Interface Reference</b>	Proxy Server Port (Page 107)

## SIP\_RGSTR\_ADDR\_n

<b>Parameter Name Example</b>	<b>SIP_RGSTR_ADDR_1, SIP_RGSTR_ADDR_2, ..., SIP_RGSTR_ADDR_6</b>
<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address or FQDN of the SIP registrar server.
<b>Value Range</b>	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Registrar Server Address (Page 106)

## SIP\_RGSTR\_PORT\_n

<b>Parameter Name Example</b>	<b>SIP_RGSTR_PORT_1, SIP_RGSTR_PORT_2, ..., SIP_RGSTR_PORT_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number to use for communication with the SIP registrar server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060
<b>Web User Interface Reference</b>	Registrar Server Port (Page 106)

## SIP\_SVCDOMAIN\_n

<b>Parameter Name Example</b>	<b>SIP_SVCDOMAIN_1, SIP_SVCDOMAIN_2, ..., SIP_SVCDOMAIN_6</b>
<b>Value Format</b>	String
<b>Description</b>	Specifies the domain name provided by your phone system dealer. The domain name is the part of the SIP URI that comes after the "@" symbol.
<b>Value Range</b>	Max. 127 characters
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Service Domain (Page 108)

## 5.7.2 SIP Settings

---

### REG\_EXPIRE\_TIME\_n

<b>Parameter Name Example</b>	REG_EXPIRE_TIME_1, REG_EXPIRE_TIME_2, ..., REG_EXPIRE_TIME_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the length of time, in seconds, that the registration remains valid. This value is set in the "Expires" header of the REGISTER request.
<b>Value Range</b>	1–4294967295
<b>Default Value</b>	3600

### REG\_INTERVAL\_RATE\_n

<b>Parameter Name Example</b>	REG_INTERVAL_RATE_1, REG_INTERVAL_RATE_2, ..., REG_INTERVAL_RATE_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the percentage of the "expires" value after which to refresh registration by sending a new REGISTER message in the same dialog.
<b>Value Range</b>	1–100
<b>Default Value</b>	90

### SIP\_SESSION\_TIME\_n

<b>Parameter Name Example</b>	SIP_SESSION_TIME_1, SIP_SESSION_TIME_2, ..., SIP_SESSION_TIME_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the length of time, in seconds, that the unit waits before terminating SIP sessions when no reply to repeated requests is received. For details, refer to RFC 4028.
<b>Value Range</b>	0, 60–65535 (0: Disable)
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	Supports Session Timer (RFC 4028) (Page 112)

### SIP\_SESSION\_METHOD\_n

<b>Parameter Name Example</b>	SIP_SESSION_METHOD_1, SIP_SESSION_METHOD_2, ..., SIP_SESSION_METHOD_6
<b>Value Format</b>	Integer
<b>Description</b>	Selects the refreshing method of SIP sessions.

<b>Value Range</b>	0–2 – 0: reINVITE – 1: UPDATE – 2: AUTO
<b>Default Value</b>	0

## DSCP\_SIP\_n

<b>Parameter Name Example</b>	DSCP_SIP_1, DSCP_SIP_2, ..., DSCP_SIP_6
<b>Value Format</b>	Integer
<b>Description</b>	Selects the DSCP level of DiffServ applied to SIP packets.
<b>Value Range</b>	0–63
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	SIP Packet QoS (DSCP) (Page 112)

## SIP\_2NDPROXY\_ADDR\_n

<b>Parameter Name Example</b>	SIP_2NDPROXY_ADDR_1, SIP_2NDPROXY_ADDR_2, ..., SIP_2NDPROXY_ADDR_6
<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address of the secondary SIP proxy server.
	<b>Note</b> <ul style="list-style-type: none"><li>• This setting is available only when "SIP_PRXY_ADDR_n" is specified in IP address notation.</li></ul>
<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string

## SIP\_2NDPROXY\_PORT\_n

<b>Parameter Name Example</b>	SIP_2NDPROXY_PORT_1, SIP_2NDPROXY_PORT_2, ..., SIP_2NDPROXY_PORT_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number to use for communication with the secondary SIP proxy server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060

## 5.7.2 SIP Settings

---

### SIP\_2NDRGSTR\_ADDR\_n

<b>Parameter Name Example</b>	<b>SIP_2NDRGSTR_ADDR_1, SIP_2NDRGSTR_ADDR_2, ..., SIP_2NDRGSTR_ADDR_6</b>
<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address of the secondary SIP registrar server. <b>Note</b> <ul style="list-style-type: none"><li>This setting is available only when "SIP_RGSTR_ADDR_n" is specified in IP address notation.</li></ul>
<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string

### SIP\_2NDRGSTR\_PORT\_n

<b>Parameter Name Example</b>	<b>SIP_2NDRGSTR_PORT_1, SIP_2NDRGSTR_PORT_2, ..., SIP_2NDRGSTR_PORT_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number to use for communication with the secondary SIP registrar server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060

### SIP\_TIMER\_T1\_n

<b>Parameter Name Example</b>	<b>SIP_TIMER_T1_1, SIP_TIMER_T1_2, ..., SIP_TIMER_T1_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the default interval, in milliseconds, between transmissions of SIP messages. For details, refer to RFC 3261.
<b>Value Range</b>	<ul style="list-style-type: none"><li>250</li><li>500</li><li>1000</li><li>2000</li><li>4000</li></ul>
<b>Default Value</b>	500
<b>Web User Interface Reference</b>	T1 Timer (Page 110)

### SIP\_TIMER\_T2\_n

<b>Parameter Name Example</b>	<b>SIP_TIMER_T2_1, SIP_TIMER_T2_2, ..., SIP_TIMER_T2_6</b>
<b>Value Format</b>	Integer

<b>Description</b>	Specifies the maximum interval, in seconds, between transmissions of SIP messages. For details, refer to RFC 3261.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• 2</li> <li>• 4</li> <li>• 8</li> <li>• 16</li> <li>• 32</li> </ul>
<b>Default Value</b>	4
<b>Web User Interface Reference</b>	T2 Timer (Page 110)

## SIP\_TIMER\_T4\_n

<b>Parameter Name Example</b>	<code>SIP_TIMER_T4_1, SIP_TIMER_T4_2, ..., SIP_TIMER_T4_6</code>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the maximum period, in seconds, that a message can remain on the network.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• 0</li> <li>• 1</li> <li>• 2</li> <li>• 3</li> <li>• 4</li> <li>• 5</li> </ul>
<b>Default Value</b>	0

## SIP\_FOVR\_NORSP\_n

<b>Parameter Name Example</b>	<code>SIP_FOVR_NORSP_1, SIP_FOVR_NORSP_2, ..., SIP_FOVR_NORSP_6</code>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to perform the fail-over process when the unit detects that the SIP server is not replying to SIP message.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable fail-over)</li> <li>• <b>N</b> (Disable fail-over)</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If set to "Y", the unit will try to use the other SIP servers via the DNS SRV and A records.</li> <li>• If set to "N", the unit will not try to use the other SIP servers.</li> </ul>
<b>Default Value</b>	Y

## 5.7.2 SIP Settings

---

### SIP\_FOVR\_MAX\_n

<b>Parameter Name Example</b>	<code>SIP_FOVR_MAX_1, SIP_FOVR_MAX_2, ..., SIP_FOVR_MAX_6</code>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the maximum number of servers (including the first [normal] server) used in the fail-over process.
<b>Value Range</b>	1–4
<b>Default Value</b>	2

### SIP\_REFRESHED\_n

<b>Parameter Name Example</b>	<code>SIP_REFRESHED_1, SIP_REFRESHED_2, ..., SIP_REFRESHED_6</code>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether to add the refresher parameter for Session Expire in SIP INVITE.
<b>Value Range</b>	0–2 <ul style="list-style-type: none"><li>– 0: Do not add the refresher parameter</li><li>– 1: Add the refresher parameter with the value "UAS"</li><li>– 2: Add the refresher parameter with the value "UAC"</li></ul>
<b>Default Value</b>	0

### SIP\_DNSSRV\_ENA\_n

<b>Parameter Name Example</b>	<code>SIP_DNSSRV_ENA_1, SIP_DNSSRV_ENA_2, ..., SIP_DNSSRV_ENA_6</code>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to request the DNS server to translate domain names into IP addresses using the SRV record.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <code>Y</code> (Enable DNS SRV lookup)</li><li>• <code>N</code> (Disable DNS SRV lookup)</li></ul>
<b>Note</b>	<ul style="list-style-type: none"><li>• If set to "<code>Y</code>", the unit will perform a DNS SRV lookup for a SIP registrar server, SIP proxy server, SIP outbound proxy server, or SIP presence server.</li><li>• If set to "<code>N</code>", the unit will not perform a DNS SRV lookup for a SIP registrar server, SIP proxy server, SIP outbound proxy server, or SIP presence server.</li></ul>
<b>Default Value</b>	<code>Y</code>
<b>Web User Interface Reference</b>	Enable DNS SRV lookup (Page 109)

## SIP\_UDP\_SRV\_PREFIX\_n

<b>Parameter Name Example</b>	<b>SIP_UDP_SRV_PREFIX_1, SIP_UDP_SRV_PREFIX_2, ..., SIP_UDP_SRV_PREFIX_6</b>
<b>Value Format</b>	String
<b>Description</b>	Specifies a prefix to add to the domain name when performing a DNS SRV lookup using UDP.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• This setting is available only when "SIP_DNSSRV_ENA_n" is set to "Y".</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Default Value</b>	_sip._udp.
<b>Web User Interface Reference</b>	SRV lookup Prefix for UDP (Page 109)

## SIP\_TCP\_SRV\_PREFIX\_n

<b>Parameter Name Example</b>	<b>SIP_TCP_SRV_PREFIX_1, SIP_TCP_SRV_PREFIX_2, ..., SIP_TCP_SRV_PREFIX_6</b>
<b>Value Format</b>	String
<b>Description</b>	Specifies a prefix to add to the domain name when performing a DNS SRV lookup using TCP.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• This setting is available only when "SIP_DNSSRV_ENA_n" is set to "Y".</li> </ul>
<b>Value Range</b>	Max. 32 characters
<b>Default Value</b>	_sip._tcp.
<b>Web User Interface Reference</b>	SRV lookup Prefix for TCP (Page 110)

## SIP\_100REL\_ENABLE\_n

<b>Parameter Name Example</b>	<b>SIP_100REL_ENABLE_1, SIP_100REL_ENABLE_2, ..., SIP_100REL_ENABLE_6</b>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to add the option tag 100rel to the "Supported" header of the INVITE message. For details, refer to RFC 3262.

## 5.7.2 SIP Settings

<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable 100rel function)</li> <li>• <b>N</b> (Disable 100rel function)</li> </ul>
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If set to "<b>Y</b>", the Reliability of Provisional Responses function will be enabled. The option tag 100rel will be added to the "Supported" header of the INVITE message and to the "Require" header of the "1xx" provisional message.</li> <li>• If set to "<b>N</b>", the option tag 100rel will not be used.</li> </ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	Supports 100rel (RFC 3262) (Page 112)

## SIP\_INVITE\_EXPIRE\_n

<b>Parameter Name Example</b>	<b>SIP_INVITE_EXPIRE_1, SIP_INVITE_EXPIRE_2, ..., SIP_INVITE_EXPIRE_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the period, in seconds, in which the INVITE message will expire.
<b>Value Range</b>	0, 60–65535 (0: Disable)
<b>Default Value</b>	0

## SIP\_18X\_RTX\_INTVL\_n

<b>Parameter Name Example</b>	<b>SIP_18X_RTX_INTVL_1, SIP_18X_RTX_INTVL_2, ..., SIP_18X_RTX_INTVL_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the retransmission interval, in seconds, for "18x" responses.
<b>Value Range</b>	0, 1–600 (0: Disable)
<b>Default Value</b>	0

## SIP\_PRSNC\_ADDR\_n

<b>Parameter Name Example</b>	<b>SIP_PRSNC_ADDR_1, SIP_PRSNC_ADDR_2, ..., SIP_PRSNC_ADDR_6</b>
<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address or FQDN of the SIP presence server.
<b>Value Range</b>	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Presence Server Address (Page 107)

## SIP\_PRSNC\_PORT\_n

<b>Parameter Name Example</b>	<b>SIP_PRSNC_PORT_1, SIP_PRSNC_PORT_2, ..., SIP_PRSNC_PORT_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number to use for communication with the SIP presence server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060
<b>Web User Interface Reference</b>	Presence Server Port (Page 107)

## SIP\_2NDPRSNC\_ADDR\_n

<b>Parameter Name Example</b>	<b>SIP_2NDPRSNC_ADDR_1, SIP_2NDPRSNC_ADDR_2, ..., SIP_2NDPRSNC_ADDR_6</b>
<b>Value Format</b>	String
<b>Description</b>	Specifies the IP address of the secondary presence server.
<b>Note</b>	<ul style="list-style-type: none"> <li>This setting is available only when "SIP_PRSNC_ADDR_n" is specified in IP address notation.</li> </ul>
<b>Value Range</b>	IP address in dotted-decimal notation
<b>Default Value</b>	Empty string

## SIP\_2NDPRSNC\_PORT\_n

<b>Parameter Name Example</b>	<b>SIP_2NDPRSNC_PORT_1, SIP_2NDPRSNC_PORT_2, ..., SIP_2NDPRSNC_PORT_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number to use for communication with the secondary SIP presence server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060

## USE\_DEL\_REG\_OPEN\_n

<b>Parameter Name Example</b>	<b>USE_DEL_REG_OPEN_1, USE_DEL_REG_OPEN_2, ..., USE_DEL_REG_OPEN_6</b>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable cancelation before registration when, for example, the unit is turned on.

### 5.7.2 SIP Settings

---

<b>Value Range</b>	<ul style="list-style-type: none"> <li>Y (Enable cancelation before registration)</li> <li>N (Disable cancelation before registration)</li> </ul>
<b>Default Value</b>	N

## USE\_DEL\_REG\_CLOSE\_n

<b>Parameter Name Example</b>	USE_DEL_REG_CLOSE_1, USE_DEL_REG_CLOSE_2, ..., USE_DEL_REG_CLOSE_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable the cancelation of registration before the SIP function shuts down when, for example, the configuration has changed.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Y (Enable registration cancelation before shutting down)</li> <li>N (Disable registration cancelation before shutting down)</li> </ul>
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>If set to "Y", registration cancelation is enabled.</li> <li>If set to "N", registration cancelation is disabled even when the SIP stack is shutting down.</li> </ul>
<b>Default Value</b>	N

## PORT\_PUNCH\_INTVL\_n

<b>Parameter Name Example</b>	PORT_PUNCH_INTVL_1, PORT_PUNCH_INTVL_2, ..., PORT_PUNCH_INTVL_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in seconds, between transmissions of the Keep Alive packet to the unit in order to maintain the NAT binding information.
	<p><b>Note</b></p> <ul style="list-style-type: none"> <li>This setting is available only when "SIP_TRANSPORT_n" is set to "0" for UDP.</li> </ul>
<b>Value Range</b>	0, 10–300 (0: Disable)
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	Keep Alive Interval (Page 113)

## SIP\_ADD\_RPORT\_n

<b>Parameter Name Example</b>	SIP_ADD_RPORT_1, SIP_ADD_RPORT_2, ..., SIP_ADD_RPORT_6
<b>Value Format</b>	Boolean
<b>Description</b>	Selects whether to add the 'rport' parameter to the top Via header field value of requests generated. For details, refer to RFC 3581.

<b>Value Range</b>	<ul style="list-style-type: none"> <li>Y (Add Rport [RFC 3581])</li> <li>N (Do not add Rport [RFC 3581])</li> </ul>
<b>Default Value</b>	N
<b>Web User Interface Reference</b>	Supports Rport (RFC 3581) (Page 113)

## SIP\_REQURI\_PORT\_n

<b>Parameter Name Example</b>	<code>SIP_REQURI_PORT_1, SIP_REQURI_PORT_2, ..., SIP_REQURI_PORT_6</code>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to add the port parameter to the Request-Line in the initial SIP request.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>Y (Add the port parameter)</li> <li>N (Do not add the port parameter)</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>Request URI in REGISTER example: <ul style="list-style-type: none"> <li>If set to "Y", the port parameter is added to the Request-Line, as follows: Request-Line: REGISTER sip:192.168.0.10:5060 SIP/2.0</li> <li>If set to "N", the port parameter is not added to the Request-Line, as follows: Request-Line: REGISTER sip:192.168.0.10 SIP/2.0</li> </ul> </li> </ul>
<b>Default Value</b>	Y

## SIP\_SUBS\_EXPIRE\_n

<b>Parameter Name Example</b>	<code>SIP_SUBS_EXPIRE_1, SIP_SUBS_EXPIRE_2, ..., SIP_SUBS_EXPIRE_6</code>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the length of time, in seconds, that the subscription remains valid. This value is set in the "Expires" header of the SUBSCRIBE request.
<b>Value Range</b>	1–4294967295
<b>Default Value</b>	3600

## SUB\_RTX\_INTVL\_n

<b>Parameter Name Example</b>	<code>SUB_RTX_INTVL_1, SUB_RTX_INTVL_2, ..., SUB_RTX_INTVL_6</code>
<b>Value Format</b>	Integer

### 5.7.2 SIP Settings

---

<b>Description</b>	Specifies the interval, in seconds, between transmissions of SUBSCRIBE requests when a subscription results in failure (server no reply or error reply).
<b>Value Range</b>	10–86400
<b>Default Value</b>	10

## REG\_RTX\_INTVL\_n

---

<b>Parameter Name Example</b>	REG_RTX_INTVL_1, REG_RTX_INTVL_2, ..., REG_RTX_INTVL_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the interval, in seconds, between transmissions of the REGISTER request when a registration results in failure (server no reply or error reply).
<b>Value Range</b>	10–86400
<b>Default Value</b>	10

## SIP\_P\_PREFERRED\_ID\_n

---

<b>Parameter Name Example</b>	SIP_P_PREFERRED_ID_1, SIP_P_PREFERRED_ID_2, ..., SIP_P_PREFERRED_ID_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to add the "P-Preferred-Identity" header to SIP messages.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Add the "P-Preferred-Identity" header)</li><li>• <b>N</b> (Do not add the "P-Preferred-Identity" header)</li></ul>
<b>Default Value</b>	<b>N</b>

## SIP\_PRIVACY\_n

---

<b>Parameter Name Example</b>	SIP_PRIVACY_1, SIP_PRIVACY_2, ..., SIP_PRIVACY_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to add the "Privacy" header to SIP messages.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Add the "Privacy" header)</li><li>• <b>N</b> (Do not add the "Privacy" header)</li></ul>
<b>Default Value</b>	<b>N</b>

## ADD\_USER\_PHONE\_n

<b>Parameter Name Example</b>	<code>ADD_USER_PHONE_1, ADD_USER_PHONE_2, ..., ADD_USER_PHONE_6</code>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to add "user=phone" to the SIP URI in SIP messages.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Add "user=phone")</li> <li>• <b>N</b> (Do not add "user=phone")</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• SIP URI example:             <ul style="list-style-type: none"> <li>– "<code>sip:1111@tokyo.example.com;user=phone</code>", when set to "Y"</li> <li>– "<code>sip:1111@tokyo.example.com</code>", when set to "N"</li> </ul> </li> </ul>
<b>Default Value</b>	<b>N</b>

## SDP\_USER\_ID\_n

<b>Parameter Name Example</b>	<code>SDP_USER_ID_1, SDP_USER_ID_2, ..., SDP_USER_ID_6</code>
<b>Value Format</b>	String
<b>Description</b>	Specifies the user ID used in the "o=" line field of SDP.
<b>Value Range</b>	Max. 32 characters (except ", &, ', :, <, >, and space)
<b>Default Value</b>	-

## SUB\_INTERVAL\_RATE\_n

<b>Parameter Name Example</b>	<code>SUB_INTERVAL_RATE_1, SUB_INTERVAL_RATE_2, ..., SUB_INTERVAL_RATE_6</code>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the percentage of the "expires" value after which to refresh subscriptions by sending a new SUBSCRIBE message in the same dialog.
<b>Value Range</b>	1-100
<b>Default Value</b>	90

## SIP\_OUTPROXY\_ADDR\_n

<b>Parameter Name Example</b>	<code>SIP_OUTPROXY_ADDR_1, SIP_OUTPROXY_ADDR_2, ..., SIP_OUTPROXY_ADDR_6</code>
<b>Value Format</b>	String

### 5.7.2 SIP Settings

---

<b>Description</b>	Specifies the IP address or FQDN of the SIP outbound proxy server.
<b>Value Range</b>	Max. 127 characters (IP address in dotted-decimal notation or FQDN)
<b>Default Value</b>	Empty string
<b>Web User Interface Reference</b>	Outbound Proxy Server Address (Page 107)

## SIP\_OUTPROXY\_PORT\_n

<b>Parameter Name Example</b>	<b>SIP_OUTPROXY_PORT_1, SIP_OUTPROXY_PORT_2, ..., SIP_OUTPROXY_PORT_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the port number to use for communication with the SIP outbound proxy server.
<b>Value Range</b>	1–65535
<b>Default Value</b>	5060
<b>Web User Interface Reference</b>	Outbound Proxy Server Port (Page 107)

## SIP\_TRANSPORT\_n

<b>Parameter Name Example</b>	<b>SIP_TRANSPORT_1, SIP_TRANSPORT_2, ..., SIP_TRANSPORT_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies which transport layer protocol to use for sending SIP packets.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• 0 (UDP)</li><li>• 1 (TCP)</li></ul>
<b>Default Value</b>	0
<b>Web User Interface Reference</b>	Transport Protocol (Page 110)

## SIP\_ANM\_DISPNAME\_n

<b>Parameter Name Example</b>	<b>SIP_ANM_DISPNAME_1, SIP_ANM_DISPNAME_2, ..., SIP_ANM_DISPNAME_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the text string to set as the display name in the "From" header when making anonymous calls.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• 0 (Use normal display name)</li><li>• 1 (Use "Anonymous" for display name)</li><li>• 2 (Do not send a display name)</li></ul>
<b>Default Value</b>	1

## SIP\_ANM\_USERNAME\_n

<b>Parameter Name Example</b>	<b>SIP_ANM_USERNAME_1, SIP_ANM_USERNAME_2, ..., SIP_ANM_USERNAME_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the text string to set as the user name in the "From" header when making anonymous calls.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• 0 (Use normal user name)</li> <li>• 1 (Use "anonymous" for user name)</li> <li>• 2 (Do not send a user name)</li> </ul>
<b>Default Value</b>	0

## SIP\_ANM\_HOSTNAME\_n

<b>Parameter Name Example</b>	<b>SIP_ANM_HOSTNAME_1, SIP_ANM_HOSTNAME_2, ..., SIP_ANM_HOSTNAME_6</b>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to set an anonymous host name in the "From" header when making anonymous calls.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Use "anonymous.invalid" for host name)</li> <li>• <b>N</b> (Use normal host name)</li> </ul>
<b>Default Value</b>	<b>N</b>

## SIP\_DETECT\_SSAF\_n

<b>Parameter Name Example</b>	<b>SIP_DETECT_SSAF_1, SIP_DETECT_SSAF_2, ..., SIP_DETECT_SSAF_6</b>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to enable SSAF for the SIP servers (registrar server, proxy server, and presence server).
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>Y</b> (Enable SSAF)</li> <li>• <b>N</b> (Disable SSAF)</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If set to "Y", the unit receives SIP messages only from the source addresses stored in the SIP servers (registrar server, proxy server, and presence server), and not from other addresses. However, if "<b>SIP_OUTPROXY_ADDR_n</b>" in <b>5.7.2 SIP Settings</b> is specified, the unit also receives SIP messages from the source address stored in the SIP outbound proxy server.</li> </ul>
<b>Default Value</b>	<b>N</b>
<b>Web User Interface Reference</b>	Enable SSAF (SIP Source Address Filter) (Page 113)

## 5.7.2 SIP Settings

### SIP\_RCV\_DET\_HEADER\_n

<b>Parameter Name Example</b>	<code>SIP_RCV_DET_HEADER_1, SIP_RCV_DET_HEADER_2, ..., SIP_RCV_DET_HEADER_6</code>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to check the username part of the SIP URI in the "To" header when receiving the INVITE message with an incorrect target SIP URI.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <code>Y</code> (Enable username check)</li><li>• <code>N</code> (Disable username check)</li></ul>
	<b>Note</b> <ul style="list-style-type: none"><li>• If set to "<code>Y</code>", the unit will return an error reply when it receives the INVITE message with an incorrect target SIP URI.</li><li>• If set to "<code>N</code>", the unit will not check the username part of the SIP URI in the "To" header.</li></ul>
<b>Default Value</b>	<code>N</code>

### SIP\_CONTACT\_ON\_ACK\_n

<b>Parameter Name Example</b>	<code>SIP_CONTACT_ON_ACK_1, SIP_CONTACT_ON_ACK_2, ..., SIP_CONTACT_ON_ACK_6</code>
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to add the "Contact" header to SIP ACK message.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <code>Y</code> (Add the "Contact" header)</li><li>• <code>N</code> (Do not add the "Contact" header)</li></ul>
<b>Default Value</b>	<code>N</code>

### SIP\_TIMER\_B\_n

<b>Parameter Name Example</b>	<code>SIP_TIMER_B_1, SIP_TIMER_B_2, ..., SIP_TIMER_B_6</code>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the value of SIP timer B (INVITE transaction timeout timer), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	250–64000
<b>Default Value</b>	32000
<b>Web User Interface Reference</b>	Timer B (Page 111)

### SIP\_TIMER\_D\_n

<b>Parameter Name Example</b>	<code>SIP_TIMER_D_1, SIP_TIMER_D_2, ..., SIP_TIMER_D_6</code>
-------------------------------	---

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the value of SIP timer D (wait time for answer resending), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	0, 250–64000
<b>Default Value</b>	5000
<b>Web User Interface Reference</b>	Timer D (Page 111)

## SIP\_TIMER\_F\_n

<b>Parameter Name Example</b>	<b>SIP_TIMER_F_1, SIP_TIMER_F_2, ..., SIP_TIMER_F_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the value of SIP timer F (non-INVITE transaction timeout timer), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	250–64000
<b>Default Value</b>	32000
<b>Web User Interface Reference</b>	Timer F (Page 111)

## SIP\_TIMER\_H\_n

<b>Parameter Name Example</b>	<b>SIP_TIMER_H_1, SIP_TIMER_H_2, ..., SIP_TIMER_H_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the value of SIP timer H (wait time for ACK reception), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	250–64000
<b>Default Value</b>	32000
<b>Web User Interface Reference</b>	Timer H (Page 111)

## SIP\_TIMER\_J\_n

<b>Parameter Name Example</b>	<b>SIP_TIMER_J_1, SIP_TIMER_J_2, ..., SIP_TIMER_J_6</b>
<b>Value Format</b>	Integer
<b>Description</b>	Specifies the value of SIP timer J (wait time for non-INVITE request resending), in milliseconds. For details, refer to RFC 3261.
<b>Value Range</b>	0, 250–64000
<b>Default Value</b>	5000
<b>Web User Interface Reference</b>	Timer J (Page 112)

## 5.7.2 SIP Settings

---

### ADD\_TRANSPORT\_UDP\_n

<b>Parameter Name Example</b>	ADD_TRANSPORT_UDP_1, ADD_TRANSPORT_UDP_2, ..., ADD_TRANSPORT_UDP_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to add the attribute "transport=udp" to the SIP header URI.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Add Transport UDP)</li><li>• <b>N</b> (Do not add Transport UDP)</li></ul>
<b>Default Value</b>	<b>N</b>

### ADD\_EXPIRES\_HEADER\_n

<b>Parameter Name Example</b>	ADD_EXPIRES_HEADER_1, ADD_EXPIRES_HEADER_2, ..., ADD_EXPIRES_HEADER_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to add an "Expires" header to REGISTER (adds an "expires" parameter to the "Contact" header).
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Add Expires Header)</li><li>• <b>N</b> (Do not add Expires Header)</li></ul>
<b>Default Value</b>	<b>Y</b>

### SIP\_HOLD\_HOLDRECEIVE\_n

<b>Parameter Name Example</b>	SIP_HOLD_HOLDRECEIVE_1, SIP_HOLD_HOLDRECEIVE_2, ..., SIP_HOLD_HOLDRECEIVE_6
<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether to allow re-INVITE for calls on hold.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Enable SIP Hold Receive)</li><li>• <b>N</b> (Disable SIP Hold Receive)</li></ul>
<b>Default Value</b>	<b>Y</b>

### SIP\_ADD\_DIVERSION\_n

<b>Parameter Name Example</b>	SIP_ADD_DIVERSION_1, SIP_ADD_DIVERSION_2, ..., SIP_ADD_DIVERSION_6
<b>Value Format</b>	Integer
<b>Description</b>	Specifies whether to add Diversion header information.

<b>Value Range</b>	0–2 – 0: Do not add Diversion header information – 1: Use own diversion information only for the Diversion header – 2: Add diversion information to existing Diversion header
<b>Default Value</b>	1

## SIP\_RESPONSE\_CODE\_DND

<b>Value Format</b>	Integer
<b>Description</b>	Selects the response code when a call is received in Do Not Disturb mode.
<b>Value Range</b>	400–699
<b>Default Value</b>	403

## SIP\_RESPONSE\_CODE\_CALL\_REJECT

<b>Value Format</b>	Integer
<b>Description</b>	Selects the response code when a call is rejected.
<b>Value Range</b>	400–699
<b>Default Value</b>	603

## SIP\_FOVR\_MODE\_n

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether INVITE/SUBSCRIBE will also follow the REGISTER Failover result.
<b>Value Range</b>	<ul style="list-style-type: none"> <li>• <b>y</b> (INVITE/SUBSCRIBE will follow the REGISTER Failover result.)</li> <li>• <b>n</b> (INVITE/SUBSCRIBE will not follow the REGISTER Failover result.)</li> </ul>
<b>Default Value</b>	<b>n</b>

## SIP\_FOVR\_DURATION\_n

<b>Value Format</b>	Integer
<b>Description</b>	Specifies the number of transmission times for the REGISTER method at the Failover destination.
<b>Value Range</b>	0–10
<b>Default Value</b>	0

## 5.7.2 SIP Settings

---

### SIP\_ADD\_ROUTE\_n

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether or not to add Route headers when setting OutBoundProxy.  <b>Note</b> <ul style="list-style-type: none"><li>• Route headers are not added when OutBoundProxy and other server settings are the same.</li></ul>
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Route headers are added)</li><li>• <b>N</b> (Route headers are not added)</li></ul>
<b>Default Value</b>	<b>Y</b>

### SIP\_403\_REG\_SUB\_RTX\_n

<b>Value Format</b>	Boolean
<b>Description</b>	Specifies whether or not to send a request when a 403 Forbidden reply is received from the server in response to an INVITE or SUBSCRIBE.
<b>Value Range</b>	<ul style="list-style-type: none"><li>• <b>Y</b> (Send)</li><li>• <b>N</b> (Do not send)</li></ul>
<b>Default Value</b>	<b>N</b>

---

## **Section 6**

### ***Useful Telephone Functions***

*This section explains phone number settings, dial plan, and phonebook import/export function.*

## 6.1 Phonebook Import and Export

This section explains how to import and export phonebook data. Phonebook data of the unit includes names and phone numbers.


Phonebook data on the unit can be exported, edited with editor tools, and imported again. In addition, phonebook data created with other software can be imported into the unit.

You can use the phonebook import and export functions as follows.

### Editing Phonebook Data on a PC

The phonebook data stored on the unit can be edited using a program such as Microsoft Excel® spreadsheet software. For details about the operation, see [6.1.2 Editing with Microsoft Excel](#).

You can export the phonebook data to the PC, edit the exported file using appropriate software, and then import it into the unit.




### Importing Address Book Data from a PC

You can import address book data stored in programs, such as Microsoft Outlook® messaging and collaboration client, into the unit.


First, export address book data from the e-mail software to a program such as Microsoft Excel, edit it as necessary, and then import the exported data into the unit.

For details about the operation, see [6.1.3 Exporting Data from Microsoft Outlook](#).




### Backing up Phonebook Data

You can export the phonebook data from the unit to a PC and keep the file as a backup in case of data loss or for use when exchanging the unit.




### Importing the Same Phonebook Data to other Units

You can export the phonebook data created on a unit to a PC, and then import it into other units.



You can also import phonebook data created on a PC to other units.



### Import/Export File Format

The file format used for importing and exporting the phonebook data is "TSV". When importing or exporting using Microsoft Excel, "CSV (Comma-separated Value)" is generally used as the file format.

A phonebook entry in the unit has 9 fields. An entry in the phonebook data is represented in text as "record ID <TAB> name <TAB> nickname <TAB> phone number <TAB> ringtones <line break>".

The text data can be edited using any text editing software that supports UTF-16 encoding with a BOM and little endian byte ordering. When you save the text file, it must be saved using the same format, or the text might become garbled.

## 6.1.1 Import/Export Operation

### Phonebook Data in Text Format

①	②	③	④	⑤	⑥	⑦	⑧	⑨	⑩	⑪	⑫	⑬	⑭	⑮	⑯	⑰
1		Aaron MacDowell			501		1234001									3
2		Barbara Nicolls			502		1234002									3
3		Carl O'Brien			503		1234003									3
4		Dorothy Parker					1234004									5
...		...			...		...			...		...		...		...
...		...			...		...			...		...		...		...

- ① Record ID (Unique ID: 1–65535)
- ② Tab
- ③ Name (up to 24 characters)
- ④ Tab
- ⑤ Nick name (up to 24 characters)
- ⑥ Tab
- ⑦ Phone number (up to 32 digits)
- ⑧ Tab
- ⑨ Phone number (up to 32 digits)
- ⑩ Tab
- ⑪ Phone number (up to 32 digits)
- ⑫ Tab
- ⑬ Phone number (up to 32 digits)
- ⑭ Tab
- ⑮ Phone number (up to 32 digits)
- ⑯ Tab
- ⑰ Ringtone (1–32)

## 6.1.1 Import/Export Operation

The following procedures explain how to import phonebook data to units, and how to export phonebook data from units to a PC through the Web user interface.

For details about the settings, see [4.6.6 Import Phonebook](#) or [4.6.7 Export Phonebook](#).

### To import phonebook data

1. Click the [Telephone] tab, and then click [**Import Phonebook**].
2. In [**File Name**], enter the full path to the file that you want to import, or click **Browse** to select the phonebook data file that you want to import.
3. Click [**Import**].

### To export the phonebook data

1. Click the [Telephone] tab, and then click [**Export Phonebook**].
2. Click [**Export**].

3. On the "Now Processing File Data" screen, click the text "HERE" in the displayed message, or wait until **File Download** window appears.

**Note**

- Depending on the security settings of your Web browser, pop-up menus might be blocked. If the file cannot be exported successfully, try the export operation again or change the security settings of your Web browser.

4. Click **Save on File Download** window.
5. On the **Save As** window, select a folder to save the exported phonebook data to, enter the file name in **File name**, select **TSV File** for **Save as type**, and click **Save**.  
If the file is downloaded successfully, the **Download complete** window appears.
6. Click **Close**.
7. To exit the operation, click the text "HERE" in the displayed message.  
The [**Export Phonebook**] screen returns.

**Note**

- Make sure that the import source or unit is in standby mode.
- The import source or unit must be specified at the time of import/export. The imported data is added to the existing phonebook data.
  - If the existing phonebook data has an entry with the same record ID as an imported entry, the entry is overwritten with the imported entry.
  - If the existing phonebook data has an entry with no record ID, it will be left in the phonebook.
  - If the imported phonebook data has an entry with no record ID, the imported entry is added as a new entry unless an existing entry with the same name and phone number is found.
- Phonebook entries that are added via the unit are not assigned record IDs. Therefore, it is recommended to export phonebook data from the unit, assign record IDs manually and then re-import them. Doing so can help manage phonebook data.
- The phonebook for a unit has the following limitations:
  - A maximum of 100 (for the KX-UT113)/500 (for the KX-UT123/KX-UT133/KX-UT136/KX-UT248) phonebook entries can be stored in the unit. If the unit already has phonebook data, it accepts up to the 500th entry, including the existing entries. The rest of the entries will not be imported, and the message "Memory Full" is displayed on the unit.
  - The name can contain up to 24 characters.
  - The phone number can contain up to 32 digits.
  - Phonebook entries exceeding the characters or digits limits cannot be imported properly.
- If the export is interrupted by an operation on the unit, only the data that has been successfully exported before the interruption is exported to a file.

## 6.1.2 Editing with Microsoft Excel

You can edit exported phonebook data on a PC with software such as Microsoft Excel. You can then import the phonebook data into units.

### To open the phonebook data on a PC


1. Open Microsoft Excel.
2. Click **Office Button**, and then **Open**.

**Note**


- Make sure to open a TSV file in this procedure. If you change the extension of a TSV file to ".csv", the file will open by simply double-clicking it. However, the character encoding of the file might not be recognized properly, resulting in garbled characters, or the phone numbers might be recognized as numbers, resulting in data alteration.

## 6.1.2 Editing with Microsoft Excel

3. Select **All Files** for the file type, select the exported phonebook data file, and click **Open**.




4. On the **Text Import Wizard - Step 1 of 3** window, click **Next**.




### Note

- Regardless of what is selected for **File origin**, the file will be processed normally if the format is appropriate.

5. On the **Text Import Wizard - Step 2 of 3** window, select **Tab** for **Delimiters**, and then click **Next**.



6. On the **Text Import Wizard - Step 3 of 3** window, select all columns in **Data preview**, select **Text** in **Column data format**, and then click **Finish**.  
The TSV file will be opened.



#### **Note**

- Phone numbers must be treated as text strings. Otherwise, a "0" at the beginning of a phone number might disappear when exported.

#### **To save the phonebook data for importing to the unit**

1. After editing the phonebook entries, click **Office Button**, and then **Save As**.
2. Enter a file name in **File name**, and select **Unicode Text** in **Save as type**.  
The file will be saved in UTF-16 little endian with a BOM. Fields will be separated by tabs.
3. Click **Save**.  
A message warning you about file compatibility will be displayed.
4. Click **Yes**.  
The file will be saved as a Unicode text file, with the fields separated by tabs.

#### **Note**

- The procedure may vary depending on the software version of Microsoft Excel. Therefore, files exported and imported between the unit and Microsoft Excel are not always compatible with each other.

## **6.1.3 Exporting Data from Microsoft Outlook**

You can export address book data stored in programs such as Microsoft Outlook, and then edit the exported data with a program such as Microsoft Excel in order to import it to the unit.

#### **To export the Microsoft Outlook address book data**

1. In Microsoft Outlook, click **File**, and then click **Import and Export**.
2. Select **Export to a file**, and click **Next**.
3. Select **Tab Separated Values (Windows)**, and click **Next**.
4. Select **Contacts**, and click **Next**.
5. Click **Browse**, select a folder, and then enter the file name to export the data to.
6. Click **OK**.
7. On the **Export to a File** window, click **Next**.
8. Click **Map Custom Fields**.
9. Clear all items in the **To** list by clicking **Clear Map**. Then, drag only **Last Name** and **Business Phone** from the **From** list to the **To** list, and click **OK**.

**10.** On the **Export to a File** window, click **Finish**.

The data will be exported.

**Note**

- You can export data from Microsoft Outlook Express by using a similar procedure. It is also possible to export data from other applications that are compatible with Microsoft Excel.
- You can open the exported file in Microsoft Excel, and then import it to the unit. For details, see **6.1.2 Editing with Microsoft Excel**.
- First and middle names are not exported using this procedure. You can export all necessary items and edit the entry before importing them to the unit.
- In the file exported from Microsoft Outlook, fields are separated by tabs and encoded using the default character encoding for your operating system.


## 6.2 Dial Plan

---

The dial plan settings control how numbers dialed by the user are transmitted over the network. Dial plan settings can be configured on a per-line basis. These settings can be programmed either through the Web user interface (→ see **4.6.2.2 Dial Plan**) or by configuration file programming (→ see **5.7.1 Call Control Settings**).

### [Dial Plan Flowchart]

When a user dials a single digit on a unit, the following sequence of events begins.



## 6.2.1 Dial Plan Settings

### To set Dial Plan

1. In the Web user interface, click the **[Telephone]** tab, and then click **[Call Control [Line 1]–[Line x]]**.
2. In **[Dial Plan]**, enter the desired dial format.  
The dial plan settings can be configured for each line separately.

## 6.2.1 Dial Plan Settings

---

For details about available characters for the dial format, see **Available Values for the Dial Plan Field** in this section.

3. Select **[Yes]** or **[No]** for **[Call Even If Dial Plan Does Not Match]**.

- If you select **[Yes]**, the call will be made even if the user dials a phone number that does not match the dial format in **[Dial Plan]**.
- If you select **[No]**, the call will be made only if the user dials a phone number that matches the dial format in **[Dial Plan]**.

**Note**

- For details about configuring these settings by configuration file programming, see "**DIAL\_PLAN\_n**" and "**DIAL\_PLAN\_NOT\_MATCH\_ENABLE\_n**" in **5.7.1 Call Control Settings**.

## Available Values for the Dial Plan Field

---

The following table explains which characters you can use in the dial format, and what the characters mean.

Element	Available Value	Description
String	0–9, [ , - , ] , < , : , > , * , # , ! , S , s , T , t , X , x , . ,   , +	You can enter dial plan descriptions using a combination of the characters listed as available values.
Digit	0–9, *, #, +	<b>Example:</b> "123" If the dialed phone number is "123", the call is made immediately.
Wildcard	X, x	<b>Example:</b> "12xxxxx" If the dialed phone number is "12" followed by any 5-digit number, the call is made immediately.
Range	[]	<b>Example:</b> "[123]" If the dialed phone number is either one of "1", "2", or "3", the call is made immediately.
Subrange	-	<b>Example:</b> "[1-5]" If the dialed phone number is "1", "2", "3", "4", or "5", the call is made immediately. <ul style="list-style-type: none"><li>• A subrange is only valid for single-digit numbers. For example, "[4-9]" is valid, but "[12-21]" is invalid.</li></ul>
Repeat	.	<b>Example:</b> "1." If the dialed phone number is "1" followed by zero or more "1"s (e.g., "11", "111"), the call is made.
Substitution	<(before):(after)>	<b>Example:</b> "<101:9999>" If the dialed phone number is "101", "101" is replaced by "9999", and then the call is made immediately.
Timer	S, s (second)	<b>Example:</b> "1x.S2" If the dialed phone number begins with "1", the call is made after a lapse of 2 seconds. <ul style="list-style-type: none"><li>• The number (0–9) followed by "S" or "s" shows the duration in seconds until the call is made.</li></ul>

Element	Available Value	Description
Macro Timer	T, t	<b>Example: "1x.T"</b> If the dialed phone number begins with "1", the call is made after a lapse of "T" seconds. <ul style="list-style-type: none"> <li>The value of "T" or "t" can be configured through the Web user interface (→ see [Timer for Dial Plan] in <b>4.6.1.1 Call Control</b>).</li> </ul>
Reject	!	<b>Example: "123xxx!"</b> If the dialed phone number is "123" followed by 3 digits, the call is not made.
Alternation		<b>Example: "1xxxx 2xxx"</b> If the dialed phone number is "1" followed by 4 digits, or "2" followed by 3 digits, the call is made immediately. You can use this element to specify multiple numbers.

**Note**

- You can enter up to 1000 characters in **[Dial Plan]**.
- You can assign up to 100 dial plans separated by "|" in **[Dial Plan]**.
- You can assign up to 32 digits per dial plan in **[Dial Plan]**.
- You can assign up to 10 substitutions in **[Dial Plan]**.
- After the user completes dialing, the unit immediately sends all the dialed digits if **[Call Even If Dial Plan Does Not Match]** is set to **[Yes]** in the Web user interface or if "**DIAL\_PLAN\_NOT\_MATCH\_ENABLE\_n**" is set to "N" in a configuration file. The unit recognizes the end of dialing as follows:
  - The inter-digit timer expires (→ see **[Inter-digit Timeout]** in **4.6.1.1 Call Control** in the Web user interface or "**INTDIGIT\_TIM**" in **5.5.1 Call Control Settings** in the configuration file).
  - The user presses **[ENTER]** or the # key.
  - The call is initiated after going off-hook (pre-dial).

## Dial Plan Example

The following example shows dial plans containing character sequences separated by "|".

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxxxx"

**Complete Match:**

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxxxx"

- If the dialed phone number is "211", "911" and so on, the call is made immediately.

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxxxx"

- If the dialed phone number is "2123456789", "5987654321" and so on, the call is made immediately.

**Partial Match (when the dial plan contains "."):**

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxxxx"

- If the dialed phone number is "01254", "012556" and so on, the call is made after the inter-digit timer expires.

**Partial Match (when the dial plan does not contain "."):**

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxxxx"

- If the dialed phone number is "21", "91" and so on when **[Call Even If Dial Plan Does Not Match]** is set to **[Yes]**, the call is made after the inter-digit timer expires.

### 6.3 Flexible Buttons (KX-UT133/KX-UT136/KX-UT248 only)

- If the dialed phone number is "21", "91" and so on when [Call Even If Dial Plan Does Not Match] is set to [No], the call is denied after the inter-digit timer expires.

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxx"

- If the dialed phone number is "21234567", "598765432" and so on when [Call Even If Dial Plan Does Not Match] is set to [Yes], the call is made after the inter-digit timer expires.
- If the dialed phone number is "21234567", "598765432" and so on when [Call Even If Dial Plan Does Not Match] is set to [No], the call is denied after the inter-digit timer expires.

#### No Match:

Example: "[2346789]11|01[2-9]x.|[2-9]xxxxxxxx"

- If the dialed phone number is "0011", "1011" and so on when [Call Even If Dial Plan Does Not Match] is set to [Yes], the call is made after the inter-digit timer expires.
- If the dialed phone number is "0011", "1011" and so on when [Call Even If Dial Plan Does Not Match] is set to [No], the call is denied.

## 6.3 Flexible Buttons (KX-UT133/KX-UT136/ KX-UT248 only)

You can customize the flexible buttons on the unit. They can then be used to make or receive outside calls or as feature buttons. These settings can be programmed either through the Web user interface (→ see

**4.6.3 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only)** or by configuration file programming (→ see **5.5.5 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only)**).

#### Note

- This feature may not be supported on your phone system.

The following types of flexible buttons are available:

Button	Description	Lamp Indication
DN	Used to seize the line assigned to the DN (Directory Number) button. When a call arrives at the DN button, pressing the button answers the call.  <b>Notice</b> <ul style="list-style-type: none"><li>• At least 2 DN buttons must be assigned to each line. If DN buttons are not assigned, calls cannot be made or answered.</li></ul> <b>Note</b> <ul style="list-style-type: none"><li>• The shared line (shared call) feature is an optional feature and may not be supported on your phone system.</li></ul>	<b>Off:</b> Idle <b>Green on:</b> The extension is on a call using the DN button. <b>Flashing green rapidly:</b> The DN extension is receiving an incoming call. <b>Flashing green slowly:</b> A call is on hold at the DN extension. <b>Red on:</b> A shared line is in use or on hold (private). <b>Flashing red slowly:</b> A shared line is on hold (normal).
One-Touch	Used to access a desired party or system feature using the One-Touch Dialing feature.	—
Headset	Used to enable or disable talking using the headset.	<b>Off:</b> Headset off <b>Red on:</b> Headset on

Button	Description	Lamp Indication
BLF	<p>Used to show the current status of another extension, call the extension and transfer calls to it.</p> <p>This button can also be used to perform Directed Call Pickup (→ see [<b>Direct Call Pickup</b>] in <b>4.6.1.1 Call Control</b> in the Web user interface or "<b>NUM_PLAN_PICKUP_DIRECT</b>" in <b>5.5.1 Call Control Settings</b> in the configuration file).</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• BLF (Busy Lamp Field) is an optional feature and may not be supported on your phone system.</li> <li>• It may be necessary to specify the Resource List URI to use this feature, depending on your phone system (→ see [<b>Resource List URI</b>] in <b>4.6.2.1 Call Control</b> in the Web user interface or "<b>RESOURCELIST_URI_n</b>" in <b>5.7.1 Call Control Settings</b> in the configuration file).</li> </ul>	<p><b>Off:</b> The BLF extension is idle.</p> <p><b>Red on:</b> A corresponding BLF extension is using the line.</p> <p><b>Flashing red rapidly:</b> The BLF extension is receiving an incoming call.</p>
ACD	<p>Used to log in or log out of a group when ACD (Automatic Call Distribution) is enabled.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• ACD is an optional feature and may not be supported on your phone system.</li> </ul>	<p><b>Off:</b> Logged in</p> <p><b>Red on:</b> Logged out</p>
Wrap Up	<p>The Wrap Up button alternates the setting of Wrap Up mode, Not Ready mode or Ready mode for incoming calls.</p> <p>In Wrap Up mode/Not Ready mode for incoming calls, incoming calls will not be received through the ACD (Automatic Call Distribution) group.</p>	<p><b>Off:</b> Ready mode for incoming calls</p> <p><b>Red on:</b> Not Ready mode for incoming calls</p> <p><b>Flashing red:</b> Wrap Up mode</p>

## 6.3.1 Flexible Button Settings

### To set Flexible Buttons

1. In the Web user interface, click the [**Telephone**] tab, and then click [**Flexible Button Settings**].
2. Enter settings as described in the following table.  
When it is necessary to set both parameter 1 and parameter 2, enter a comma between the values.

### 6.3.1 Flexible Button Settings

Button	Parameter 1		Parameter 2	
	Description	Value	Description	Value
DN	Ringtone	1–32	Line No.	<ul style="list-style-type: none"> <li>• 1–4 (for KX-UT133/KX-UT136)</li> <li>• 1–6 (for KX-UT248)</li> </ul>
One-Touch	Phone Number	Up to 32 digits	—	—
Headset	—	—	—	—
BLF	Extension Number <sup>1</sup>	Up to 32 digits	—	—
ACD	Line No.	<ul style="list-style-type: none"> <li>• 1–4 (for KX-UT133/KX-UT136)</li> <li>• 1–6 (for KX-UT248)</li> </ul>	—	—
Wrap Up	Line No.	<ul style="list-style-type: none"> <li>• 1–4 (for KX-UT133/KX-UT136)</li> <li>• 1–6 (for KX-UT248)</li> </ul>	—	—

<sup>1</sup> You can also assign extension numbers automatically to BLF buttons using the information in the server's resource list without having to input information here.

#### Note

- For details about configuring these settings by configuration file programming, see **5.5.5 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only)**.

#### [Setting Example]

The following screen shows an example of setting flexible buttons.

Flexible Button Settings			
No.	Type	Parameter	Label Name
1.	ACD	1	ACD1
2.	Headset		Headset
3.	DN	1,1	DN1-1
4.	DN	1,1	DN1-2
5.	DN	2,2	DN2-1
6.	DN	2,2	DN2-2
7.	One-Touch	0123456789	Office
8.	One-Touch	1112223333	Home
9.	BLF	301	301
10.	BLF	302	302
11.	BLF	303	303

#### Description:

- Button 1 is set to log in and log out of an ACD group on line 1.
  - Button 2 is set to enable or disable talking using the headset.
  - Buttons 3 and 4 are set to make/receive calls on line 1 using ringtone 1.
  - Buttons 5 and 6 are set to make/receive calls on line 2 using ringtone 2.
  - Buttons 7 and 8 are set to make calls to a certain destination using the One-Touch Dialing feature.
  - Buttons 9, 10 and 11 are set to show the status of a certain extension. They can also be used to call that extension and transfer calls to it.<sup>1</sup>
- <sup>1</sup> You can also assign extension numbers automatically to BLF buttons using the information in the server's resource list without having to input information here.

### **6.3.1 Flexible Button Settings**

---

---

## **Section 7**

### **Firmware Update**

*This section explains how to update the firmware of the unit.*

## 7.1 Firmware Server Setup

---

No special server is necessary for the firmware update. You can use an HTTP, HTTPS, FTP, or TFTP server as the firmware server by simply setting its URL.

## 7.2 Firmware Update Settings

---

Firmware updates are provided by the manufacturer when necessary.

The firmware update will be executed by setting the corresponding parameters using configuration file programming (→ see **5.3.4 Firmware Update Settings**) or Web user interface programming (→ see **4.7.1 Firmware Maintenance**). The following shows the parameters and the setting procedures:

### Firmware Update Enable/Disable

- In a configuration file, add the line, **FIRM\_UPGRADE\_ENABLE="Y"**.
- In the Web user interface, click the **[Maintenance]** tab, click **[Firmware Maintenance]**, and then select **[Yes]** for **[Enable Firmware Update]**.

### Firmware Version Number

- In a configuration file, specify the new version number in "**FIRM\_VERSION**".

### Automatic Update

- In a configuration file, add the line, **FIRM\_UPGRADE\_AUTO="Y"**.
- In the Web user interface, click the **[Maintenance]** tab, click **[Firmware Maintenance]**, and then select **[Automatic]** for **[Update Type]**.

### Firmware Server URL

- In a configuration file, specify the URL in "**FIRM\_FILE\_PATH**".
- In the Web user interface, click the **[Maintenance]** tab, click **[Firmware Maintenance]**, and then enter the URL in **[Firmware File URL]**.

## Configuration Parameter Example

---

By setting the parameters as shown in the following example, the unit will automatically download the firmware file from the specified URL, "http://firm.example.com/firm/01.050.fw", and perform the update operation if the currently used firmware version is older than 01.050.

### Example

```
FIRM_UPGRADE_ENABLE="Y"  
FIRM_VERSION="01.050"  
FIRM_UPGRADE_AUTO="Y"  
FIRM_FILE_PATH="http://firm.example.com/firm/01.050.fw"
```

## 7.3 Executing Firmware Update

---


After configuring the firmware update settings in the configuration file, the firmware will be updated when the configuration file is downloaded. The firmware update procedure is detailed below.

### The firmware update process

#### Step 1

The unit downloads a configuration file from the provisioning server.


- For details about setting the timing of when configuration files are downloaded, see [2.2.4 Downloading Configuration Files](#).



#### Step 2


The unit compares the version number of the firmware in the configuration file to the unit's current firmware version.

(In this example, the unit is using version 01.000 and the configuration file specifies version 01.050.)




#### Step 3

When a newer firmware version is specified in the configuration file, the unit will download the firmware from the address specified under "`FIRM_FILE_PATH`" in the configuration file.



#### Step 4

Once the newer firmware is downloaded, it is applied to the unit and the unit automatically restarts.



## 7.4 Local Firmware Update

When an updated version of the firmware is provided on a Web site or other means, you can perform the firmware update manually using Web user interface programming.

For details about the local firmware update, see [4.7.2 Local Firmware Update](#).

### To manually update the firmware

- In the Web user interface, click the **[Maintenance]** tab, and then click **[Local Firmware Update]**.
- Click **Browse**, select the folder where the firmware file is stored, and specify the firmware file on your PC.
- Click **[Update Firmware]**.

## **7.4 Local Firmware Update**

---

---

## **Section 8**

### **Troubleshooting**

*This section provides information about troubleshooting.*

## 8.1 Troubleshooting

If you still have difficulties after following the instructions in this section, disconnect the unit from the AC outlet, then connect the AC adaptor again. If using PoE, disconnect the LAN cable, then connect the LAN cable again.

### General Use

Problem	Cause/Solution
I cannot hear a dial tone.	<ul style="list-style-type: none"> <li>• Network settings may not be correct.</li> <li>• Many installation issues can be resolved by resetting all the equipment. First, shut down your modem, router, hub, unit, and PC. Then turn the devices back on, one at a time, in this order: modem, router, hub, unit, PC.</li> <li>• If you cannot access Internet Web pages using your PC, check to see if your phone system is having connection issues in your area.</li> <li>• Check the VoIP status in the Web user interface and confirm that each line is registered properly (→ see <b>To check the setting status in the Web user interface</b> in this section).</li> <li>• Check that the SIP server address, URLs of the configuration files, encryption key, and other required settings are correct.</li> <li>• Check the firewall and port forwarding settings on the router (→ see <b>1.1.7 Other Network Settings</b>).</li> <li>• For details about the settings, consult your network administrator or phone system dealer.</li> </ul>
The unit will not start up correctly.	<ul style="list-style-type: none"> <li>• Web user interface settings or configuration file settings may not be correct. Perform the following procedure to initialize the settings, and then reconfigure the unit correctly.             <ol style="list-style-type: none"> <li>1. Press <b>Setup</b>.</li> <li>2. Press <b>[#][1][3][6]</b>.</li> <li>3. Press <b>[▲] or [▼]</b> to select "IP Reset", and then press <b>[ENTER]</b>.</li> <li>4. Press <b>[▲] or [▼]</b> to select "Yes", and then press <b>[ENTER]</b>.</li> <li>5. Press <b>[▲] or [▼]</b> to select "Yes", and then press <b>[ENTER]</b>.</li> </ol> <p>After performing IP Reset, the unit will restart automatically.</p> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• If settings were not initialized after performing this procedure, consult your phone system dealer.</li> </ul> </li> </ul>

## Making/Answering Calls, Intercom

Problem	Cause/Solution
The unit does not ring.	<ul style="list-style-type: none"> <li>• Check the VoIP status in the Web user interface and confirm that each line is registered properly (→ see <b>To check the setting status in the Web user interface</b> in this section).</li> <li>• Check that the SIP server address, URLs of the configuration files, encryption key, and other required settings are correct.</li> <li>• Check the firewall and port forwarding settings on the router (→ see <b>1.1.7 Other Network Settings</b>).</li> <li>• Check [<b>Call Control</b>] for each line in the [<b>Telephone</b>] tab in the Web user interface. <ul style="list-style-type: none"> <li>– If [<b>Do Not Disturb</b>] is set to [<b>Yes</b>], the unit does not receive calls (→ see <b>4.6.2.3 Call Features</b>).</li> <li>– If [<b>Unconditional (Enable Call Forward)</b>] is set to [<b>Yes</b>], the unit does not receive calls (→ see <b>4.6.2.4 Call Forward</b>).</li> <li>– If [<b>Block Anonymous Call</b>] is set to [<b>Yes</b>], the unit does not receive anonymous calls (→ see <b>4.6.2.3 Call Features</b>).</li> </ul> </li> <li>• Check that [<b>Do Not Disturb</b>], [<b>Enable Call Forward</b>], and [<b>Block Anonymous Call</b>] are not controlled by your phone system.</li> <li>• For details about settings, consult your network administrator or phone system dealer.</li> </ul>
I cannot make a call.	<ul style="list-style-type: none"> <li>• Check the VoIP status in the Web user interface and confirm that each line is registered properly (→ see <b>To check the setting status in the Web user interface</b> in this section).</li> <li>• Check that the SIP server address, URLs of the configuration files, encryption key, and other required settings are correct.</li> <li>• Check the firewall and port forwarding settings on the router (→ see <b>1.1.7 Other Network Settings</b>).</li> <li>• For details about settings, consult your network administrator or phone system dealer.</li> </ul>

## Password for Web User Interface Programming

Problem	Cause/Solution
I have lost the login password of the Web user interface for the Administrator or User account.	<ul style="list-style-type: none"> <li>• Reset the password from the unit. The passwords for both Administrator and User will be reset (→ see <b>3.1.4 Reset Web ID/Password</b>). For security reasons, it is recommended that the passwords are set again immediately (→ see <b>4.4.2 Administrator Password</b> or <b>4.4.3 Change User Password</b>).</li> </ul>

## 8.1 Troubleshooting

---

### Time

Problem	Cause/Solution
The time is not correct.	<ul style="list-style-type: none"><li>In the Web user interface, you can set NTP synchronization and DST (Summer Time) control to adjust the time automatically (→ see <b>4.4.5 Time Adjust Settings</b>).</li><li>If the time is still incorrect even after setting NTP synchronization, check the firewall and port forwarding settings on the router (→ see <b>1.1.7 Other Network Settings</b>).</li></ul>

### Error Codes

---

When a system error occurs, an error code is displayed on the unit.

Error code	Probable Cause	Solution
10001	MAC address error	Consult your network administrator or phone system dealer.
11001–11006	Device error	Consult your network administrator or phone system dealer.
21001	IEEE 802.1X authentication error (KX-UT248 only)	Consult your network administrator or phone system dealer.
90001	<ul style="list-style-type: none"><li>Transmission error</li><li>Unit not registered</li></ul>	<ul style="list-style-type: none"><li>Check network settings.</li><li>Check that settings are correct for registration to the SIP server.</li></ul>

### Checking the Status of the Unit

---

You can check the status of the unit by using Web user interface programming (→ see **4.2.2 Network Status** and **4.2.3 VoIP Status**) or by looking at system logs (→ see **5.3.3 Syslog Settings**) sent from the unit.

#### To check the setting status in the Web user interface

1. Click the **[Status]** tab, and then click **[Network Status]** to check the network settings.
2. Check the status displayed.
3. Click **[VoIP Status]** to check the VoIP settings.
4. Check the status displayed.

#### To send the system logs of specified events to the syslog server

1. Set the following parameters to specify your PC (Windows, Linux® operating system, etc.) as the syslog server:
  - **SYSLOG\_ADDR**: Specifies the IP address or FQDN of the syslog server.
  - **SYSLOG\_PORT**: Specifies the port number of the syslog server.
2. Set the following parameters to log specific events:
  - **SYSLOG\_EVENT\_SIP**: Logs SIP-related syslog events.
  - **SYSLOG\_EVENT\_CFG**: Logs syslog events regarding configuration.

- **SYSLOG\_EVENT\_VOIP**: Logs syslog events regarding VoIP operation.

## **8.1 Troubleshooting**

---

---

## ***Section 9***

## ***Appendix***

## 9.1 Revision History

---

### 9.1.1 KX-UT113/KX-UT123/KX-UT133/KX-UT136 Software File Version 01.025

#### New Contents

---

- 5.7.1 Call Control Settings—VOICE\_MESSAGE\_AVAILABLE (Page 243)
- 5.7.1 Call Control Settings—HOLD\_SOUND\_PATH\_n (Page 243)
- 5.7.2 SIP Settings—SIP\_REQURI\_PORT\_n (Page 257)

#### Changed Contents

---

- 1.2.1.1 Resetting to Factory Default (Factory Setting) (Page 29)
- 1.2.1.2 Resetting the Network Settings (IP Reset) (Page 30)
- 3.1.1 Phone User Interface Feature List and Direct Commands (Page 56)
- 5.5.2 Tone Settings—HOLD\_TONE\_TIMING (Page 217)

## 9.1.2 KX-UT113/KX-UT123/KX-UT133/KX-UT136 Software File Version 01.080

### New Contents

---

- 4.3.7 Application Settings (Page 93)
- 4.5.4.1 Quality of Service (QoS)—RTCP Packet QoS (DSCP) (Page 116)
- 4.5.4.4 DTMF—DTMF Relay (Page 118)
- 4.6.8 Application Settings (Page 142)
- 5.3.6 Management Server Settings
  - ANNEX\_G\_STUN\_ENABLE (Page 187)
  - ANNEX\_G\_STUN\_SERV\_ADDR (Page 187)
  - ANNEX\_G\_STUN\_SERV\_PORT (Page 187)
  - ANNEX\_G\_STUN\_USER\_ID (Page 187)
  - ANNEX\_G\_STUN\_PASS (Page 188)
  - ANNEX\_G\_STUN\_MAX\_KEEP\_ALIVE (Page 188)
  - ANNEX\_G\_STUN\_MIN\_KEEP\_ALIVE (Page 188)
  - UDP\_CON\_REQ\_ADDR\_NOTIFY\_LIMIT (Page 189)
- 5.5.6 XML Application Settings (Page 225)
- 5.6.2 RTP Settings—DSCP\_RTCP\_n (Page 232)
- 5.6.3 Miscellaneous VoIP Settings—DTMF\_RELAY\_n (Page 237)

### Changed Contents

---

- 2.6 Setting Configuration File Parameters Using TR-069 (Page 50)

## 9.1.3 KX-UT113/KX-UT123/KX-UT133/KX-UT136/KX-UT248 Software File Version 01.160

### New Contents

---

- 3.1.5 Sound Quality (KX-UT113/KX-UT123/KX-UT133/KX-UT136 only) (Page 57)
- 4.3.2.2 LLDP Settings (Page 83)
- 5.4.9 LLDP-MED Settings (Page 201)

### Changed Contents

---

- 2.1.3 Server for Pre-provisioning (Page 35)
- 3.1.1 Phone User Interface Feature List and Direct Commands (Page 56)
- 4.3.2 Ethernet Port Settings (Page 81)
- 4.3.2.3 VLAN Settings (Page 84)
- 4.6.3.1 Flexible Button Settings (Page 134)
- 5.3.5 Provisioning Settings (Page 177)
- 5.5.1 Call Control Settings (Page 202)
- 5.5.3 Telephone Settings (Page 219)
- 5.5.4 Miscellaneous Telephone Settings (Page 222)
- 5.5.5 Flexible Button Settings (KX-UT133/KX-UT136/KX-UT248 only) (Page 224)
- 5.5.6 XML Application Settings (Page 225)
- 5.7.2 SIP Settings (Page 243)
- 6.2.1 Dial Plan Settings (Page 275)
- 6.3 Flexible Buttons (KX-UT133/KX-UT136/KX-UT248 only) (Page 278)
- 6.3.1 Flexible Button Settings (Page 279)

---

# ***Index***

**Numerics**

1–30 125

**A**

Access Level 23, 60  
Access Levels (IDs and Passwords) 21, 23  
Accessing the Web User Interface 23  
ACS\_PASS 185  
ACS\_URL 184  
ACS\_USER\_ID 184  
ADD\_EXPIRES\_HEADER\_n 264  
ADD\_TRANSPORT\_UDP\_n 264  
ADD\_USER\_PHONE\_n 259  
ADJDATA\_ATT 223  
ADJDATA\_GAIN 222  
ADMIN\_ID 167  
ADMIN\_PASS 167  
Administrator Password 95  
ANNEX\_G\_STUN\_ENABLE 187  
ANNEX\_G\_STUN\_MAX\_KEEP\_ALIVE 188  
ANNEX\_G\_STUN\_MIN\_KEEP\_ALIVE 188  
ANNEX\_G\_STUN\_PASS 188  
ANNEX\_G\_STUN\_SERV\_ADDR 187  
ANNEX\_G\_STUN\_SERV\_PORT 187  
ANNEX\_G\_STUN\_USER\_ID 187  
Application Authentication 93  
Application Bootup URL 142  
Application initial URL 143  
Application Port 93  
Application Settings 93, 142  
Audience 2  
Authentication ID 87, 88, 93, 108, 144, 151  
Authentication Password 87, 89, 94, 109, 145, 151  
Authentication Protocol 86  
AUTO\_ANS\_RING\_TIM 206  
AUTO\_CALL\_HOLD 207  
Available Values for the Dial Plan Field 276

**B**

Basic Network Settings 18, 77  
Basic Network Setup 18  
Before Accessing the Web User Interface 22  
BELL\_CORE\_PATTERN1\_TIMING 218  
BELL\_CORE\_PATTERN2\_TIMING 218  
BELL\_CORE\_PATTERN3\_TIMING 218  
BELL\_CORE\_PATTERN4\_TIMING 219  
BELL\_CORE\_PATTERN5\_TIMING 219  
Block Anonymous Call 129  
Block Caller ID 129  
Busy (Enable Call Forward) 131  
Busy (Phone Number) 132  
Busy Tone 136  
BUSY\_TONE\_FRQ 212  
BUSY\_TONE\_GAIN 212  
BUSY\_TONE\_RPT 212  
BUSY\_TONE\_TIMING 212

**C**

Call Control 122, 125, 126  
Call Control [Line 1]–[Line x] 125

Call Control Settings 158, 163, 202, 239, 276  
Call Even If Dial Plan Does Not Match 128  
Call Features 129  
Call Forward 127, 130, 131, 132, 241  
Call Hold 119, 238  
Call log URL 144  
Call Rejection Phone Numbers 125  
Cancel Button 25  
CFG\_CYCLIC 182  
CFG\_CYCLIC\_INVL 183  
CFG\_FILE\_KEY\_LENGTH 182  
CFG\_FILE\_KEY1 181  
CFG\_FILE\_KEY2 182  
CFG\_FILE\_KEY3 182  
CFG\_MASTER\_FILE\_PATH 180  
CFG\_PRODUCT\_FILE\_PATH 179  
CFG\_RESYNC\_DURATION 184  
CFG\_RESYNC\_FROM\_SIP 184  
CFG\_RESYNC\_TIME 183  
CFG\_ROOT\_CERTIFICATE\_PATH 198  
CFG\_RTRY\_INVL 183  
CFG\_STANDARD\_FILE\_PATH 178  
Change Administrator Password 95  
Change User Password 96  
Channel 1–25 92  
Characters Available for String Values 166  
Checking the Status of the Unit 290  
CODEC Preferences 119  
Codec Settings 161, 230  
Codec Settings, Examples 48  
CODEC\_ENABLE\_n 231  
CODEC\_G711\_REQ 230  
CODEC\_G729\_PARAM 231  
CODEC\_PRIORITYx\_n 231  
CON\_REQ\_PASS 186  
CON\_REQ\_USER\_ID 186  
Conference Server URI 123  
CONFERENCE\_SERVER\_URI 203  
Configuration File 38, 165  
Configuration File Examples 47  
Configuration File Parameter List 154  
Configuration File Parameters 165  
Configuration File Programming 153  
Configuration File Specifications 46  
Configuration Parameter Example 284  
Configuring the Network Settings of the Unit 19  
Confirm New Password 96, 97  
Connection Mode 74, 78  
CONNECTION\_TYPE 189  
Controls on the Window 24  
Country Calling Code 124  
COUNTRY\_CALLING\_CODE 204  
Current Password 95, 96  
CUSTOM\_WEB\_PAGE 201  
CW\_ENABLE\_n 242  
CW\_TONE1\_FRQ 216  
CW\_TONE1\_GAIN 216  
CW\_TONE1\_RPT 216  
CW\_TONE1\_TIMING 216  
Cyclic Auto Resync 149

**D**

DATA\_LINE\_MODE 205  
 Day of Week 101, 102  
 Daylight Saving Time (Summer Time) 100  
 Default Gateway 74, 80  
 Default Line for Outgoing 124  
 DEFAULT\_LANGUAGE 220  
 DEFAULT\_LINE\_SELECT 204  
 Detection Interval 90  
 Detection Method 90  
 DHCP Server 18, 35, 177  
 DHCP Settings 78  
 DHCP\_DNS\_ENABLE 190  
 Dial Plan 128, 274, 275  
 Dial Plan (max 1000 columns) 128  
 Dial Plan Example 277  
 Dial Plan Settings 275  
 Dial Tone 135  
 DIAL\_PLAN\_n 239  
 DIAL\_PLAN\_NOT\_MATCH\_ENABLE\_n 240  
 DIAL\_TONE1\_FRQ 209  
 DIAL\_TONE1\_GAIN 209  
 DIAL\_TONE1\_RPT 209  
 DIAL\_TONE1\_TIMING 209  
 DIAL\_TONE2\_FRQ 210  
 DIAL\_TONE2\_GAIN 210  
 DIAL\_TONE2\_RPT 210  
 DIAL\_TONE2\_TIMING 210  
 DIAL\_TONE4\_FRQ 211  
 DIAL\_TONE4\_GAIN 211  
 DIAL\_TONE4\_RPT 211  
 DIAL\_TONE4\_TIMING 211  
 Direct Call Pickup 125  
 Direct Commands 56  
 DISCONNECTION\_MODE 207  
 Display Name 126  
 DISPLAY\_DATE\_PATTERN 220  
 DISPLAY\_NAME\_n 239  
 DISPLAY\_NAME\_REPLACE 219  
 DISPLAY\_TIME\_PATTERN 220  
 DNS 109  
 DNS Server 19, 79, 190  
 DNS Server Settings 19  
 DNS Settings 19, 156, 192  
 DNS\_PRIORITY 193  
 DNS\_QRY\_PRLL 192  
 DNS1 75, 80  
 DNS1\_ADDR 193  
 DNS2 75, 81  
 DNS2\_ADDR 193  
 Do Not Disturb 127, 130, 131, 132, 241  
 Domain Name Server 79  
 Downloading a Configuration File via the Web User Interface 40  
 DSCP\_RTCP\_n 232  
 DSCP RTP\_n 232  
 DSCP\_SIP\_n 249  
 DST Offset (Summer Time Offset) 100  
 DST\_ENABLE 169  
 DST\_OFFSET 169  
 DST\_START\_DAY\_OF\_WEEK 170  
 DST\_START\_MONTH 170

DST\_START\_ORDINAL\_DAY 170  
 DST\_START\_TIME 171  
 DST\_STOP\_DAY\_OF\_WEEK 172  
 DST\_STOP\_MONTH 171  
 DST\_STOP\_ORDINAL\_DAY 172  
 DST\_STOP\_TIME 172  
 DTMF 118  
 DTMF Relay 118  
 DTMF Type 118  
 DTMF\_INTDIGIT\_TIM 238  
 DTMF\_RELAY\_n 237  
 DTMF\_SIGNAL\_LEN 238

**E**

Editing with Microsoft Excel 271  
 Embedded web 22  
 Enable Application 93  
 Enable DNS SRV lookup 109  
 Enable DST (Enable Summer Time) 100  
 Enable Firmware Update 145  
 Enable Global IP Address Usage per Line 92  
 Enable IEEE802.1X 86  
 Enable LLDP 83  
 Enable Provisioning 148  
 Enable Proxy 89  
 Enable Shared Call 127  
 Enable SSAF (SIP Source Address Filter) 113  
 Enable Synchronization by NTP 99  
 Enable VLAN 84  
 Encryption 44, 147  
 Encryption Key 44, 181, 182  
 End Day and Time of DST (End Day and Time of Summer Time) 102  
 Entering Characters 25  
 Error Codes 290  
 Ethernet Link Status (LAN Port) 73  
 Ethernet Link Status (PC Port) 73  
 Ethernet Port Settings 81, 157, 194  
 Export Button 270  
 Export Phonebook 141, 270  
 Exporting Data from Microsoft Outlook 273  
 Extension PIN 140  
 EXTENSION\_PIN 221  
 External RTP Port 92

**F**

Factory Defaults 18, 29, 30, 57  
 Factory Setting 29  
 File Name 141, 147  
 Firewall and Router Setup 27  
 FIRM\_FILE\_PATH 176  
 FIRM\_UPGRADE\_AUTO 176  
 FIRM\_UPGRADE\_ENABLE 175  
 FIRM\_VERSION 176  
 Firmware File URL 146  
 Firmware Maintenance 145, 284  
 Firmware Server 31, 284  
 Firmware Update 31, 145, 175, 283, 284  
 Firmware Update Settings 155, 175, 284  
 Firmware Version 72  
 FIRSTDIGIT\_TIM 203

Flash Hook Event 125  
Flash/Recall Button 124  
FLASH\_RECALL\_TERMINATE 242  
FLASHHOOK\_CONTENT\_TYPE 242  
FLEX\_BUTTON\_FACILITY\_ACTx 224  
FLEX\_BUTTON\_FACILITY\_ARGx 224  
FLEX\_BUTTON\_LABELx 225  
FLEX\_BUTTON\_QUICK\_DIALx 224  
Flexible Button Settings 134, 160, 224, 279  
Flexible Buttons 278, 279  
FWD\_DND\_SYNCHRO\_ENABLE\_n 241

**G**

G722 (Enable) 119  
G722 (Priority) 119  
G726–32 (Enable) 120  
G726–32 (Priority) 120  
G729A (Enable) 120  
G729A (Priority) 121  
Global Address Detection 29, 89, 90  
Global IP Address 91

**H**

Header Value for Resync Event 150  
HOLD\_ALARM\_FRQ 215  
HOLD\_ALARM\_GAIN 215  
HOLD\_ALARM\_RPT 215  
HOLD\_ALARM\_TIMING 215  
HOLD\_AND\_CALL\_ENABLE 208  
HOLD\_PACKAGE 206  
HOLD\_RECALL\_TIM 206  
HOLD\_SOUND\_PATH\_n 243  
HOLD\_TONE\_FRQ 217  
HOLD\_TONE\_GAIN 217  
HOLD\_TONE\_RPT 217  
HOLD\_TONE\_TIMING 217  
HOLD\_TRANSFER\_OPERATION 208  
Host Name 78  
HOST\_NAME 190  
HTTP Authentication 88  
HTTP Client Settings 87, 88  
HTTP Settings 157, 197  
HTTP User Agent 88  
HTTP Version 88  
HTTP\_SSL\_VERIFY 198  
HTTP\_USER\_AGENT 197  
HTTP\_VER 197  
HTTPD\_PORTOPEN\_AUTO 197  
HTTPS 44, 45

**I**

Idling URL 144  
IEEE 802.1X Settings 157, 195  
IEEE802.1X Authentication 86  
IEEE802.1X Settings 86  
IEEE802.1X Status 75  
IEEE8021X\_AUTH\_PRTCL 196  
IEEE8021X\_ENABLE 195  
IEEE8021X\_USER\_ID 196  
IEEE8021X\_USER\_PASS 196  
Import Button 270

Import Phonebook 140, 141, 270  
Import/Export File Format 269  
Import/Export Operation 270  
INBANDDTMF\_VOL 237  
Incoming call URL 143  
Incorrect Example 49  
Initial Delay 118  
INTDIGIT\_TIM 203  
Inter-digit Timeout 123  
International Call Prefix 123  
INTERNATIONAL\_ACCESS\_CODE 204  
IP Address 74  
IP Phone 83  
IP Phone (Priority) 83, 85  
IP Phone (VLAN ID) 84  
IP Reset 30  
IP Settings 156, 189  
IPL Version 72

**J**

Jitter Buffer 117

**K**

Keep Alive Interval 113  
Key Click Tone 139  
KEY\_PAD\_TONE 208

**L**

Label Name (No. 1–24) 135  
LAN Port 82  
Language 94  
Language Selection 18, 20, 21, 94  
Language Selection for the Unit 18  
Line 1–Line x 92  
Line No. 76  
Line Settings 163, 239  
LINE\_ENABLE\_n 245  
Link Speed/Duplex Mode 82  
LLDP Settings 83  
LLDP\_ENABLE 201  
LLDP\_INTERVAL 202  
LLDP\_VLAN\_ID\_PC 202  
LLDP\_VLAN\_PRI\_PC 202  
LLDP-MED Interval timer 83  
LLDP-MED Settings 157, 201  
Local Firmware Update 146, 147, 285  
LOCAL\_TIME\_ZONE\_POSIX 173  
Login Account Settings 154, 167

**M**

MAC Address 73  
MACRODIGIT\_TIM 203  
Maintenance 71  
Maintenance Tab 71, 145  
Making call URL 143  
Management Server 150, 151  
Management Server Authentication 151  
Management Server Settings 156, 184  
Management Server URL 151  
Master Configuration File 39, 149, 180

Master File URL 149  
MAX\_DELAY\_n 233  
Maximum Delay 117  
Maximum RTP Port Number 115  
Microsoft Excel 268, 271  
Microsoft Outlook 268, 273  
MIN\_DELAY\_n 233  
Minimum Delay 117  
Minimum RTP Port Number 114  
Miscellaneous Network Settings 157, 201  
Miscellaneous Telephone Settings 160, 222  
Miscellaneous VoIP Settings 162, 236  
Model 72  
Month 101, 102

**N**

NAPT 91  
NAT 28, 91, 113, 256  
NAT Identity 113  
NAT Traversal 28, 92  
National Access Code 124  
NATIONAL\_ACCESS\_CODE 204  
Network 61  
Network Phone Book URL 144  
Network Phone Book URL Authentication 144  
Network Settings 156, 189  
Network Status 73, 290  
Network Tab 61, 77  
New Password 95, 97  
No Answer (Enable Call Forward) 132  
No Answer (Phone Number) 133  
No Answer (Ring Count) 133  
NOM\_DELAY\_n 234  
NOTES 2  
NTP Server Address 100  
NTP\_ADDR 199  
NUM\_PLAN\_PICKUP\_DIRECT 205  
Number Matching Lower Digit 140  
Number Matching Upper Digit 140  
NUMBER\_MATCHING\_LOWER\_DIGIT 219  
NUMBER\_MATCHING\_UPPER\_DIGIT 220  
NW\_SETTING\_ENABLE 201

**O**

ONHOOK\_TRANSFER\_ENABLE 207  
Open Source Software Notice 2  
Opening/Closing the Web Port 22  
Operating Bank 72  
OPTION66\_ENABLE 177  
OPTION66\_REBOOT 177  
Other Network Settings 27  
OUTBANDDTMF\_n 236  
OUTBANDDTMF\_VOL 237  
Outbound Proxy Server 107  
Outbound Proxy Server Address 107  
Outbound Proxy Server Port 107  
Outline 2  
Overview of Programming 20

**P**

Parameter (No. 1–24) 134

PC (Priority) 84, 85  
PC (VLAN ID) 84, 85  
PC Port 82  
PCMA (Enable) 120  
PCMA (Priority) 120  
PCMU (Enable) 121  
PCMU (Priority) 121  
PERIODIC\_INFORM\_ENABLE 185  
PERIODIC\_INFORM\_INTERVAL 185  
PERIODIC\_INFORM\_TIME 185  
Phone Number 76, 105  
Phone User Interface Feature List and Direct Commands 56  
Phone User Interface Programming 20, 56  
PHONE\_NUMBER\_n 244  
Phonebook Data in Text Format 270  
Phonebook deletion 56  
Phonebook Import and Export 268  
Port Close Timer 98  
Port Forwarding 28  
PORT\_PUNCH\_INTVL\_n 256  
POUND\_KEY\_DELIMITER\_ENABLE 221  
Pre-provisioning 34  
Presence Server Address 107  
Presence Server Port 107  
Primary DNS Server 19, 75, 79, 80, 192, 193  
Priority of Setting Methods 45  
Product Configuration File 39, 149, 179  
Product File URL 149  
PROFILE\_ENABLEn 245  
PROVISION\_ENABLE 178  
Provisioning 38  
Provisioning Maintenance 40, 147, 148  
Provisioning Server 37, 43  
Provisioning Settings 40, 155, 177  
Proxy Server Address 89, 106  
Proxy Server Port 89, 107  
Proxy Server Settings 89

**Q**

Quality of Service (QoS) 112, 116

**R**

Recommended Environment 22  
REDIALKEY\_CALLOG\_ENABLE 207  
Refresh Button 25, 73, 76  
REG\_EXPIRE\_TIME\_n 248  
REG\_INTERVAL\_RATE\_n 248  
REG\_RTX\_INTVL\_n 258  
Registrar Server Address 106  
Registrar Server Port 106  
Related Documentation 2  
Reliability of Provisional Responses 112, 254  
Reorder Tone 138  
REORDER\_TONE\_FRQ 213  
REORDER\_TONE\_GAIN 213  
REORDER\_TONE\_RPT 213  
REORDER\_TONE\_TIMING 213  
Reset 29  
Reset to Defaults 151  
Reset Web ID/Password 23, 57

- Reset Web Settings 30  
Reset Web Settings Button 151  
Resource List URI 128  
RESOURCELIST\_URI\_n 241  
Restart 152  
Restart Button 152  
Result Messages 26  
Resync Interval 150  
RETURN\_VOL\_SET\_DEFAULT\_ENABLE 242  
RFC2543\_HOLD\_ENABLE\_n 238  
RINGBACK\_TONE\_FRQ 214  
RINGBACK\_TONE\_GAIN 214  
RINGBACK\_TONE\_RPT 214  
RINGBACK\_TONE\_TIMING 214  
Ringing Tone 137  
RINGING\_OFF\_SETTING\_ENABLE 206  
Root Certificate 44, 198  
Router Setup 29  
RTCP Enable 117  
RTCP Interval 117  
RTCP Packet QoS (DSCP) 116  
RTCP\_ENABLE\_n 235  
RTCP\_INVL\_n 233  
RTCP\_SEND\_BY\_SDP\_n 236  
RTP (Real-time Transport Protocol) Setup 29  
RTP Packet QoS (DSCP) 116  
RTP Packet Time 114  
RTP Settings 29, 114, 162, 232  
RTP\_CLOSE\_ENABLE\_n 236  
RTP\_PORT\_MAX 234  
RTP\_PORT\_MIN 234  
RTP\_PTIME 235
- S**
- Save Button 25, 26  
SDP\_USER\_ID\_n 259  
Secondary DNS Server 19, 75, 79, 81, 192, 193  
Secure Provisioning Methods 44  
Security 113  
Send SUBSCRIBE to Voice Mail Server 122  
Service Domain 108  
Setting Configuration File Parameters Using TR-069 50  
Setting Priority 45  
Shared Call 127, 240  
SHARED\_CALL\_ENABLE\_n 240  
SIP Authentication 108  
SIP extensions 112  
SIP Packet QoS (DSCP) 112  
SIP Server 106  
SIP Service Domain 108  
SIP Setting 104  
SIP Settings 28, 103, 104, 163, 243  
SIP Settings [Line 1]–[Line x] 104  
SIP Setup 28  
SIP Source Address Filter (SSAF) 113, 261  
SIP Source Port 108  
SIP URI 106  
SIP User Agent 104  
SIP\_100REL\_ENABLE\_n 253  
SIP\_18X\_RTX\_INVL\_n 254  
SIP\_2NDPROXY\_ADDR\_n 249  
SIP\_2NDPROXY\_PORT\_n 249  
SIP\_2NDPRSNC\_ADDR\_n 255  
SIP\_2NDPRSNC\_PORT\_n 255  
SIP\_2NDRGSTR\_ADDR\_n 250  
SIP\_2NDRGSTR\_PORT\_n 250  
SIP\_403\_REG\_SUB\_RTX\_n 266  
SIP\_ADD\_DIVERSION\_n 264  
SIP\_ADD\_ROUTE\_n 266  
SIP\_ADD\_RPORT\_n 256  
SIP\_ANM\_DISPNAME\_n 260  
SIP\_ANM\_HOSTNAME\_n 261  
SIP\_ANM\_USERNAME\_n 261  
SIP\_AUTHID\_n 245  
SIP\_CONTACT\_ON\_ACK\_n 262  
SIP\_DETECT\_SSAF\_n 261  
SIP\_DNSSRV\_ENA\_n 252  
SIP\_FOVR\_DURATION\_n 265  
SIP\_FOVR\_MAX\_n 252  
SIP\_FOVR\_MODE\_n 265  
SIP\_FOVR\_NORSP\_n 251  
SIP\_HOLD\_HOLDRECEIVE\_n 264  
SIP\_INVITE\_EXPIRE\_n 254  
SIP\_OUTPROXY\_ADDR\_n 259  
SIP\_OUTPROXY\_PORT\_n 260  
SIP\_P\_PREFERRED\_ID\_n 258  
SIP\_PASS\_n 246  
SIP\_PRIVACY\_n 258  
SIP\_PRSNC\_ADDR\_n 254  
SIP\_PRSNC\_PORT\_n 255  
SIP\_PRXY\_ADDR\_n 246  
SIP\_PRXY\_PORT\_n 246  
SIP\_RCV\_DET\_HEADER\_n 262  
SIP\_REFRESHER\_n 252  
SIP\_REQURI\_PORT\_n 257  
SIP\_RESPONSE\_CODE\_CALL\_REJECT 265  
SIP\_RESPONSE\_CODE\_DND 265  
SIP\_RGSTR\_ADDR\_n 247  
SIP\_RGSTR\_PORT\_n 247  
SIP\_SESSION\_METHOD\_n 248  
SIP\_SESSION\_TIME\_n 248  
SIP\_SRC\_PORT\_n 246  
SIP\_SUBS\_EXPIRE\_n 257  
SIP\_SVCDOMAIN\_n 247  
SIP\_TCP\_SRV\_PREFIX\_n 253  
SIP\_TIMER\_B\_n 262  
SIP\_TIMER\_D\_n 262  
SIP\_TIMER\_F\_n 263  
SIP\_TIMER\_H\_n 263  
SIP\_TIMER\_J\_n 263  
SIP\_TIMER\_T1\_n 250  
SIP\_TIMER\_T2\_n 250  
SIP\_TIMER\_T4\_n 251  
SIP\_TRANSPORT\_n 260  
SIP\_UDP\_SRV\_PREFIX\_n 253  
SIP\_URI\_n 244  
SIP\_USER\_AGENT 243  
Sound Quality 57  
Source Port 108  
SRV lookup Prefix for TCP 110  
SRV lookup Prefix for UDP 109  
SSAF → SIP Source Address Filter 113, 261  
SSL 44  
Standard Configuration File 39, 148, 178  
Standard File URL 148

Start Day and Time of DST (Start Day and Time of Summer Time) 101  
 Static IP Address 79  
 Static NAPT Settings 91  
 Static Settings 79  
 STATIC\_GATEWAY 191  
 STATIC\_IP\_ADDRESS 190  
 STATIC\_SUBNET 191  
 Statistical Information 117  
 Status 60  
 Status Tab 60, 71  
 STUN Server 90, 200  
 STUN Server Address 90  
 STUN Server Port 91  
 STUN Settings 157, 200  
 STUN\_2NDSERV\_ADDR 200  
 STUN\_2NDSERV\_PORT 200  
 STUN\_SERV\_ADDR 200  
 STUN\_SERV\_PORT 200  
 Stutter Tone 138  
 SUB\_INTERVAL\_RATE\_n 259  
 SUB\_RTX\_INTVL\_n 257  
 Subnet Mask 74, 80  
 Supports 100rel (RFC 3262) 112  
 Supports RFC 2543 (c=0.0.0.0) 119  
 Supports Rport (RFC 3581) 113  
 Supports Session Timer (RFC 4028) 112  
 Synchronization 99  
 Synchronization Interval 99  
 Synchronize Do Not Disturb and Call Forward 127  
 Syslog Settings 154, 173, 290  
 SYSLOG\_ADDR 174  
 SYSLOG\_EVENT\_CFG 174  
 SYSLOG\_EVENT\_SIP 173  
 SYSLOG\_EVENT\_TEL 174  
 SYSLOG\_EVENT\_VOIP 174  
 SYSLOG\_PORT 175  
 SYSLOG RTPSMLY\_INTVL\_n 175  
 System 63  
 System Settings 154, 167  
 System Tab 63, 94  
 System Time Settings 154, 168

**T**

T1 Timer 110  
 T2 Timer 110  
 Tab-separated Value (TSV) 141, 269, 271  
 TALK\_PACKAGE 205  
 Talking URL 143  
 TCP/IP Settings 18  
 TCP/IP Settings (DHCP or Static IP Address Assignment) 18  
 Technical Support 2  
 Telephone 68  
 Telephone Settings 139, 158, 160, 202, 219  
 Telephone Tab 68, 121  
 Telephone-event Payload Type 115  
 TELEVENT\_PAYLOAD 237  
 Terminal No. 56  
 Terminal Number Settings 56  
 TFTP Server 34, 35, 177  
 Time 102, 103

Time Adjust Settings 99, 157, 199  
 Time Server 100  
 Time Zone 100  
 TIME\_QUERY\_INTVL 199  
 TIME\_SYNC\_INTVL 199  
 TIME\_ZONE 168  
 Timer B 111  
 Timer D 111  
 Timer F 111  
 Timer for Dial Plan 123  
 Timer H 111  
 Timer J 112  
 Timer Settings 110  
 Timing of Downloading 40  
 Tone Frequencies 135, 136, 137, 138  
 Tone Settings 135, 159, 209  
 Tone Timings 136, 137, 138, 139  
 TONE\_LEN\_DISCONNECT\_HANDSET 207  
 TONE\_LEN\_DISCONNECT\_HANDSFREE 208  
 TR-069 50  
 Trademarks 2  
 Transport Protocol 110  
 Transport Protocol of SIP 110  
 Troubleshooting 287  
 TSV → Tab-separated Value 141, 269, 271  
 Type (No. 1–24) 134

**U**

UDP\_CON\_REQ\_ADDR\_NOTIFY\_LIMIT 189  
 Unconditional (Enable Call Forward) 130  
 Unconditional (Phone Number) 131  
 Update Firmware Button 146, 285  
 Update Type 146  
 URL 142, 143, 144  
 USE\_DEL\_REG\_CLOSE\_n 256  
 USE\_DEL\_REG\_OPEN\_n 255  
 USER\_DNS1\_ADDR 192  
 USER\_DNS2\_ADDR 192  
 USER\_ID 168  
 USER\_PASS 168  
 Using 2 Types of Configuration Files 39  
 Using 3 Types of Configuration Files 39

**V**

Version Information 72  
 VLAN Settings 84  
 VLAN\_ENABLE 194  
 VLAN\_ID\_IP\_PHONE 194  
 VLAN\_ID\_PC 195  
 VLAN\_PRI\_IP\_PHONE 194  
 VLAN\_PRI\_PC 195  
 VM\_NUMBER\_n 239  
 VM\_SUBSCRIBE\_ENABLE 202  
 Voice Mail Access Number 126  
 VOICE\_MESSAGE\_AVAILABLE 243  
 VoIP 65  
 VoIP Settings 114, 116, 161, 230  
 VoIP Settings [Line 1]–[Line x] 116  
 VoIP Status 75, 76, 290  
 VoIP Tab 65, 103

**W**

Web Language 21, 94  
Web Port 22, 25, 98  
Web Port Close Button 22, 24, 25  
Web Server Port 98  
Web Server Settings 97, 98  
Web User Interface Programming 21, 59  
Web User Interface Setting List 60  
Web User Interface Window 24

**X**

XML Application Settings 161, 225  
XML\_ERROR\_INFORMATION 230  
XML\_HTTPD\_PORT 230  
XML\_INITIATE\_KEY\_FLASH 229  
XML\_INITIATE\_KEY\_FWDDND 229  
XML\_INITIATE\_KEY\_SOFT1 228  
XML\_INITIATE\_KEY\_SOFT2 229  
XML\_INITIATE\_KEY\_SOFT3 229  
XML\_INITIATE\_KEY\_SOFT4 229  
XMLAPP\_CALLLOG\_URL 227  
XMLAPP\_ENABLE 225  
XMLAPP\_IDLING\_URL 227  
XMLAPP\_INCOMING\_URL 226  
XMLAPP\_INITIAL\_URL 226  
XMLAPP\_LDAP\_URL 228  
XMLAPP\_LDAP\_USERID 228  
XMLAPP\_LDAP\_USERPASS 228  
XMLAPP\_MAKECALL\_URL 227  
XMLAPP\_START\_URL 226  
XMLAPP\_TALKING\_URL 227  
XMLAPP\_USERID 225  
XMLAPP\_USERPASS 226



**Panasonic System Networks Co., Ltd.**

1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

**Copyright:**

This material is copyrighted by Panasonic System Networks Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic System Networks Co., Ltd.

© Panasonic System Networks Co., Ltd. 2011

**PNQX3582VA DD0611MK4062**