

## Easy-TV5

### English

Universal remote control

Batteries NOT included!

Made in Peoples Republic of China

Produced for Geemarc

All technical data and illustrations are subject to errors, deviations & modifications.

On/off switch

AV button

Volume up or volume down

Key for device A/B with LED status

Channel up or channel down

### Programming of Easy-TV5

With the Easy-TV5 one is able to control any two devices (e.g. TV, receiver, VCR, etc.). For this purpose, two profiles, identified by the letters "A" and "B" are stored in the remote control. For successful programming, you need the original remote control of the device, which is then to be programmed in.

#### Step 1

To access learning mode, please hold the key "A" or "B" and "□" key on the Easy-TV5 simultaneously for 5 seconds. Now the LED next to the "A" or "B" button lights up permanently. The remote control is now in learning mode.

#### Step 2

Place or hold both remotes with the respective infrared sensor (usually on the top of the remote) at a distance of approximately 2.5 cm apart.

#### Step 3

Now you can press the key on the Easy-TV5 which you want to program. The LED next to the "A" or "B" button goes out.

#### Step 4

After you have selected and pressed the key to be programmed by the Easy-TV5, you can press the corresponding key on the original remote control. If this signal is received correctly, the LED will light up for a second and thereafter for 3 short flashes.

#### Step 5

To program other keys you now select the next key on the Easy-TV5 by pressing on it and repeating steps 3 and 4.

#### Step 6

To exit learning mode after successful programming of the keys, press the "A" or "B" key.

### Nederlands

Universele afstandsbediening

Batterijen NIET meegeleverd!

Gefabriceerd in de Volksrepubliek China

Geproduceerd voor Geemarc

Alle technische gegevens en afbeeldingen kunnen fouten, afwijkingen en veranderingen bevatten.

AAN/UIT schakelaar

AV knop

Volume omhoog of omlaag

Toets voor A/B apparaat met LED status

Kanaal omhoog of omlaag

### De Easy-TV5 programmeren

U kunt twee willekeurige apparaten (bijv. TV, ontvangsttoestel, VCR, enz.) met de Easy-TV5 bedienen. Daartoe zijn twee profielen (aangeduid met de letters 'A' en 'B', opgeslagen in de afstandsbediening. Om de Easy-TV5 met succes te programmeren heeft u de originele afstandsbediening van het apparaat nodig, zodat u deze in de Easy-TV5 kunt programmeren.

#### Stap 1

Om de programmeringstand te openen moet u de toetsen 'A' of 'B' en 'V' op de Easy-TV5 voor 5 seconden tegelijk indrukken. Nu zal de LED naast de knoppen continue gaan branden. De afstandsbediening staat nu in de programmeringstand.

#### Stap 2

Zet en houd beide afstandsbedieningen met hun infrarood sensor (gewoonlijk aan de bovenkant van de afstandsbediening) tegenover elkaar op een afstand van ongeveer 2,5 cm.

#### Stap 3

U kunt nu op de Easy-TV5 de toets die u wilt programmeren indrukken. De LED naast de 'A' of 'B' knop gaat uit.

#### Stap 4

Nadat u de op de Easy-TV5 te programmeren toets heeft gekozen en ingedrukt, kunt u de corresponderende toets op de originele afstandsbediening indrukken. Als dit signaal correct is ontvangen, zal de LED één seconde oplichten en vervolgens drie keer kort knipperen.

#### Stap 5

Om de andere toets te programmeren drukt u op de volgende toets op de Easy-TV5 en herhaalt u de stappen 3 en 4.

#### Stap 6

Nadat u de toetsen met succes heeft geprogrammeerd, drukt u op toets 'A' of 'B' om de programmeringstand af te sluiten.