

5) Troubleshooting

All the devices are carefully inspected and tested. If trouble occurs during the use of PYRAMID, correct the problem by reference to the following.

The lamp does not light:

Check the mains connection.

Check the telephone line connections: only the central two wires inside the PYRAMID telephone cable must be connected.

The lamp is blown. Refer to qualified personnel and ask for replacing.

DO NOT attempt to replace the lamp with similar kind of lamps. PYRAMID one has a special high voltage halogen lamp, hard to find. An incorrect replacing will permanently damage the device.

The lamp stops to work after many rings:

PYRAMID One has a thermal shutdown protection in order to prevent case overheating. If the lamp has been lit many times or the device is positioned in a warm place, the thermal protection may shut down the circuit. In this case, just wait until the device cools down and you will see that it will start working normally again.

6) Guarantee


PYRAMID One is guaranteed one year from purchasing date for all manufacturing defect.

The faulty device has to be returned to the dealer with this manual, the attached coupon duly compiled and the purchasing receipt.

The guarantee does not cover damages due to incorrect use of the device and it is no longer valid if the device has been opened, modified or tampered.

PYRAMID

ONE



Ringer Flash Signaler

Operating Instruction



Recycling directives

The WEEE (Waste Electrical and Electronic Equipment) has been put in place for the products in end of life are recycled in the best way.

When this product is out of order, please do not put it in your domestic waste bin. Please use one of following disposal options.

- Remove the batteries and deposit them in an appropriate WEEE skip.**
- Deposit the product in an appropriate WEEE skip.**
- Or hand the old product to the retailer. If you purchase a new one, they should accept it.**

Thus if you respect these instructions you ensure human health and environmental protection.

1) Introduction

Congratulation on your purchase of "PYRAMID One", the Ringer notification flash, a unique device with its particular shape and its powerful halogen lamp. This device is made according to the highest quality standards and it has full compliance with EMC & Safety rules. It is important to read all of these instruction before the product is operated.

2) Warnings

Connect this device only to a 220/240V 50Hz mains.

Do not damage cables. Route them carefully.

Position the device where it can be easily cooled down: the lamp rapidly overheat when it is lit.

Never leave the device near heaters, ovens, powerful lamps or exposed to direct sunlight: plastic case or internal circuits may be permanently damaged.

NOTE: The device is protected against overheating. When the temperature exceeds the limits, the protection circuitry switches off the device.

DO NOT use the device near water (laundry tub, wash bowl) or in wet places like bathrooms, swimming pools.

DO NOT insert any kind of object or spill liquids inside the device: electric shocks or fire may occur. This device is NOT a toy: please, keep away from children.

Do not attempt to service this device yourself. Opening the cover may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

If the device has been damaged or do not operate properly, disconnect all the wirings and refer to qualified personnel.

Unplug the device from mains before cleaning. Use a damp cloth for cleaning. Do not use liquid cleaners or aerosol cleaners.

3) Installation

The installation of PYRAMID One is very easy and quick.

- A) Position the device in a safe place, with good visibility.
- B) Connect the power supply cord (1) in the 220/240 mains socket. If the socket is not compatible with the PYRAMID plug, do not cut the cable; install a suitable adapter instead (2).
- C) Connect one end of the equipped telephone cable (3) to the RJ socket on the PYRAMID (4) and the other side in parallel to the existing telephone line, according to the local rules.

4) Using PYRAMID One

PYRAMID One is extremely simple to use because it is completely automatic. If correctly installed, when the phone rings, its internal lamp will light during the ring sound.

Thus until someone picks up the telephone or the caller hangs up.

