

Quick reference guide Konftel 60W

Connection to computer via USB

English

Konftel is a leading company within loudspeaker communication and audio technology. We develop and sell products and technology for telephone meetings based on cutting-edge expertise within acoustics and digital signal processing. Characteristic of our products is that all conference telephones contain the same high quality audio technology – OmniSound® – providing crystal clear sound. Learn more about Konftel and our other products on www.konftel.com.

Developed by Konftel AB
Box 268, SE-901 06 Umeå, Sweden
Phone: +46 90 706 489 Fax: +46 90 131 435
E-mail: info@konftel.com Web: www.konftel.com

Conference phones for every situation






OVERVIEW

LEDs
Blue – microphone on
Red – microphone muted


Loudspeakers, x3

Microphone, 360° sound pick-up



- On/off button**
Transfer the call from your computer to the Konftel 60W
- button**
Decrease the speaker volume
- Mute button**
Briefly press to mute the microphone
- + button**
Increase the speaker volume
- Trim button**
Tune your Konftel 60W manually.

CONNECTION



Only mains transformer of types Helms-Man DEN4824129, DPX481821 (USA) or DBN4824129 (UK) may be connected.

USB adapter with cable
Item no. 900102058
(optional)

VOLUME CONTROL



Select Volume control from the Start Menu:

Start > Control panel > Sounds and Audio Devices.

Enter the tab Audio and make sure that the USB Headset is the default device.



Loudspeaker volume

Select Volume by the Sound playback and adjust the loudspeaker volume.

The volume can be adjusted via the Konftel 60W when necessary.




Microphone volume

Select Volume by the Sound recording and adjust the microphone volume for Mic in.

The volume can be adjusted via the Konftel 60W when necessary as described below.

Adjust the microphone volume on the Konftel 60W



Connect a call and press the Mute button for 2 seconds until the LEDs start flashing.

Adjust the microphone volume to a minimum level. Note that if the level is too high, it may cause echoes.

Press the Mute button to save the volume setting.

MAKING OR ANSWERING A CALL



Answer or make a call with your IP Softphone (i.e. Skype etc.).

Switch to loudspeaker by pressing the On/off-button on your Konftel 60W.

ENDING A CALL



End the call on your IP Softphone. Press the On/off button to turn off the Konftel 60W.

For other functions and information, please refer to your Konftel 60W User Guide on www.konftel.com