



Hotel Compact Type IP Phone HS108v2 Quick Operator Guide



Message Light


LED Status	Description
Red, flashing	There is an incoming call or call on hold.
Red, steady	Pick up and enter normal call.
Lighting-off	Free

Mounting Bracket



2-1

Network Connection



Network Setting

If you want to set of network information, Pls login into WEB>Network
LAN Port: Type/IP/Mask/GW/DNS1or2/Web Port/Telnet Port

Register

Login into WEB> SIP account Setting,
As the following options is main functions .
a)Enable account* b)Account Mode c)User Name* d)user pwd*
e)SIP1*
When you finished above setting, your account will be work now.

Placing a Call

- **Speaker:** Press **Speaker** button and dial number directly, then press # button to dial.
- **Dial directly:** Dial number directly, then press # button to dial
- **Redial:** Press **Redial** button/soft-key to dial the latest number;

2-2

Flash Key

Flash keys function:

- During a call, press the flash key to enter the transferred pattern with dial tone. The call will be holding.
- When transferring the dialing, pressing the flash key can cancel the transferred function. The call still be holding.
- Pressing the flash key can recover the on holding call

Volume Adjustment

Phone Status	Corresponding volume
Standby	Ring volume
Hook off	Handset volume

You can adjust the corresponding input volume as follow:

- Web Set: Enter website >select "Volume setting".

*For details, you can refer to the corresponding User Manual.

Summary

List	Count
Phone	1
Cable	1
Quick Operator Guide	1



ES CENE COMMUNICATION CO.,LTD.
Web: <http://www.escene.cn/en>
Address: Floor 4 Building C YueAn Industrial Park No.51 Huangcun Road
Tianhe District Guangzhou China

2-3