

## Model RF-200

*It's as easy as 1,2,3*


### Quick Start Guide Cell Phone Ringer/Flasher



(cellphone not included.)

#### Connection:

1. Connect the RF-200 as shown.




#### Cell Phone Call Alert:

1. Set cell phone ring to "Vibrate" (with or without ringtone) and place it on the RF-200.
2. When your cell phone rings, lift cell phone to answer and press **RESET** on RF-200 to reset.
3. If you did not answer, the flasher light will blink slowly to indicate that you have missed a call.


#### SMS Message Alert:

1. Set cell phone to ringtone (with or without vibrate) and place it on the RF-200. Connect the short cord as shown.
2. When SMS is received, lift cell phone to review. Press **RESET** on the RF-200 to reset.
3. If you did not answer, the flasher light will blink slowly to indicate that you have missed a call.



#### Charging Your Cell Phone:

1. Connect your cell phone charging cable as shown.



#### Landline Call Alert:

1. When your landline phone rings, lift handset to answer.

Need Help? Call Toll-free Help Line:  
**866-376-9271 (8AM - 5PM PST, M-F)**