


GXW FXS Series Configurations

Configure the GXW VoIP Scenario One

- Connect analog phone to existing key system/PBX (or directly to GXW400x);
- Connect key system to GXW400x
- Connect GXW400x to Internet (*via broadband connection*)
- Configure GXW400x to route calls
- **Remote office:**
 - connect GXW400x to Internet (*via broadband connection*)
 - configure GXW400x to route calls to analog phone
- Dial out-going number or extension from remote office or headquarters

Scenario One

Traditional phone system (key system/PBX) with remote analog extensions via VoIP (no PSTN network)



- Dial Suzie's **extension** in Chicago office;
- Call routed through (key system) to GXW400x;
- Call routed over Internet;
- Analog phone rings;
- Suzie says "hello".


Traditional PBX/Key System: Avaya, MiTEL, Panasonic, Sony, NEC, etc.

Configure the GXW VoIP Scenario Two

- Connect IP phone to existing IPPBX or directly through a ITSP provider;
- **Remote office:**
 - connect GXW400x to Internet (*via broadband connection*)
 - configure GXW400x to route calls to analog phone
- Dial out-going number or extension from remote office or headquarters

Scenario Two

Remote office with analog phones via VoIP (no PSTN network)



- Dial Bob in remote office;
- Call routed through IPPBX;
- IPPBX routes call over Internet;
- Call routed to GXW400x;
- Analog phone rings;
- Bob says “hello”.