

GEEMARC CL64

EASY CONNECT CORDED AMPLIFIED TELEPHONE

The Geemarc Clearsound CL64™ is a retro classic style phone which has been specially designed to offer a traditional looking phone to help people with memory loss, they do recognise the retro style phone. It is easy to connect by simply pressing one button!

As with most Geemarc phones the phone is totally hearing aid compatible and has amplification to help those who are hard of hearing. The telephone will ring at 70dB and can be increased further to ring at 80dB with the insertion of 4 x AA Size batteries. The phone has Tone control slide button on the side of the phone for the user to increase or decrease the tone by plus or minus 10dB. The volume control button can increase the caller's voice by an additional 25dB.

In addition to the features above, this phone can also increase or decrease your voice to the caller if they struggle to hear your voice!

There are 3 one touch easy connect buttons – in the centre of the phone is a large SOS button which can be programmed to any number

Underneath the phone is a lockable flap which houses a full numeric keypad to programme the numbers. The lock for the keypad can be unlocked using a coin or your thumbnail.

The phone has 3 ringer options, without batteries inserted the phone has a normal two tone electronic ring, with the batteries you have the UK (tring.. tring..) and European (triiiiing) style bells options as well.

The phone can also dial out if no button is pressed when the hook has been lifted and no button pressed for 4 seconds. It will dial the SOS number, the phone is already programmed to ring 112 as a factory standard. This can be changed using the keypad underneath. The phone has an LED which flashes when an incoming call is received. A small led flashes red when the batteries are becoming low and need replacing.

If the phone is not placed correctly on the cradle the phone will still ring! it automatically goes back on line to allow you to make contact.

A superb phone for carers – programme your number into the phone as the SOS number so your patient knows they can always contact you with the Easy Connect Geemarc CL64™